

[Manuals.plus](#) /

› [STYLUSHOME](#) /

› STYLUSHOME Stylus Pens User Manual

STYLUSHOME B088CW3F8F

STYLUSHOME Stylus Pens User Manual

Model: B088CW3F8F

1. INTRODUCTION

Thank you for choosing STYLUSHOME Stylus Pens. This manual provides essential information for the proper use and maintenance of your new stylus pens. These dual-tip stylus pens are designed for high sensitivity and precision across all capacitive touchscreen devices, offering a smooth and responsive experience for various tasks.



Image: Two STYLUSHOME stylus pens, one black and one one white, with replacement tips shown in the background.

2. PRODUCT OVERVIEW

The STYLUSHOME Stylus Pen features a lightweight aluminum body and a dual-tip design for versatile use.

- **Fiber Tip (0.24-inch):** Ideal for general navigation, scrolling, and light drawing.
- **Clear Disc Tip (0.27-inch):** Provides high precision for detailed writing, drawing, and accurate selection, offering an unobstructed view of the contact point.
- **Magnetic Caps:** Two caps are included, designed to magnetically attach to both ends of the stylus, protecting the tips from damage and preventing loss.
- **Dimensions:** 6.18 inches (15.7 cm) long, 0.52 ounces (14.7 grams) in weight.




Image: Diagram illustrating the components of the stylus pen, including the fiber tip, clear disc tip, aluminum body, and magnetic caps.

Transparent Disc Tip

No obstruction of view & 180-degree writing angle




Image: Detailed view of the transparent disc tip, highlighting its precision and 180-degree writing angle for clear visibility.

3. SETUP

The STYLUSHOME Stylus Pen is designed for immediate use without complex setup. It does not require batteries or Bluetooth connection.

1. **Unpack:** Carefully remove the stylus pens and any included accessories from the packaging.
2. **Remove Caps:** Detach the magnetic caps from the desired tip before use. Store the caps securely to prevent loss.
3. **Ready to Use:** The stylus is now ready for interaction with your touchscreen device.

Important Note for iPad Users:

If you are using an iPad and experience issues, please ensure that any active Apple Pencil or similar stylus is disconnected. You may also need to adjust settings within specific applications to ensure proper stylus functionality. Refer to the 'APP Setup Guide' provided with your product or scan the QR code on the packaging for more details.

4. OPERATING INSTRUCTIONS

Your STYLUSHOME Stylus Pen is compatible with all capacitive touchscreen devices, including iPads, iPhones, smartphones, tablets, and laptops. It functions as a precise extension of your finger.

- **General Navigation:** Use either tip for tapping, swiping, and scrolling on your device's screen.
- **Writing and Drawing:** For precise lines and detailed work, utilize the clear disc tip. The transparent disc allows you to see exactly where your mark will appear.
- **Gaming:** Enhance your mobile gaming experience with improved control and accuracy.
- **Note-Taking:** Use the stylus for digital note-taking, sketching diagrams, and annotating documents.







Image: Examples of stylus usage for studying, drawing, browsing, and playing games on different touchscreen devices.

Transparent Disc Tip

No obstruction of view & 180-degree writing angle



Image: Stylus being used for video editing on a tablet.

Upgraded Reinforced Tip

Higher quality & Easier to replace



ours

Reinforced Metal Ring



others

Normal Fiber Tip

Image: Stylus being used for note-taking on a tablet, showing a mind map.

Comfortable to Hold

This metal stylus is made of aluminum alloy, with a stylish appearance, comfortable grip, and moderate weight.



Image: Stylus being used for gaming by a child and an adult.

StylusHome

Stylus Pens for Touchscreens - 2 Pack



Image: Stylus being used for digital drawing on a tablet.

Official Product Video: App Settings Reference

Your browser does not support the video tag.

Video: This video from StylusHome provides a reference for adjusting app settings, particularly useful for note-taking applications.

5. MAINTENANCE

Proper care will extend the life of your stylus pens.

- **Cleaning:** Wipe the stylus body with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Tip Protection:** Always use the magnetic caps when the stylus is not in use to protect both the fiber and disc tips from damage.
- **Storage:** Store the stylus in a clean, dry place, ideally in a case or a stylus slot if your device case has one.

2-in-1 High Precision Stylus Pens

No Lag, Continues Line, No Slip



Image: The stylus pen fitting into a dedicated slot on an iPad case for convenient storage.

Tip Replacement

Replacement tips are available for purchase. Search ASIN: B08L34JX24 or B08L355KQV for StylusHome replacement tips.

To replace the Disc Tip:

- 1. Gently pull out the old disc tip.
- 2. Insert the new disc tip firmly into place.

To replace the Fiber Tip:

- 1. Turn to unscrew and remove the old fiber tip.
- 2. Screw in the new fiber tip until secure.



Easy to Carry & Storage

The stylus is sized to fit in the stylus slot of the iPad case for easy storage.

Image: Instructions for replacing both the clear disc tip and the fiber tip.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Stylus not responding or inconsistent.	Screen protector too thick; dirty screen/tip; active pencil connected (iPad); worn-out tip.	Ensure screen protector is compatible. Clean screen and stylus tip. Disconnect other active styluses. Replace tip if worn.
Disc tip feels loose or falls off.	Tip not fully inserted; tip mechanism worn.	Ensure tip is pushed in firmly. If issue persists, replace the tip.
Magnetic cap does not stay on.	Magnet weakened or damaged.	Contact customer support if the cap is defective.
Stylus leaves marks or scratches.	Tip is damaged or dirty.	Inspect tip for damage. Clean tip thoroughly. Replace tip if damaged.

7. SPECIFICATIONS

- **Product Dimensions:** 6.18 x 0.35 x 0.35 inches (15.7 x 0.89 x 0.89 cm)
- **Item Weight:** 0.52 ounces (14.7 grams)
- **Material:** Aluminum alloy body
- **Tips:** 0.24-inch fiber tip, 0.27-inch clear disc tip
- **Compatibility:** All capacitive touchscreen devices (iPad, iPhone, Smartphones, Tablets, Laptops)
- **Battery Required:** No
- **Bluetooth Connection:** No
- **Color:** Black/White
- **Model Number:** B088CW3F8F
- **UPC:** 303276839542

8. WARRANTY AND SUPPORT

STYLUSHOME provides a **2 Years Limited Warranty** for this product. This warranty covers manufacturing defects and ensures product quality.

For customer support, inquiries, or warranty claims, please contact STYLUSHOME customer service:

- **Email:** sales@stylushomeusa.com
- **Service Availability:** 24/7 customer support
- **Returns:** Free returns with no questions asked



Image: Customer service details, including warranty information and contact email.

For more information and product updates, visit the official STYLUSHOME YouTube channel![STYLUSHOME
YouTube Channel](#)

© 2025 STYLUSHOME. All rights reserved.