

NPET WK20

NPET WK20 Wireless Keyboard User Manual

Brand: NPET | Model: WK20

1. INTRODUCTION

Thank you for choosing the NPET WK20 Wireless Keyboard. This full-size keyboard is designed for efficiency and comfort, featuring a 2.4 GHz wireless connection, a dedicated number pad, and 14 multimedia keys. Its durable, spill-proof design and long battery life make it an ideal companion for your PC or laptop, whether at home or in the office. This manual provides detailed instructions to help you get the most out of your new keyboard.



Figure 1: NPET WK20 Wireless Keyboard Overview

2. FEATURES

- **2.4 GHz Wireless Connectivity:** Enjoy a strong, reliable wireless connection with up to 33 ft (10m) range, ensuring no drop-outs or delays.
- **Full-Size Layout:** Standard full-size keyboard with all F-keys, a dedicated number pad, and arrow keys for comprehensive functionality.

- **14 Multimedia Hotkeys:** Quick access to essential functions like Internet, E-mail, play/pause, volume control, and more, enhancing productivity.
- **Long-lasting Battery Life:** Powered by a single 1.5V AA battery (not included), offering up to 24 months of battery life with a convenient on/off switch.
- **Spill-Proof Design:** Engineered to withstand accidental spills, allowing liquids to drain through, protecting internal components.
- **Durable Construction:** Features durable print characters and water drop-shaped keycaps for comfortable and long-lasting use.
- **Adjustable Tilt Legs:** Customize your typing angle for improved ergonomics and comfort.



Figure 2: Overview of 14 Quick-access Hotkeys for enhanced productivity.




Figure 3: The keyboard features a spill-resistant design, allowing liquids to drain safely.

3. SETUP GUIDE

1. **Install Battery:** Locate the battery compartment on the underside of the keyboard. Open the cover and insert one 1.5V AA battery (not included), ensuring correct polarity. Close the battery compartment cover securely.
2. **Locate USB Receiver:** The compact USB receiver is typically stored inside the battery compartment for convenience. Carefully remove it.
3. **Connect USB Receiver:** Plug the USB receiver into an available USB port on your desktop, laptop, or netbook computer.
4. **Power On Keyboard:** Locate the On/Off switch on the top right side of the keyboard and slide it to the "On" position. The keyboard is plug-and-play, requiring no additional software installation.
5. **Adjust Tilt (Optional):** Flip out the adjustable tilt legs on the underside of the keyboard to achieve your preferred typing angle.

Plug and Play



Figure 4: Simply plug the USB receiver into your computer for instant wireless connectivity.

Stronger Battery Life



Figure 5: The keyboard features a power switch and offers up to 24 months of battery life.

Your browser does not support the video tag.

Video 1: Official NPET WK20 Wireless Keyboard setup and feature overview. This video demonstrates the ease of setup and highlights key functionalities.

4. OPERATING INSTRUCTIONS

4.1 Basic Typing

The NPET WK20 keyboard provides a comfortable and responsive typing experience. The spherically dished keys are designed for perfect stroke and fluid, efficient, and responsive typing.



Figure 6: The unique water drop-shaped keycaps provide a comfortable and precise typing experience.

4.2 Multimedia Keys and Hotkeys

The keyboard features 14 dedicated multimedia hotkeys located above the function keys (F1-F12) and integrated into the F-keys themselves. These provide instant access to frequently used functions.

- **Dedicated Multimedia Keys:** Control media playback (play/pause, stop, previous/next track), volume (mute, volume down, volume up), and quick access to browser, email, and calculator.
- **Function (Fn) Key Combinations:** Use the 'Fn' key in combination with F1-F12 for additional shortcuts, as indicated by the icons on the keys.

12 Multimedia Shortcuts




Figure 7: The keyboard includes 12 dedicated multimedia shortcuts for quick access to common functions.

Improve Working Efficiency



Figure 8: Detailed illustration of hotkey functions and Fn key combinations for improved working efficiency.

Your browser does not support the video tag.

Video 2: Demonstration of the WK20 Wireless Keyboard's features, including its quiet typing and multimedia keys.

5. MAINTENANCE

5.1 Cleaning

To clean your keyboard, gently wipe the surface with a soft, damp cloth. For deeper cleaning, especially after spills, ensure the keyboard is powered off and the USB receiver is disconnected. The spill-proof design allows liquids to drain, but it is recommended to dry the keyboard thoroughly before resuming use.

5.2 Battery Replacement

When the battery indicator light (located near the On/Off switch) begins to flash or the keyboard becomes unresponsive, it's time to replace the battery. Follow the steps in Section 3.1 to replace the 1.5V AA battery.



Figure 9: Indicator lights for Num Lock, Caps Lock, and Power/Battery status.

6. TROUBLESHOOTING

- **Keyboard not responding:**
 - Ensure the keyboard is powered on.
 - Check the battery level and replace if necessary.
 - Verify the USB receiver is securely plugged into a working USB port on your computer.
 - Try plugging the USB receiver into a different USB port.
 - Ensure the keyboard is within the 33 ft (10m) operating range of the USB receiver.
- **Keys are sticky or unresponsive:**
 - Clean the keyboard as described in the Maintenance section.
 - Ensure no debris is lodged under the keys.
- **Battery indicator light is flashing:**
 - This indicates low battery. Replace the AA battery.

7. SPECIFICATIONS

Attribute	Detail
Model Number	WK20
Product Dimensions	17.52 x 5.87 x 0.93 inches
Item Weight	1.39 pounds
Connectivity Technology	2.4 GHz Wireless (USB Receiver)
Operating Range	Up to 33 ft (10m)
Battery Type	1 x 1.5V AA Battery (not included)
Battery Life	Up to 24 months
Number of Keys	118 (Full-size with 14 multimedia keys)
Compatible Devices	PC (Windows 7, 8, 10, or later)
Special Features	Spill-proof design, Adjustable tilt legs, Water drop-shaped keycaps

8. WARRANTY AND SUPPORT

The NPET WK20 Wireless Keyboard is built for durability and comes with a 24-month battery life expectation, indicating the product's robust design. For any product inquiries, technical support, or warranty claims, please visit the official NPET website or contact their customer service.

Official NPET Store: [Visit NPET Store on Amazon](#)

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question