

Manuals.plus /

› FFsign /

› FFsign Replacement Steam Mop Pads for Bissell PowerFresh Steam Mops (Models 1940, 1440, 1544, 1806, 2075 Series) - Instruction Manual

FFsign 1940-6

FFsign Replacement Steam Mop Pads for Bissell PowerFresh Steam Mops (Models 1940, 1440, 1544, 1806, 2075 Series) - Instruction Manual

Product

[Overview](#)

[Installation](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Support](#)

1. PRODUCT OVERVIEW

This manual provides instructions for the FFsign Replacement Steam Mop Pads, designed for use with various Bissell PowerFresh Steam Mop models. These pads are engineered to provide effective cleaning on sealed hard floors.

1.1 Pad Types

The 6-pack includes two types of pads to address different cleaning needs:

- **Soft Microfiber Mop Pads (3 pieces):** Ideal for daily cleaning and general use on delicate surfaces.
- **Microfiber Mop Pads with Scrubbing Strips (3 pieces):** Designed for tackling tough, sticky messes and more stubborn dirt.




Figure 1: Assortment of FFsign Replacement Steam Mop Pads. This image displays three soft microfiber pads and three microfiber pads with scrubbing strips, highlighting the variety included in the pack.

Microfiber Stripe Pads for Dirt & Messes



Figure 2: Microfiber Stripe Pad for Dirt and Messes. This detailed view shows the textured scrubbing strips and the mesh material on the back of the pad, designed for effective removal of stubborn dirt.

Microfiber Soft Mop Pads For Daily Cleaning



Figure 3: Microfiber Soft Mop Pad for Daily Cleaning. This image highlights the features of the soft pad, including its washable microfiber composition, strong water absorption, durable seamed edge, and quick-drying capability.

1.2 Compatibility

These replacement pads are compatible with the following Bissell PowerFresh Steam Mop series and models:

- **Bissell PowerFresh Steam Mop Series:** 1940, 1440, 1544, 1806, 2075, 2685A, 2814
- **Specific Models:** 19402, 19404, 19408, 19409, 1940A, 1940F, 1940Q, 1940T, 1940W, 15441, 15443, 15446, 15448, 1544A, 1544B, 1806, 2075A, B0006, B0017
- **Replaces Part Numbers:** 5938, 203-2633, 1606668, 1606669

for Bissell Powerfresh Steam Mop :

19402 19404 19408 19409 1940A 1940F 1940Q 1940T 1940W



15441, 1544, 15443, 15446, 15448, 1544A, 1544B

1806, 2075A, B0006, B0017



Compatible part 5938 & 203-2633 1606668 and 1606669



Figure 4: Compatible Bissell PowerFresh Steam Mop Models. This image illustrates various Bissell PowerFresh steam mop models that are compatible with these replacement pads.

2. INSTALLATION

Follow these steps to install the replacement steam mop pads onto your Bissell PowerFresh Steam Mop:

1. Ensure your steam mop is unplugged and cool before handling.
2. Remove the used or dirty mop pad from the mop head. Most Bissell PowerFresh models use a hook-and-loop (Velcro) attachment system.
3. Select the appropriate FFsign replacement pad for your cleaning task (soft microfiber for daily cleaning or scrubbing strip pad for tough messes).
4. Align the new pad with the mop head, ensuring the mesh side (if applicable) faces the mop head.
5. Press the pad firmly onto the mop head until it is securely attached. Ensure the pad covers the entire mop head surface.
6. Your steam mop is now ready for use.

3. OPERATING INSTRUCTIONS

These pads are designed for effective cleaning on various sealed hard floor surfaces. Always refer to your Bissell PowerFresh Steam Mop's original instruction manual for specific operating procedures and safety guidelines.

- **Floor Types:** Suitable for sealed wooden floors, ceramic tile, marble floors, and laminate floors.
- **Cleaning Effectiveness:** The premium microfiber material is designed to capture dirt, water stains, paper scraps, and hair without scratching or smearing floor surfaces.
- **Pad Selection:** Use the soft microfiber pads for general cleaning and the pads with scrubbing strips for areas requiring more aggressive cleaning.



Perfect for all hard seal floors such as



Figure 5: Suitable Floor Types for Cleaning. This image demonstrates that the pads are effective on various sealed hard surfaces, including wooden, marble, laminate, and ceramic floors.

4. MAINTENANCE

Proper maintenance of your FFsign replacement pads will ensure their longevity and continued cleaning performance.

4.1 Cleaning the Pads

The pads are machine washable and reusable:

- **Machine Wash:** Wash pads in warm water with a mild detergent. Do not use bleach or fabric softeners, as these can degrade the microfiber material and reduce its effectiveness.
- **Hand Wash:** For best results or to extend pad life, hand wash with warm water and mild soap.
- **Drying:** Air dry or tumble dry on low heat. Do not iron.
- **Storage:** Store clean, dry pads in a clean, dry place until next use.



Figure 6: Machine Washable and Reusable Pads. This image shows the convenience of cleaning the pads in a washing machine, emphasizing their reusability.

Easy to Clean



Figure 7: Easy Hand Cleaning of Pads. This image illustrates the simplicity of cleaning the mop pads by hand under running water.

5. TROUBLESHOOTING

If you encounter issues with your replacement pads, consider the following common solutions:

Problem	Possible Cause	Solution
Pad does not fit the mop head.	Incorrect mop model or pad not aligned properly.	Verify your Bissell PowerFresh Steam Mop model number against the compatibility list in Section 1.2. Ensure the pad is centered and pressed firmly onto the mop head.
Pad is not cleaning effectively.	Pad is saturated, dirty, or incorrect pad type used for the mess.	Replace with a clean pad. For tough messes, use the scrubbing strip pads. Ensure your steam mop is producing sufficient steam.
Pad leaves streaks on the floor.	Pad is too dirty, or detergent residue is present.	Wash the pad thoroughly without fabric softener. Ensure the floor is free of loose debris before steam mopping.

6. SPECIFICATIONS

- **Product Name:** FFsign Replacement Steam Mop Pads
- **Model Number (Pads):** 1940-6
- **Material:** Ultra-fine fiber (70% polyester & 30% polyamide microfiber)
- **Package Contents:** 3 Soft Microfiber Mop Pads, 3 Microfiber Mop Pads with Scrubbing Strips (6 total)
- **Compatibility:** Bissell PowerFresh Steam Mop 1940, 1440, 1544, 1806, 2075, 2685A, 2814 Series
- **Care Instructions:** Machine washable, hand washable, air dry or tumble dry low. Do not bleach or use fabric softener.
- **Dimensions (Package):** 9.29 x 7.6 x 3.86 inches
- **Item Weight:** 12.7 ounces

7. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your FFsign Replacement Steam Mop Pads, please contact the seller directly through the platform where the purchase was made. Please retain your proof of purchase for any warranty claims or support inquiries.

For information regarding your Bissell PowerFresh Steam Mop, please refer to the original manufacturer's documentation or contact Bissell customer support.