

[Manuals.plus](#) /

› [UpStart Components](#) /

› Instruction Manual: 240363701 Refrigerator Door Shelf Bin Replacement for Frigidaire FFHS2313LS0 Refrigerator

UpStart Components AP-240363701-DL416

Instruction Manual: Refrigerator Door Shelf Bin Replacement

Brand: UpStart Components

INTRODUCTION

This manual provides essential information for the installation, use, and maintenance of your UpStart Components Replacement Refrigerator Door Shelf Bin. This product is designed to replace the original 240363701 door shelf bin in compatible Frigidaire FFHS2313LS0 refrigerators, as well as other models compatible with AP2116105 door shelves. Please read these instructions carefully before proceeding with installation or use.

PRODUCT OVERVIEW



UPStart components



Image 1: Front view of the UpStart Components Replacement Refrigerator Door Shelf Bin. This image displays the overall shape and the two mounting tabs on either side, designed for secure installation within the refrigerator door.



Image 2: Top-down perspective of the shelf bin, illustrating its capacity and the smooth, easy-to-clean interior surface. The design ensures efficient storage of various items.




Image 3: Side profile of the replacement bin, emphasizing the durable plastic material and the structural integrity of the design. This view also shows the slight outward curve of the bin.



Image 4: An angled view of the shelf bin, providing a comprehensive look at its dimensions and how it would appear when installed. The white color is consistent with many refrigerator interiors.

SETUP AND INSTALLATION

This replacement door shelf bin is designed for easy, at-home installation. No special tools are typically required.

1. **Preparation:** Ensure your refrigerator is unplugged or the power to the refrigerator circuit is turned off before beginning any installation. This is a safety precaution, although direct electrical contact is unlikely for this part.
2. **Remove Old Bin (if applicable):** If you are replacing an existing damaged bin, carefully lift it upwards and then pull it outwards from the door liner. Note how the old bin was secured.
3. **Inspect Mounting Slots:** Examine the slots or rails on the inside of your refrigerator door where the new bin will be installed. Ensure they are clean and free of debris.
4. **Install New Bin:** Align the mounting tabs on the back of the new UpStart Components shelf bin with the corresponding slots or rails on the refrigerator door. Gently push the bin downwards until it clicks securely into place. You may need to apply slight pressure to ensure it is fully seated.
5. **Verify Stability:** Once installed, gently tug on the bin to ensure it is firmly attached and does not wobble.
6. **Restore Power:** Plug your refrigerator back in or restore power to the circuit.

Important: Before purchasing and installing, please verify that your original part number matches 240363701, AP2116105, 240363707, 891286, or PS430206 to ensure compatibility.

OPERATING INSTRUCTIONS

The refrigerator door shelf bin is designed for convenient storage of various items within your refrigerator door. To use:

- **Placement:** Place items such as bottles, jars, condiments, or smaller containers into the bin.
- **Weight Limit:** Avoid overloading the bin. While made from durable plastic, excessive weight can cause stress or damage over time. Distribute weight evenly.
- **Temperature:** Ensure items placed in the bin are suitable for refrigerator temperatures.

MAINTENANCE AND CARE

Regular cleaning will help maintain the appearance and hygiene of your door shelf bin.

- **Cleaning:** The bin can be easily removed for cleaning. Wash with warm, soapy water using a soft cloth or sponge.
- **Rinsing:** Rinse thoroughly with clean water to remove all soap residue.
- **Drying:** Allow the bin to air dry completely or wipe it dry with a clean cloth before reinstalling it in the refrigerator door.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, scouring pads, or harsh chemical solvents, as these can damage the plastic surface.

TROUBLESHOOTING

If you encounter issues with your replacement door shelf bin, consider the following:

- **Bin Does Not Fit:**
 - Double-check the part numbers: Ensure your original bin's part number (or your refrigerator model's compatible part number) matches those listed for this replacement (240363701, AP2116105, 240363707, 891286, PS430206).
 - Verify installation: Ensure the bin is aligned correctly with the door slots and pushed down firmly until it locks into place.
- **Bin Feels Loose:**
 - Re-seat the bin: Remove the bin and re-install it, ensuring the tabs are fully engaged in the door slots.
 - Inspect door slots: Check for any damage or debris in the door slots that might prevent a secure fit.

- **Cracks or Damage:**
 - While made from durable material, excessive force or overloading can cause damage. If the bin is cracked, it may need replacement.

SPECIFICATIONS

Manufacturer	UpStart Components
Part Number	AP-240363701-DL416
Compatible Part Numbers	240363701, AP2116105, 240363707, 891286, PS430206
Material	Plastic
Number of Pieces	1
ASIN	B088G22D7R
Date First Available	May 12 2020

WARRANTY INFORMATION

This product is an UpStart Components Brand replacement part. It is not an OEM (Original Equipment Manufacturer) product. Any warranties for this product are offered solely by UpStart Components. Please refer to the UpStart Components official website or contact their customer support for specific warranty terms and conditions.

CUSTOMER SUPPORT

For further assistance, questions, or support regarding your UpStart Components Replacement Refrigerator Door Shelf Bin, please contact UpStart Components directly. Refer to the packaging or the retailer's website for the most current contact information. When contacting support, please have your product model number (AP-240363701-DL416) and the ASIN (B088G22D7R) ready for quicker service.



© 2024 UpStart Components. All rights reserved.

All brand names and logos are registered trademarks of their respective owners. This product is not affiliated with any brands and is not covered under any warranties offered by the original manufacturers.