

[Manuals.plus](#) /

› [Bellemave](#) /

› Bellemave Twin Size Low House Bunk Bed Instruction Manual

Bellemave House Bunk Bed Twin Size

Bellemave Twin Size Low House Bunk Bed

INSTRUCTION MANUAL

Introduction

Thank you for purchasing the Bellemave Twin Size Low House Bunk Bed. This manual provides detailed instructions for the safe assembly, proper use, and maintenance of your new bunk bed. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Safety Information

Your safety and the safety of your children are paramount. Please adhere to the following safety guidelines:

- **Maximum Weight Capacity:** The upper bed has a weight capacity of 175 lbs. The bottom bed has a weight capacity of 275 lbs. Do not exceed these limits.
- **Mattress Thickness:** For the upper bed, the recommended mattress thickness is 6 inches. For the bottom bed, the recommended mattress thickness is 8 inches. Ensure the mattress on the upper bunk is below the top of the guardrails.
- **Guardrails:** Always use the guardrails on the upper bunk to prevent falls.
- **Ladder Safety:** Use the ladder for entering and exiting the upper bunk. Do not use the bed as a climbing frame.
- **Assembly:** Ensure all parts are securely fastened before use. Regularly check and tighten all bolts and screws.
- **Children's Safety:** Bunk beds are not recommended for children under 6 years of age on the upper bunk.
- **Ventilation:** The semi-enclosed design provides a comforting atmosphere while maintaining air circulation.

Package Contents

This product is shipped in two separate boxes. Please ensure you have received both packages before beginning assembly. Carefully unpack all components and check against the parts list (not provided in this general manual, refer to your specific product packaging for a detailed list). If any parts are missing or damaged, contact customer support immediately.

Expected Components:

- Bed frame components (headboards, footboards, side rails)
- Roof and wall section panels
- Ladder
- Plywood slats for both upper and lower beds
- Hardware pack (screws, bolts, nuts, Allen wrench)

Setup and Assembly

Assembly requires two adults. Clear a spacious area for assembly. Do not use power tools for assembly as they may overtighten and damage the wood.

Tools Required (Not Included):

- Phillips Head Screwdriver
- Rubber Mallet (optional, for gentle tapping)

Assembly Steps:

1. **Step 1: Assemble the Lower Bed Frame.** Connect the headboard and footboard of the lower bed to the side rails using the provided hardware. Ensure all connections are snug but do not fully tighten yet.
2. **Step 2: Assemble the Upper Bed Frame.** Repeat the process for the upper bed frame, connecting its headboard, footboard, and side rails.
3. **Step 3: Attach Guardrails.** Secure the full-length guardrails to the upper bed frame as indicated in your specific assembly diagram.
4. **Step 4: Install Ladder.** Attach the ladder securely to the designated side of the bunk bed frame.
5. **Step 5: Position Upper Bed.** Carefully lift and place the assembled upper bed frame onto the lower bed frame, aligning the support posts. Secure with the provided connecting hardware.
6. **Step 6: Install Slats.** Place the plywood support slats across the bed frames for both the upper and lower bunks. Secure them with screws as directed. These slats eliminate the need for a box spring.
7. **Step 7: Assemble House Structure.** Attach the pitched roof and wall section with the window to the upper frame, following the specific instructions for alignment and fastening.
8. **Step 8: Final Tightening.** Once all components are in place and aligned, systematically tighten all screws and bolts. Do not overtighten.

SIZE INCH




Image: Overall dimensions of the Bellemave Twin Size Low House Bunk Bed. The bed measures 77.8 inches in length, 41 inches in width, and 83.1 inches in height. Key measurements for the house structure, ladder, and bed heights are also shown.



Image: An angled view of the assembled Bellemave House Bunk Bed, showcasing the pitched roof, windowed wall section, and the sturdy wooden frame with slats.



Image: A front view of the Bellemave House Bunk Bed, highlighting the low profile design, the integrated ladder, and the guardrails on the upper bunk.



Image: A close-up view of the integrated ladder, showing its sturdy construction and how it provides access to the upper bunk.



Image: A detailed view of the pitched roof section of the bunk bed, illustrating its design and how it integrates with the overall house structure.

Operating and Usage

Once assembled, the Bellemave Twin Size Low House Bunk Bed is ready for use. Follow these guidelines for safe operation:

- **Mattress Placement:** Place the appropriate size and thickness mattresses on both the upper and lower bunks. Ensure the upper mattress does not exceed the guardrail height.
- **Supervision:** Always supervise young children using the bunk bed, especially the upper bunk.
- **No Horseplay:** Prohibit jumping on the bed or engaging in rough play on or around the bunk bed.
- **Clearance:** Ensure there is adequate space around the bed for safe movement.

Maintenance

Regular maintenance will prolong the life and safety of your bunk bed:

- **Cleaning:** Wipe down the bed frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Hardware Check:** Periodically (e.g., every 3-6 months) check all bolts, screws, and connections to ensure they are tight. Retighten as necessary.
- **Inspect for Damage:** Regularly inspect the wood for any cracks, splinters, or signs of wear. Address any damage promptly to maintain structural integrity.

Troubleshooting

If you encounter issues with your bunk bed, refer to the following common solutions:

- **Bed feels wobbly:** Ensure all hardware (bolts, screws) are fully tightened. Check that the bed is on a level surface.
- **Squeaking noises:** This often indicates loose hardware. Identify the source of the squeak and tighten the corresponding fasteners.
- **Missing parts:** If parts were missing upon delivery, contact Bellemave customer support with your purchase details and the specific part numbers needed.
- **Difficulty assembling:** Review the assembly steps carefully. Ensure you are using the correct hardware for each step. Do not force parts together.

Specifications

Overall Product Dimension	77.8"L x 41"W x 83.1"H
Number of Packages	2
Overall Product Weight	134.5 LBS
Weight Capacity (Upper Bed)	175 LBS
Weight Capacity (Bottom Bed)	275 LBS
Recommended Mattress Thickness (Upper Bed)	6"
Recommended Mattress Thickness (Bottom Bed)	8"
Material	Plywood + MDF + Pinewood
Box Spring Required	No
Number of Slats (Upper Bed)	8
Number of Slats (Bottom Bed)	8
Assembly Required	Yes
Color	Antique White

Warranty and Support

For warranty information or customer support, please refer to the documentation included with your purchase or contact Bellemave directly through their official website or the retailer where the product was purchased. Please have your model number (B088GX634S) and purchase date available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B088GX634S>

More documents and user manuals: <https://manuals.plus/>