

[Manuals.plus](#) /

› [Frigidaire](#) /

› Frigidaire EFR182 1.6 cu ft Stainless Steel Mini Fridge User Manual

Frigidaire EFR182

Frigidaire EFR182 1.6 cu ft Stainless Steel Mini Fridge User Manual

Model: EFR182

INTRODUCTION

This manual provides essential instructions for the safe and efficient operation, installation, and maintenance of your Frigidaire EFR182 1.6 cu ft Stainless Steel Mini Fridge. Please read this manual thoroughly before using your appliance and retain it for future reference.



Image: Front view of the Frigidaire EFR182 1.6 cu ft Stainless Steel Mini Fridge.

IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons. This appliance is designed for household use only. Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

- Ensure the appliance is properly grounded.
- Do not damage the refrigerant circuit.
- Keep ventilation openings clear of obstruction.
- Unplug the appliance before cleaning or maintenance.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended

by the manufacturer.

SETUP AND INSTALLATION

1. Unpacking

Carefully remove all packaging materials, including foam and adhesive tape. Dispose of packaging responsibly. Ensure all components are present and undamaged. Allow the refrigerator to stand upright for at least 2-4 hours before connecting it to power to allow refrigerant fluids to settle.

2. Placement

Place the refrigerator on a firm, level surface away from direct sunlight and heat sources (e.g., stoves, heaters). Ensure adequate air circulation around the unit. The flat-back design allows for space-saving placement. Use the adjustable leveling legs to ensure the unit is stable and level.




Image: Illustrates key features including adjustable leveling legs and reversible door. Text description: This image highlights the refrigerator's quiet operation, adjustable leveling legs for stability, a removable shelf for flexible storage, and a reversible door for adaptable

placement.

3. Reversible Door Installation

The door of your refrigerator can be reversed to open from either the left or right side, depending on your preference and space requirements. Refer to the detailed diagrams in the full product manual for specific steps on how to reverse the door. This process typically involves removing hinges and reinstalling them on the opposite side.



Space Saving Design

Enjoy versatile placement options with a reversible door and flush back design.



Image: Shows the interior of the refrigerator with beverages, emphasizing the space-saving design and reversible door. Text description: This image demonstrates the interior storage capacity and highlights the space-saving design, including the reversible door and flush back, which allow for versatile placement options.

4. Power Connection

Connect the refrigerator to a dedicated, grounded 120 Volt AC outlet. Do not use extension cords or adapter plugs. Ensure the power cord is not pinched or damaged.

OPERATING INSTRUCTIONS

1. Temperature Adjustment

The refrigerator features a mechanical temperature adjustment dial located inside the unit. Turn the dial to select your desired cooling level. The temperature ranges from approximately -2°C to 2°C (32°F to 35.6°F). A higher number on the dial typically indicates a colder setting. Allow several hours for the temperature to stabilize after adjustment.

Efficient Organization

This small fridge provides organized storage for your drinks and snacks



Image: Interior view of the refrigerator showing the adjustable temperature dial, freezer compartment, movable shelving, and a 2L door basket. Text description: This image illustrates the efficient organization within the refrigerator, highlighting the adjustable temperature control, the dedicated freezer compartment, flexible movable shelving, and a convenient 2-liter door basket for larger items.

2. Storage and Organization

The 1.6 cu ft capacity provides ample space for beverages and snacks. Utilize the large storage areas and the slide-out shelf to keep items organized. The ice cube chamber freezer is suitable for making ice cubes or storing small frozen items. The integrated tall bottle holder in the door can accommodate larger bottles.

Compact Yet Spacious

1.6 CU. FT. STORAGE CAPACITY




Image: Front view of the Frigidaire EFR182, emphasizing its compact size and 1.6 cu ft storage capacity. Text description: This image showcases the Frigidaire EFR182 mini fridge, highlighting its compact design while emphasizing its spacious 1.6 cubic feet storage capacity, suitable for various items.

CARE AND MAINTENANCE

1. Cleaning

Before cleaning, always unplug the refrigerator from the power outlet. Clean the interior and exterior surfaces with a soft cloth and a mild detergent solution. Avoid abrasive cleaners or harsh chemicals. For the interior, a solution of warm water and baking soda is recommended. Regularly clean the door gasket to ensure a proper seal.

2. Defrosting

This refrigerator features an automatic defrost system for the main compartment. However, the ice cube chamber freezer may require manual defrosting if ice buildup becomes excessive. To defrost the freezer compartment, unplug the unit, remove all contents, and allow the ice to melt naturally. Do not use sharp objects to remove ice.


TROUBLESHOOTING GUIDE

Before contacting customer service, please review the following common issues and solutions:

Problem	Possible Cause	Solution
Refrigerator does not operate.	Not plugged in; circuit breaker tripped; temperature control set to "OFF".	Ensure plug is secure; reset circuit breaker; adjust temperature control.
Temperature is not cold enough.	Door opened too frequently; warm food placed inside; poor air circulation; temperature control set too high.	Minimize door openings; allow hot food to cool before storing; ensure proper clearance around unit; adjust temperature control to a colder setting.
Unusual noises.	Unit not level; objects vibrating against the unit; normal compressor operation.	Adjust leveling legs; ensure nothing is touching the unit; some operational sounds are normal.
Door does not close properly.	Unit not level; gasket dirty or damaged; items obstructing closure.	Adjust leveling legs; clean or replace gasket; rearrange contents.

PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	EFR182
Brand	Frigidaire
Capacity	1.6 cu ft (1.8 Cubic Feet listed in some specifications)
Color	Stainless Steel
Product Dimensions (D x W x H)	18.5" x 20" x 18.5" (47 cm x 50.8 cm x 47 cm)
Item Weight	28 Pounds (12.7 kg)
Voltage	120 Volts
Number of Doors	1
Configuration	Compact Internal Freezer
Defrost System	Automatic (main compartment)
Refrigerant Type	R600a
Special Features	Adjustable leveling legs, Flat-back design, Half-width ice cube chamber, Reversible door
Manufacturer	Curtis International Ltd.



Frigidaire is a pending or registered trademark of Electrolux Home Products and used under license from Electrolux Home Products, Inc.

Image: Diagram showing the dimensions of the Frigidaire EFR182 mini fridge. Text description: This diagram provides the precise measurements of the Frigidaire EFR182 mini fridge, indicating a height of 19.8 inches, a depth of 16.73 inches, and a width of 17.83 inches.

WARRANTY AND CUSTOMER SUPPORT

This Frigidaire EFR182 Mini Fridge comes with a full 1-year warranty from the date of purchase. This warranty covers manufacturing defects and workmanship under normal household use. For warranty claims or technical support, please contact the manufacturer, Curtis International Ltd., or your retailer. Please retain your proof of purchase for warranty service.

For further assistance, you may visit the official Frigidaire website or contact their customer service department. Contact information can typically be found on the manufacturer's website or in the packaging materials.

© 2023 Frigidaire. All rights reserved. Frigidaire is a pending or registered trademark of Electrolux Home Products and used under license from Electrolux Home Products, Inc.