

[manuals.plus](#) /› [GEN](#) /› [User Manual for GEN KXTGFA61B KX-TGFA61 Link2Cell Additional Expansion Handset](#)

GEN KXTGFA61B

User Manual

GEN KXTGFA61B KX-TGFA61 Link2Cell Additional Expansion Handset

1. INTRODUCTION

This manual provides essential information for the proper use and maintenance of your GEN KXTGFA61B KX-TGFA61 Link2Cell Additional Expansion Handset. Please read this manual thoroughly before using the handset to ensure safe and optimal performance. This handset is designed to expand an existing compatible Link2Cell phone system, such as the KX-TGF670 or KX-TG885 series.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package. If any items are missing or damaged, please contact your seller.

- 1 x KXTGFA61B Handset
- 1 x Charging Cradle
- 1 x AC Power Adapter for Charging Cradle
- 2 x AAA Rechargeable Batteries



This image displays all components included with your KXTGFA61B expansion handset: the cordless handset, its charging cradle, the AC power adapter for the cradle, and two AAA rechargeable batteries.

3. SETUP

3.1 Battery Installation

1. Locate the battery compartment cover on the back of the handset.
2. Slide the cover downwards and remove it.
3. Insert the two AAA rechargeable batteries, observing the correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover by sliding it upwards until it clicks into place.



The back of the KXTGFA61B handset, as it sits in the cradle, reveals the design of the battery compartment cover and the overall ergonomic shape of the device.

3.2 Connecting the Charging Cradle

1. Connect the AC power adapter to the DC IN jack on the back of the charging cradle.
2. Plug the AC power adapter into a standard electrical outlet.
3. Place the handset in the charging cradle. Ensure the charge indicator on the handset illuminates, confirming proper connection.



This side view illustrates the slim design of the KXTGFA61B handset while docked in its charging cradle. The connected AC power adapter is also visible, indicating the charging setup.

3.3 Initial Charging

For optimal battery performance, charge the handset for at least 7 hours before initial use. The charge indicator on the handset will typically turn off or change color once fully charged.

3.4 Registering the Handset

This expansion handset must be registered to your existing compatible Link2Cell base unit (e.g., KX-TGF670, KX-TG885) before it can be used. Refer to your main base unit's user manual for specific registration instructions. Generally, the process involves:

1. Placing the handset in the base unit's charging cradle.
2. Pressing and holding the LOCATOR/INTERCOM button on the base unit for a few seconds until a registration tone sounds.
3. Pressing the OK or MENU button on the handset, then following the on-screen prompts to complete registration.

4. OPERATING THE HANDSET



The KXTGFA61B cordless handset rests in its charging cradle. The handset features a digital display, a full numeric keypad, and dedicated buttons for Talk, Off, Volume, Redial, CID, Speakerphone, Call Block, and Flash.



A detailed view of the handset's keypad, highlighting the large, easy-to-read numbers and key function buttons such as 'TALK', 'OFF', 'VOL', 'REDIAL', 'CID', 'SP-PHONE', 'CALL BLOCK', and 'FLASH'.

4.1 Making a Call

1. Press the **TALK** button.
2. Dial the phone number using the numeric keypad.
3. To end the call, press the **OFF** button or place the handset back in the charging cradle.

4.2 Answering a Call

When the phone rings, press the **TALK** button to answer the call.

4.3 Adjusting Volume

During a call, press the **VOL. (Volume)** up or down arrow buttons to adjust the earpiece volume.

4.4 Using Speakerphone

During a call, press the **SP-PHONE** button to switch to speakerphone mode. Press it again to switch back to the earpiece.

4.5 Caller ID

When a call comes in, the caller's information (name and number, if available) will be displayed on the handset screen. Press the **CID (Caller ID)** button to review recent calls.

4.6 Call Block

Press the **CALL BLOCK** button to block unwanted numbers. Refer to your main base unit's manual for detailed instructions on setting up and managing the call block list.

4.7 Redial

Press the **REDIAL** button to view a list of recently dialed numbers. Press **TALK** to call a selected number from the list.

5. MAINTENANCE

5.1 Cleaning

Wipe the handset and charging cradle with a soft, damp cloth. Do not use abrasive cleaners, waxes, or solvents. Avoid spraying cleaning liquids directly onto the unit.

5.2 Battery Care

- Always use the provided rechargeable AAA batteries.
- If the handset will not be used for an extended period, remove the batteries to prevent leakage.
- Battery life may vary and is not guaranteed. Replace batteries when performance degrades significantly.

5.3 Storage

Store the handset and cradle in a cool, dry place away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

If you experience issues with your handset, try the following troubleshooting steps. For more complex issues, refer to the user manual of your main base unit.

Problem	Solution
---------	----------

Problem	Solution
Handset does not turn on or has no dial tone.	Ensure batteries are correctly installed and charged. Verify the charging cradle is properly connected to power. Confirm the handset is registered to the base unit.
Cannot make or receive calls.	Check if the handset is within range of the base unit. Ensure the main phone line is connected to the base unit. Verify the handset is registered.
Poor sound quality.	Move closer to the base unit. Check for interference from other electronic devices.

7. SPECIFICATIONS

- **Model:** KXTGFA61B / KX-TGFA61
- **Brand:** GEN
- **Color:** Black
- **Power Source:** Battery Powered, Corded Electric (for cradle)
- **Dialer Type:** Single Keypad
- **Answering System Type:** Digital (functionality depends on base unit)
- **Caller Identification:** Yes (requires subscription to Caller ID service)
- **Item Weight:** Approximately 8.7 ounces (247 grams)
- **Package Dimensions:** Approximately 8.11 x 4.96 x 1.5 inches (20.6 x 12.6 x 3.8 cm)

8. WARRANTY AND SUPPORT

For information regarding warranty coverage, technical support, or service, please refer to the documentation provided with your original phone system or contact the manufacturer/seller directly. Keep your purchase receipt as proof of purchase for warranty claims.