

[Manuals.plus](#) /

› [Lomiluskr](#) /

› Lomiluskr K680T Wireless 60% Mechanical Keyboard User Manual

Lomiluskr K680T

Lomiluskr K680T Wireless 60% Mechanical Keyboard User Manual

Model: K680T

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Lomiluskr K680T Wireless 60% Mechanical Keyboard. Please read this guide thoroughly before using the product to ensure optimal performance and longevity.



N-Key Rollover

全キー無衝突



Wired/Bluetooth

有線/bluetooth



White Backlit

あっさりした白い光



Compact 68 Keys

シンプル68ボタン



Double-Shot
Injection Keycap

二色射出成形

Image: The Lomilusr K680T keyboard in a typical desktop setup, showcasing its compact design.

2. PRODUCT FEATURES

- **68-Key Compact Layout:** A 60% layout mechanical keyboard that minimizes size (13.4×4.25×1.4 inches) while retaining essential keys for gaming and Mac compatibility. This design saves desktop space, providing more room for mouse movement.
- **Bluetooth Wireless/Wired Dual Mode:** Offers flexibility with both Bluetooth 3.0 and wired (Type-C) connectivity. Bluetooth mode provides a stable transmission distance of up to 10 meters and can connect to three devices simultaneously. The wired mode also charges the keyboard.
- **1000mAh Built-in Battery:** Equipped with a large capacity battery for extended use. Provides approximately 10 hours of use with backlight on, 60 hours with backlight off, and 360 hours of standby time. Fast charging takes about 3 hours.
- **18 Backlight Effects:** Features a white backlight with 18 different effects (flashing, static, breathing, etc.). Brightness and speed can be adjusted using FN+arrow keys.
- **Professional Mechanical Switches:** Utilizes custom chips for fast and lossless response. The 68 keys feature real

mechanical switches (Black Switch variant) designed for a balanced typing and gaming experience, with a durability of over 50 million clicks.



Image: A detailed view of the Black Mechanical Switch, highlighting its construction.

3. PACKAGE CONTENTS

Please check the package for the following items:

- Lomiluskr K680T Mechanical Keyboard
- Type-C USB Cable
- User Manual



Image: The Lomilusr K680T keyboard, Type-C cable, and user manual as found in the product packaging.

4. SPECIFICATIONS

Feature	Detail
Brand	Lomilusr
Model Number	K680T
Connectivity Technology	Bluetooth & Wired (Type-C)
Compatible Devices	Mac, PC, Laptop, Tablet, Smartphone, PS
Keyboard Layout	QWERTY, 68 Keys (60% Layout)
Keyboard Backlighting	White Backlight, 18 Effects
Switches	Mechanical (Black Switch)
Battery Capacity	1000mAh
Product Dimensions	13.4"L x 4.25"W x 1.4"H
Item Weight	810 Grams

5. SETUP

Initial Charging

Before first use, it is recommended to fully charge the keyboard. Connect the provided Type-C USB cable to the keyboard's port and the other end to a USB power source (e.g., computer, wall adapter). The keyboard will charge automatically in wired mode.

Switching Between Modes

The keyboard supports both wired and Bluetooth modes. A switch on the bottom of the keyboard allows you to select the desired mode. Slide the switch to the USB icon for wired mode or the Bluetooth icon for wireless mode.

Bluetooth/Wired Dual-Mode Bluetooth/有線 両対応

Bluetooth connection and USB wired connection, dual-mode connection supports multi-devices, easier to switch.

キーボードはBluetooth接続とUSBケーブル接続をサポートしています。デュアルモード接続方式は様々な設備の使用をサポートしています。設備のシームレスな切り替えに便利です。

Bluetooth Mode/bluetoothモード

Wireless Bluetooth 3.0 stable transmission,
10 m effective transmission distance

有効距離10 m、線材の束縛を抜け出して、
仕事が便利であります。



USB Wired Mode/有線モード

Type-C interface, usb while charging,
Transmission is more stable

USBケーブルは分離でき、伝送は安定的
で効率的で、ゲームをより快適にします。



Image: The bottom of the K680T keyboard, indicating the switch for selecting between Bluetooth and wired modes.

6. OPERATING INSTRUCTIONS

Bluetooth Connection Method

The K680T keyboard can connect to up to three Bluetooth devices simultaneously. Follow these steps to pair your device:

1. **Step 1: Select a Device Slot.** Turn the dial on the bottom of the keyboard to the "BT" position. Press and hold **FN + Q** (for Device 1, indicator light red), **FN + W** (for Device 2, indicator light green), or **FN + E** (for Device 3, indicator light blue) to assign the current connection to one of the three memory slots.
2. **Step 2: Initiate Pairing.** After selecting a slot, press and hold **FN + P** for 2 seconds. The indicator light will flash, signifying that the keyboard is in pairing mode.
3. **Step 3: Search on Your Device.** On your computer, tablet, or smartphone, enable Bluetooth and search for available devices.
4. **Step 4: Connect.** Select "AJazz K680T Keyboard" from the list of found devices to complete the connection.

Bluetooth Connection Method Bluetooth接続方法

Dial the bottom button to the "BT" position
下のボタンを「BT」の位置にダイヤルします



Step1



Switch to this device,
the indicator light is red
設備を切り替え
対応ランプが赤色に点灯します



Switch to this device,
the indicator light is green
設備を切り替え
対応ランプがグリーンに点灯します



Switch to this device,
the indicator light is blue
設備を切り替え
対応ランプがブルーに点灯します

Step2

Press Fn and one of Q/W/E as the storage key and then release the key.
(This product can memorize 3 devices, stored in Q/W/E buttons)

Fn+Q/W/Eのいずれかを保存キーとして押してからキーを離します。

(この製品は3つの端末装置を記憶して、それぞれQ/W/Eの3つのキーに保存します。)

Step3

Press the FN+P button for 2 seconds, release it to enter the pairing state after the indicator flashes.

FN+Pキー2sを長押しし、指示灯が点滅してから離して接続状態にします。

Step4

Turn on the device's Bluetooth function and search.

設備のbluetooth機能を開いて検索し。

Step5

Find the device named "AJAZZ K680T Keyboard" and click Connect to complete the connection.

「AJAZZ K680T Keyboard」という機器が接続をクリックすると接続が完了します。

Image: Visual guide for connecting the K680T keyboard via Bluetooth, detailing key combinations and indicator lights.

Switching Between Paired Devices

To switch between previously paired Bluetooth devices, simply press **FN + Q**, **FN + W**, or **FN + E** corresponding to the device slot you wish to use. No re-pairing is required.

Up to 3 devices, Easy to Switch 3台の機器に対応し、ワンタッチで切り替える

Compatible with a variety of devices, can store three Bluetooth device connections, use Fn+QWE directly to switch to the corresponding device when you use it again, no need to connect again.

複数の機器に対応しており、3つのbluetooth機器接続が格納されている。
再利用はFn+Q/W/Eを直接使用して対応機器に切り替えることで利用可能であり、再接続操作は不要であります。



Image: The K680T keyboard demonstrating its ability to connect and switch between up to three different devices.

Wired Connection

For a wired connection, ensure the switch on the bottom of the keyboard is set to the USB icon. Connect the provided Type-C USB cable to the keyboard and your computer. The keyboard will be recognized automatically, and it will also charge the internal battery.

Backlight Control

The keyboard features a white backlight with various effects. Use the following key combinations to control the backlight:

- Press **FN + Right Arrow** (→) or **FN + Left Arrow** (←) to cycle through the 18 different backlight effects.
- Press **FN + Up Arrow** (↑) to increase backlight brightness.
- Press **FN + Down Arrow** (↓) to decrease backlight brightness.

Your browser does not support the video tag.

Video: An overview of the Lomilusk K680T keyboard, demonstrating its compact design, wired/wireless capabilities, and backlight features.

7. MAINTENANCE

Cleaning

To clean your keyboard, disconnect it from all power sources. Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution. Avoid spraying liquids directly onto the keyboard. For keycaps, they can be carefully removed for deeper cleaning if necessary. Use compressed air to remove dust and debris from between the keys.

Battery Care

To prolong battery life, avoid fully discharging the keyboard frequently. If storing the keyboard for an extended period, charge it to about 50% and store it in a cool, dry place. Recharge every few months to prevent deep discharge.

8. TROUBLESHOOTING

- **Keyboard not responding in wired mode:** Ensure the Type-C cable is securely connected to both the keyboard and your computer. Check if the mode switch on the bottom of the keyboard is set to the USB icon. Try a different USB port or cable.
- **Keyboard not connecting via Bluetooth:**
 - a. Ensure the keyboard is charged.
 - b. Verify the mode switch on the bottom of the keyboard is set to the Bluetooth icon.
 - c. Confirm you are pressing **FN + P** for 2 seconds to enter pairing mode (indicator light flashing).
 - d. Check your device's Bluetooth settings to ensure Bluetooth is enabled and it is searching for new devices.
 - e. If previously paired, try deleting the keyboard from your device's Bluetooth list and re-pairing.
 - f. Ensure no other devices are interfering with the Bluetooth signal.
- **Keys not registering or registering multiple times:** This can sometimes occur with low battery. Charge the keyboard fully. If the issue persists, try connecting in wired mode to see if the problem is resolved.
- **Backlight not working:** Ensure the keyboard is charged. Adjust brightness using **FN + Up Arrow** (↑). Cycle through effects using **FN + Right Arrow** (→) or **FN + Left Arrow** (←).

9. WARRANTY AND SUPPORT

Lomilusk products are designed for reliability and performance. For warranty information, technical support, or service inquiries, please refer to the contact information provided on the product packaging or the official Lomilusk website. Keep your purchase receipt as proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question