

[Manuals.plus](#) /

› [Accutime](#) /

› Accutime U.S. Polo Assn. Men's Quartz Watch (Model: USC40436AZ) Instruction Manual

Accutime USC40436AZ

Accutime U.S. Polo Assn. Men's Quartz Watch

MODEL: USC40436AZ

Introduction

Thank you for choosing the Accutime U.S. Polo Assn. Men's Quartz Watch. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your new timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

Product Overview

The U.S. Polo Assn. Men's Quartz Watch features a classic analog display with a durable alloy case and a metal link strap. It is designed for everyday wear and includes water resistance for added durability.





Front view of the Accutime U.S. Polo Assn. Men's Quartz Watch, showcasing its black dial with Roman numerals and the U.S. Polo Assn. logo, along with a silver-tone metal link strap.

Setup

1. Setting the Time

1. **Pull out the crown:** Locate the crown on the right side of the watch case. Gently pull it out to the first or second position (depending on the model, typically the outermost position for time setting).
2. **Adjust the hands:** Turn the crown clockwise or counter-clockwise to move the hour and minute hands to the correct time.
3. **Push in the crown:** Once the time is set, push the crown back into its original position against the watch case. This will start the watch movement.



Side view of the watch, illustrating the position of the crown and any additional pushers for setting or operating functions.

2. Adjusting the Strap

The watch features an adjustable metal link strap with a jewelry clasp closure. If the strap is too loose or too tight, it may require professional adjustment by removing or adding links. It is recommended to visit a qualified jeweler for this service to avoid damaging the strap or clasp.

3. Battery Information

Your watch is powered by a product-specific battery, which is included and pre-installed. When the battery needs replacement, it is recommended to have it replaced by a professional watch repair service to ensure the watch's water resistance is maintained.

4. Water Resistance

This watch is water resistant up to 100 meters. This means it is suitable for showering, swimming, and snorkeling. However, it is **not** suitable for diving. Avoid operating the crown or pushers while the watch is wet or submerged to

prevent water intrusion.

Operating the Watch

The Accutime U.S. Polo Assn. watch is an analog quartz timepiece. Its primary function is to display the current time (hours, minutes, and seconds) through its hands on the dial. No complex operations are typically required beyond setting the time.



The watch displayed on a wrist, demonstrating its fit and appearance during wear.

Maintenance

1. Cleaning

To clean your watch, wipe the case and strap with a soft, dry cloth. For more thorough cleaning, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish.

2. Water Resistance Care

While your watch is water resistant, it is advisable to rinse it with fresh water after exposure to saltwater or chlorinated water. Ensure the crown is fully pushed in before any contact with water. Avoid exposing the watch to extreme temperature changes, such as moving from a hot sauna to cold water, as this can compromise the seals.

3. Storage

When not wearing your watch, store it in a cool, dry place, away from direct sunlight and extreme temperatures. The original watch box can be used for safe storage.



The watch's packaging box, suitable for storage when the watch is not in use.

Troubleshooting

- **Watch not running:** Check if the crown is fully pushed in. If it is, the battery may need replacement.
- **Time is incorrect:** Re-set the time as described in the "Setting the Time" section. If the time consistently loses or gains significantly, the watch may require servicing.
- **Condensation under the crystal:** This indicates a potential breach in water resistance. Immediately take the watch to a professional for inspection and repair to prevent further damage to the movement.

Specifications

Feature	Detail
Model Number	USC40436AZ
Brand	Accutime (U.S. Polo Assn.)
Movement Type	Quartz
Display Type	Analog

Case Material	Alloy
Band Material	Metal
Band Color	Black
Dial Color	Black
Case Diameter	41 Millimeters
Band Width	16 Millimeters
Case Thickness	19 Millimeters
Crystal Type	Glass
Water Resistance Depth	100 Meters
Power Source	Battery Powered (1 Product Specific battery included)
Clasp Type	Buckle
Item Weight	0.29 Kilograms (10.41 ounces)

Warranty Information

This Accutime U.S. Polo Assn. watch is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration of coverage. Keep your proof of purchase for any warranty claims.

Customer Support

For further assistance, questions, or service requests regarding your Accutime U.S. Polo Assn. watch, please contact Accutime customer support. You may also refer to the official U.S. Polo Assn. watch website or the retailer where the watch was purchased for additional support resources.

Online Resources:

- Accutime Store on Amazon: [Visit Accutime Store](#)
- Product Page on Amazon: [View Product Details](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question