

[Manuals.plus](#) /

› [MEILAN](#) /

› MEILAN M3 Mini GPS Bike Computer User Manual

MEILAN M3

MEILAN M3 Mini GPS Bike Computer User Manual

INTRODUCTION

The MEILAN M3 Mini GPS Bike Computer is a compact and lightweight device designed to track essential cycling data. Featuring a high-sensitivity GPS chip, it provides accurate measurements for speed, distance, riding time, and altitude. Its wireless design, USB rechargeable battery, and IPX5 waterproof rating make it suitable for various outdoor cycling conditions. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your MEILAN M3 Mini GPS Bike Computer.



LCD Display



Built-in GPS Chip



IPX5 Waterproof



400mAh Battery



USB Rechargeable



Image: MEILAN M3 Mini GPS Bike Computer in use by a cyclist.

PRODUCT OVERVIEW

The MEILAN M3 Mini GPS Bike Computer integrates advanced technology to enhance your cycling experience:

- **High-Sensitivity GPS Chip:** Equipped with a built-in GPS chip supporting Beidou, GPS, and GLONASS systems for rapid and precise global positioning.
- **Multi-Functional Display:** Tracks and displays current speed, average speed, maximum speed, riding distance, total mileage, riding time, total riding time, and current altitude.
- **Day & Night Backlight:** A 1.7-inch anti-glare LCD screen with adjustable backlight ensures clear visibility in all lighting conditions.
- **Wireless and Rechargeable:** Eliminates the need for wires, offering easy installation. The integrated 400mAh lithium battery provides up to 8 hours of operation and is conveniently rechargeable via USB.
- **Durable Design:** IPX5 waterproof rating protects the device from splashes and rain, making it reliable for outdoor use.
- **Automatic Sleep Function:** Conserves battery life by entering sleep mode when inactive.



Image: MEILAN M3 Mini GPS Bike Computer features diagram.

WHAT'S IN THE BOX

Your MEILAN M3 Mini GPS Bike Computer package includes the following components:

- MEILAN M3 Mini GPS Bike Computer Unit
- Bike Mount
- Rubber Rings (for mounting)
- USB Charging Cable
- User Manual (this document)



Image: Included components of the MEILAN M3 Mini GPS Bike Computer.

SETUP

1. Mounting the Device:

Attach the bike mount to your bicycle's handlebar or stem using the provided rubber rings. Ensure the mount is secure and positioned for optimal viewing. Align the MEILAN M3 Mini GPS Bike Computer with the mount and twist it into place until it clicks securely.



Image: Installation diagram for the MEILAN M3 Mini GPS Bike Computer showing mounting on stem and handlebar.

2. Initial Power On and GPS Acquisition:

Press the power button to turn on the device. Before first use, ensure you are in an open outdoor area to facilitate quick GPS signal acquisition. The device will automatically calibrate the time and date once a stable GPS signal is established. Set your local time zone in the device settings to

ensure accurate time display.



Image: MEILAN M3 Mini GPS Bike Computer acquiring GPS signal.

3. Setting Units (KM/H to MPH):

Refer to the device's on-screen menu or specific button combinations (usually involving holding down certain buttons) to switch between Kilometers per Hour (KM/H) and Miles per Hour (MPH) as desired.

Your browser does not support the video tag.

Video: This video demonstrates the setup process, including how to switch between KM/H and MPH units on the MEILAN M3 Mini GPS Bike Computer.

OPERATING INSTRUCTIONS

- **Power On/Off:** Press and hold the power button to turn the device on or off.
- **Data Display:** The main screen displays current speed prominently. Use the designated buttons (refer to the device interface) to cycle through other data points such as average speed, maximum speed, riding distance, total mileage, riding time, total riding time, and current altitude.




Image: Real-time data display on the MEILAN M3 Mini GPS Bike Computer.

- **Backlight Control:** To adjust the backlight level for day or night riding, simultaneously press the back and right buttons on the device.



Image: Day and Night backlight modes of the MEILAN M3 Mini GPS Bike Computer.

- **Charging:** Connect the device to a USB DC 5V power source using the provided USB charging cable. The 400mAh lithium battery provides approximately 8 hours of continuous use.
- **Automatic Sleep:** The device will automatically enter sleep mode after a period of inactivity to conserve battery. Press any button to wake it up.

Your browser does not support the video tag.

MAINTENANCE

- **Cleaning:** Wipe the device with a soft, damp cloth. Avoid using abrasive cleaners or solvents.
- **Water Resistance:** The device has an IPX5 waterproof rating, meaning it is protected against low-pressure water jets from any direction. It is resistant to rain and splashes but should not be submerged in water.
- **Battery Care:** To prolong battery life, avoid fully discharging the device frequently. Charge it regularly, especially if it will be stored for an extended period.

TROUBLESHOOTING

If you encounter issues with your MEILAN M3 Mini GPS Bike Computer, refer to the following common solutions:

- **No GPS Signal / Slow Acquisition**
 - Ensure you are in an open outdoor area with a clear view of the sky. Obstructions like buildings, dense trees, or indoor environments can interfere with GPS reception.
 - Wait a few minutes for the device to acquire a stable signal.
- **Incorrect Time/Date:**
 - Verify that the correct time zone is set in the device's settings. The time and date will automatically calibrate once a stable GPS signal is acquired.
- **Screen Freezing or Unresponsive:**
 - If the screen freezes or the device becomes unresponsive, perform a soft reset by pressing and holding the power button until the device turns off, then power it back on.
- **Inaccurate Readings:**
 - Ensure the device is securely mounted and has a clear line of sight to the sky for optimal GPS performance.
- **Battery Draining Quickly:**
 - Frequent use of the backlight, especially at higher brightness levels, can reduce battery life. Adjust backlight settings as needed.
 - Ensure the device is fully charged before each ride.
- **Further Assistance:** For more detailed troubleshooting, please refer to the official Troubleshooting Guide (PDF) or contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	MEILAN
Model	M3
Product Dimensions (L x W x H)	1.77" x 0.79" x 2.36"

Item Weight	0.08 Pounds
Screen Size	1.7 Inches
Display Type	LCD
Battery Type	Lithium Ion (400mAh)
Battery Average Life	8 Hours
Connectivity Technology	GPS (Beidou, GPS, GLONASS)
Waterproof Rating	IPX5
Mounting Type	Handlebar/Stem Mount
Human Interface Input	Buttons

WARRANTY AND SUPPORT

- **Warranty:** The MEILAN M3 Mini GPS Bike Computer comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects and ensures product reliability.
- **Customer Support:** For any questions, technical assistance, or warranty claims, please contact MEILAN customer service. Refer to the contact information provided on the official MEILAN website or your purchase documentation.
- **Additional Resources:** A detailed Troubleshooting Guide (PDF) is available for download at <https://manuals.plus/m/8e8f18a2c03669ab28a8591c39f824c8efef3f90c96a4d858f27e8862de12329>.