

CHICOLOGY VBOA7884

CHICOLOGY Vertical Blinds - Oxford Alabaster (Vinyl) 78"W x 84"H

Instruction Manual for Model VBOA7884

PRODUCT OVERVIEW

The CHICOLOGY Vertical Blinds provide a modern and functional solution for wide openings, sliding doors, and patio doors. These cordless blinds offer privacy and light control with durable vinyl slats, designed for ease of use and low maintenance.

- **Material:** 100% PVC Vinyl for durability and easy cleaning.
- **Operation:** Cordless design for a contemporary look and safe operation.
- **Light Control:** Room darkening opacity with adjustable slats for custom light filtering.
- **Dimensions:** 78 inches wide by 84 inches high.



Image: CHICOLOGY Vertical Blinds in Oxford Alabaster installed on a sliding glass door, providing privacy and light control in a living room setting.

SETUP AND INSTALLATION

This section outlines the general steps for installing your CHICOLOGY Vertical Blinds. The blinds support both inside and outside mount configurations.

Tools Required:

- Drill
- Tape Measure
- Phillips Head Screwdriver
- Pencil
- Ladder (if necessary)

Installation Steps:

1. **Measure and Mark:** Carefully measure the desired mounting location. Mark the positions for the mounting brackets, ensuring they are level and evenly spaced. For inside mount, ensure sufficient depth. For outside mount, ensure adequate overlap.
2. **Install Brackets:** Using a drill and appropriate screws, securely attach the mounting brackets to the wall or window frame at the marked positions. Ensure the brackets are firmly fixed to support the weight of the blinds.
3. **Mount Headrail:** Carefully attach the headrail of the vertical blinds to the installed mounting brackets. Ensure it clicks securely into place.
4. **Attach Valance:** If included, attach the decorative valance to the front of the headrail for a finished appearance.
5. **Hang Slats:** Individually hang each vinyl slat onto the carriers within the headrail. Ensure each slat is correctly oriented and fully inserted.





Image: Visual representation of the vertical blind's dimensions and key design features, highlighting its suitability for wide openings and its space-saving stack.



Cordless
Safe for kids and pets



3.5" PVC Slats
Durable and
low maintenance



Valance
Matches the blinds for
a clean, finished look

Image: Detailed view of the cordless mechanism, the durable 3.5-inch PVC slats, and the integrated valance for a clean, finished look.

OPERATING INSTRUCTIONS

The CHICOLOGY Vertical Blinds feature a cordless design for simple and safe operation.

Adjusting Light and Privacy:


- **Rotate Slats:** Use the control wand (if applicable) or gently grasp a slat and rotate it to adjust the angle of the blinds. This allows you to control the amount of light entering the room and your level of privacy.
- **Open/Close Blinds:** To open the blinds and stack the slats, gently push or pull the lead slat in the desired direction (left or right). To close, pull the lead slat back across the opening.

Custom Light Control

Easily rotate the slats to let in just the right amount of light



Image: Comparison showing the vertical blinds with slats open to allow light and with slats closed to achieve a blackout effect, illustrating custom light control.



Easy to Clean

Dust-resistant slats make cleaning quick and simple

Image: Visual guide demonstrating the flexibility of the vertical blinds to stack and open either to the left or to the right side of the window.

MAINTENANCE

Maintaining your CHICOLOGY Vertical Blinds is simple due to their durable PVC vinyl construction.

- **Cleaning:** The blinds are designed for spot cleaning only. Use a soft, damp cloth with mild soap and water to gently wipe down the slats. Avoid harsh chemicals or abrasive cleaners.
- **Dusting:** Regularly dust the slats with a soft cloth or a duster to prevent buildup.
- **Inspection:** Periodically check the headrail and slat carriers for any signs of wear or damage.



Image: A hand demonstrating the ease of cleaning the dust-resistant vinyl slats, emphasizing quick and simple maintenance.

TROUBLESHOOTING

If you encounter any issues with your vertical blinds, please refer to the following common solutions. For problems not listed here, contact customer support.

- **Slats Not Rotating Evenly:** Check if any slats are caught or misaligned in the carrier mechanism. Gently adjust them to ensure free movement.
- **Blinds Not Opening/Closing Smoothly:** Inspect the headrail track for any obstructions or debris. Ensure the lead slat is moving freely along the track.
- **Damaged Slats:** Individual slats can often be replaced. Contact customer support for replacement options.

SPECIFICATIONS

Feature	Detail
---------	--------

Brand	CHICOLOGY
Model Number	VBOA7884
Material	Vinyl (100% PVC)
Color	Oxford Alabaster
Size	78"W x 84"H
Product Dimensions	84"L x 78"W
Opacity	Blackout
Operation Mode	Manual, Cordless
Mounting Type	Inside Mount & Outside Mount
Included Components	Vertical Blind, Wand
Item Weight	14.7 Pounds
UPC	812030038102



Open to Left



Open to Right



Image: Color swatches displaying Oxford White, Oxford Alabaster, and Oxford Gray vinyl options for CHICOLOGY blinds.

WARRANTY INFORMATION

Your CHICOLOGY Vertical Blinds are covered by a **Limited One-Year Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.



CUSTOMER SUPPORT

For further assistance, technical support, or warranty claims, please contact CHICOLOGY customer service:

- **Website:** Visit the official CHICOLOGY website for FAQs and contact options.
- **Email:** Refer to your product packaging or the CHICOLOGY website for direct email support.
- **Phone:** Refer to your product packaging or the CHICOLOGY website for phone support.

When contacting support, please have your model number (VBOA7884) and purchase information readily available.

Related Documents - VBOA7884

	<p>Cordless 1-Inch Vinyl Mini Blind Installation Guide</p> <p>Comprehensive installation guide for Chicology's cordless 1-inch vinyl mini blinds, covering preparation, inside and outside mounting, hardware usage, and warranty details.</p>
	<p>Cordless 1-Inch Vinyl Mini Blind Installation Guide</p> <p>Comprehensive installation guide for Chicology's cordless 1-inch vinyl mini blinds, covering preparation, inside and outside mounting, hardware usage, and warranty details.</p>