

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VIVO](#) /

› [VIVO STAND-TV70B Studio TV Display Stand Instruction Manual](#)

VIVO STAND-TV70B

VIVO STAND-TV70B Studio TV Display Stand Instruction Manual

Model: STAND-TV70B | Brand: VIVO

1. PRODUCT OVERVIEW

The VIVO STAND-TV70B is a V-Base studio TV display stand designed to support 49-inch to 70-inch flat or curved screen televisions weighing up to 88 lbs. This stand features a sleek design, height adjustment, 360-degree swivel capability, and integrated cable management to maintain an organized appearance. It is compatible with various VESA mounting patterns.



Image 1.1: The VIVO STAND-TV70B Studio TV Display Stand in a modern living room environment, showcasing its minimalist design.

Video 1.1: An official VIVO video highlighting the features of the STAND-TV70B V-Base Studio TV Stand, including its design, VESA compatibility, and cable management.

2. SAFETY INFORMATION

- **Weight Capacity:** Do not exceed the maximum weight capacity of 88 lbs (40 kg). This stand is designed for televisions between 49 and 70 inches.
- **VESA Compatibility:** Ensure your TV's VESA mounting pattern is compatible with the stand's supported patterns: 200x200mm, 300x200mm, 300x300mm, 400x200mm, 400x300mm, 400x400mm, or 600x400mm.
- **Stable Placement:** Always place the stand on a flat, stable, and level surface to prevent tipping.
- **Assembly:** Follow all assembly instructions carefully. Improper assembly can lead to product failure or injury. Two people are recommended for TV installation.
- **Cable Management:** Utilize the integrated cable management system to prevent tripping hazards and ensure cables are not pinched or damaged.
- **Anti-Tip Strap:** An anti-tip strap is included for additional safety. Install it as directed to secure the TV and stand.

3. PARTS LIST

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or defective, contact VIVO customer support.

- Main Base (V-shaped leg)
- Vertical Pole (Upper and Lower sections)
- VESA Mounting Brackets (Upper and Lower)
- Foot Pads (for base)
- Cable Management Covers
- Assembly Hardware (screws, washers, Allen wrench)
- Anti-Tip Strap

4. SETUP AND INSTALLATION

Follow these steps carefully for proper assembly and installation of your VIVO STAND-TV70B.

Video 4.1: Official VIVO assembly video for the STAND-TV70B V-Base Studio TV Stand, demonstrating each step of the installation process.

Step 1: Assemble the Base

Slide the two feet sections onto the main V-base and secure them with the provided screws. Screw the foot pads onto the base and feet to protect your floor and prevent slipping.

STABLE FEET

designed to safely support your tv




Image 4.1: The stable V-base feet with rubber pads, designed to prevent sliding and scratching floors. Dimensions are shown as 34.9 inches wide and 25.1 inches deep.

Step 2: Attach the Vertical Pole

Screw the vertical pole sections onto the assembled base. Loosen the set screws on the collar to adjust the pole's height. Once the desired height is achieved, tighten the set screws, ensuring they face towards the back of the stand for a clean look.

Step 3: Prepare VESA Brackets

Remove the screw in the lower VESA bracket. This screw will be used later in Step 5 to secure the TV to the pole.

Step 4: Attach VESA Brackets to TV

Attach the upper and lower VESA mounting brackets to the back of your television using the appropriate screws and spacers from the hardware kit. Ensure the brackets are securely fastened to your TV's VESA holes.

UNIVERSAL VESA COMPATIBILITY



Image 4.2: Universal VESA compatibility diagram, showing supported patterns from 200x200mm to 600x400mm, and a maximum weight capacity of 88 lbs.

Step 5: Mount the TV to the Stand

With assistance, carefully slide the TV (with attached VESA brackets) onto the vertical pole of the stand. The snap-lock design allows for easy and quick TV assembly. Once positioned, secure the TV by re-inserting and tightening the screw removed in Step 3 into the lower VESA bracket and the pole.

QUICK and EASY INSTALLATION

snap lock for easier and quick TV assembly



Image 4.3: Visual guide demonstrating the quick and easy installation process, highlighting the snap-lock feature for TV attachment.

Step 6: Cable Management

Route all necessary cables through the designated cable holes in the vertical pole. Install the cable covers to conceal the wires, ensuring a clean and organized setup.



Image 4.4: Detail of the integrated cable management system, showing how cables are routed and hidden within the stand's pole for a tidy appearance.

5. OPERATING INSTRUCTIONS

Height Adjustment

The TV stand allows for height adjustment along the vertical pole. To adjust the height, loosen the set screws on the collar, carefully raise or lower the TV to the desired position, and then firmly tighten the set screws to secure it.

HEIGHT ADJUSTMENT

elevates screen to an ergonomic height



Image 5.1: The TV stand from a side perspective, demonstrating its height adjustment capability to achieve an ergonomic viewing level.

Swivel Function

The stand features a fluid 360-degree swivel. Gently rotate the television to achieve the optimal viewing angle for your audience. No locking mechanism is required for the swivel function.

6. MAINTENANCE

- **Cleaning:** Wipe the stand with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Hardware Check:** Periodically check all screws and connections to ensure they remain tight and secure. Re-tighten if necessary.
- **Cable Inspection:** Regularly inspect cables for any signs of wear, fraying, or pinching. Replace damaged cables immediately.

7. TROUBLESHOOTING

- **Stand is Unstable:** Ensure the stand is placed on a level surface. Check that all screws in the base and pole connections are fully tightened. Verify the TV weight does not exceed the maximum capacity.

- **TV Not Mounting Correctly:** Confirm your TV's VESA pattern matches the supported range. Ensure the VESA brackets are correctly aligned and attached to the TV.
- **Difficulty Adjusting Height:** Loosen the set screws on the pole collar sufficiently before attempting to adjust the height. Ensure no cables are obstructing the pole's movement.

8. SPECIFICATIONS

Feature	Specification
Model Number	STAND-TV70B
Brand	VIVO
Compatible TV Sizes	49 to 70 inches
Weight Capacity	Up to 88 lbs (40 kg)
VESA Compatibility	200x200mm, 300x200mm, 300x300mm, 400x200mm, 400x300mm, 400x400mm, 600x400mm
Movement Type	Height Adjusting, Swivel (360°)
Mounting Type	Floor Mount
Material	Aluminum, Steel, Plastic
Color	Black
Item Weight	19.45 pounds
Package Dimensions	42.52 x 11.34 x 7.4 inches

9. WARRANTY AND SUPPORT

This VIVO product is backed by a **3-Year Manufacturer Warranty**. For any questions, concerns, or assistance with your product, please contact VIVO customer support. Our U.S.-based sales and technical support team is available to provide high-quality assistance.