

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [BRUNNER](#) /

› [BRUNNER 7-Piece Aluminum Camping Cookware Set with Vacublock System, Ø 24 cm Instruction Manual](#)

BRUNNER 0806085NCO

BRUNNER 7-Piece Aluminum Camping Cookware Set with Vacublock System, Ø 24 cm Instruction Manual

1. INTRODUCTION

This instruction manual provides essential information for the safe and effective use of your BRUNNER 7-Piece Aluminum Camping Cookware Set. Please read this manual thoroughly before initial use and retain it for future reference. This set is designed for efficient cooking in camping and outdoor environments, featuring a space-saving Vacublock system and durable non-stick coating.



Figure 1: Overview of the BRUNNER 7-Piece Aluminum Camping Cookware Set.

2. PRODUCT COMPONENTS

The BRUNNER 7-Piece Aluminum Camping Cookware Set includes the following items:

- 1 x Large Pot (Ø 24 cm, approximately 6 liters capacity)
- 1 x Small Pot (Ø 20 cm, approximately 2.5 liters capacity)
- 1 x Large Frying Pan (Ø 24 cm)
- 1 x Small Frying Pan (Ø 22 cm)
- 2 x Lids (compatible with various pieces)
- 1 x Removable Handle
- 1 x Lashing Strap (for securing stacked set)



Figure 2: Stacked cookware set illustrating dimensions and total weight (3.80 kg).

3. SETUP

3.1 Initial Cleaning

Before first use, wash all pots, pans, and lids with warm soapy water. Rinse thoroughly and dry completely. This removes any manufacturing residues.

3.2 Attaching the Removable Handle

The set includes a removable handle for convenience and space-saving. To attach, align the handle's gripping mechanism with the rim of the pot or pan. Squeeze the handle's lever to open the grip, secure it firmly to the cookware rim, and release the lever to lock it in place. Ensure the handle is securely attached before lifting or moving hot cookware.

GRIP SYSTEM



PFOA free



Ceramic

Gas

Electric Induction

Figure 3: Detail of the removable handle attachment mechanism.

3.3 Vacublock Stacking System

The Vacublock system is designed for compact storage and secure transport. Stack the pots and pans in descending order of size. The lids are designed to fit snugly, and the entire stack can be compressed and secured using the provided lashing strap to prevent movement and rattling during transport.



Figure 4: Illustration of the Vacublock stacking process.



Figure 5: The cookware set fully stacked and secured with the lashing strap.

4. OPERATING INSTRUCTIONS

4.1 Stovetop Compatibility

This cookware set is compatible with various heat sources, including:

- Gas stovetops
- Electric stovetops
- Ceramic stovetops
- Induction hobs

Ensure the cookware base is centered on the heat source for even heating.

4.2 Cooking with Non-Stick Surfaces

The pots and pans feature a durable non-stick coating. To prolong its life:

- Use low to medium heat settings. High heat can damage the non-stick surface over time.
- Always use wooden, silicone, or plastic utensils. Metal utensils can scratch the coating.
- Avoid cutting food directly in the pans.

4.3 Using the Lids

The included lids are designed for efficient cooking. Some lids may feature integrated straining holes for easy draining of liquids.



Figure 6: Lids with integrated pouring features for convenience.

4.4 Oven Use

The cookware is oven-safe. Remove the removable handle before placing pots or pans in the oven.

5. MAINTENANCE

5.1 Cleaning

The BRUNNER cookware set is dishwasher safe. For best results and to prolong the life of the non-stick coating, hand washing with warm soapy water and a soft sponge is recommended. Avoid abrasive cleaners or scouring pads, which can damage the non-stick surface.

5.2 Care for Non-Stick Coating

To maintain the non-stick properties:

- Allow cookware to cool completely before washing.
- Do not use metal scrubbers.

- Store carefully to prevent scratching by other utensils or cookware. The Vacublock system and pot protectors (if included) help prevent this.

5.3 Storage

Utilize the Vacublock stacking system and lashing strap for compact and secure storage, especially during travel. This prevents damage and minimizes noise.

6. TROUBLESHOOTING

- **Food Sticking:** Ensure you are using appropriate cooking fats or oils. Avoid excessively high heat, which can degrade the non-stick coating.
- **Cookware Rattling During Transport:** Re-stack the set using the Vacublock system and ensure the lashing strap is securely tightened.
- **Handle Not Attaching Securely:** Check for any debris in the gripping mechanism. Ensure the handle is fully engaged and the lever is released to lock it onto the cookware rim.

7. SPECIFICATIONS

Feature	Detail
Brand	BRUNNER
Model Number	0806085NCO
Material	Aluminum
Coating	Non-stick, Stone-effect
Color	Black
Number of Pieces	7
Total Weight	3.8 kg
Stovetop Compatibility	Gas, Electric, Ceramic, Induction
Oven Safe	Yes (without removable handle)
Dishwasher Safe	Yes

8. WARRANTY AND SUPPORT

Information regarding product warranty and customer support is not provided within this manual. Please refer to the product packaging or the retailer's website for details on warranty coverage and how to contact customer service for assistance.