

[Manuals.plus](#) /

› [Skullcandy](#) /

› Skullcandy Jib Wired Earbuds S2DUYK-M712 User Manual

Skullcandy Jib

Skullcandy Jib Wired Earbuds User Manual

Model: Jib (S2DUYK-M712)

INTRODUCTION

Thank you for choosing Skullcandy Jib Wired Earbuds. This manual provides essential information for setting up, operating, and maintaining your product. Please read it carefully to ensure optimal performance and longevity.





Image: Skullcandy Jib Wired Earbuds in Cobalt Blue, showcasing the earbud design and in-line remote.

WHAT'S INCLUDED

- Skullcandy Jib Wired Earbuds
- Ear Gels (Small, Medium)
- User Manual (this document)

SETUP

1. Selecting the Right Ear Gels

For optimal sound quality and noise isolation, it is crucial to select the correct size ear gels. Your Jib earbuds come with two sizes: Small (S) and Medium (M).

1. Try both sizes to determine which provides the most comfortable and secure fit.
2. A good fit will create a seal in your ear canal, enhancing bass response and blocking external noise.



Image: A person wearing Skullcandy Jib earbuds, demonstrating proper fit and placement in the ear.

2. Connecting to Your Device

The Skullcandy Jib Wired Earbuds feature a standard 3.5mm AUX plug for universal compatibility.

1. Locate the 3.5mm audio jack on your smartphone, tablet, computer, or other audio device.
2. Insert the 3.5mm plug of your Jib earbuds firmly into the audio jack.
3. No charging or pairing is required. Your earbuds are ready for use immediately upon connection.

OPERATING YOUR EARBUDS

Your Skullcandy Jib earbuds are equipped with an in-line remote and microphone for convenient control of audio playback and calls.



Image: Close-up view of the in-line remote on the Skullcandy Jib earbuds, showing the single button and microphone.

Audio Control

- **Play/Pause:** Press the button once.
- **Next Track:** Press the button twice quickly.
- **Previous Track:** Press the button three times quickly.

Call Control

- **Answer/End Call:** Press the button once.
- **Reject Call:** Press and hold the button for approximately 2 seconds.

MAINTENANCE

Cleaning Your Earbuds

- Gently wipe the earbuds and ear gels with a soft, dry, lint-free cloth.
- For deeper cleaning of ear gels, remove them from the earbuds and wash with mild soap and water. Ensure they are completely dry before reattaching.
- Do not use harsh chemicals or abrasive materials.

Storage

- Store your earbuds in a clean, dry place when not in use.
- Avoid extreme temperatures and direct sunlight.
- Do not wrap the cable too tightly to prevent damage.

TROUBLESHOOTING

- **No Sound:**
 - Ensure the 3.5mm plug is fully inserted into your device's audio jack.
 - Check your device's volume settings.
 - Test the earbuds with another audio device to rule out a device-specific issue.
- **Microphone Not Working:**
 - Ensure the 3.5mm plug is fully inserted.
 - Check your device's microphone input settings during a call or recording.
 - Ensure the microphone is not obstructed.
- **Poor Sound Quality / Muffled Audio:**
 - Verify that the ear gels are correctly sized and creating a proper seal in your ear.
 - Clean the ear gels and earbud nozzles to remove any debris.
 - Test with another audio source to check if the issue persists.

SPECIFICATIONS

Feature	Detail
Model Name	Jib
Item Model Number	S2DUYK-M712
Connectivity Technology	Wired (3.5 mm Jack)
Noise Control	Sound Isolation
Microphone	In-line Microphone Included
Control Type	In-line button for Call and Track Control
Frequency Range	20 Hz - 20,000 Hz
Item Weight	4 Grams (0.141 ounces)
Product Dimensions	7.68 x 2.64 x 1.36 inches

Material	Plastic
UPC	878615098619

WARRANTY & SUPPORT

Your Skullcandy Jib Wired Earbuds are covered by a**Skullcandy 1-Year USA Limited Warranty**. This warranty covers manufacturing defects and ensures your product performs as expected. For warranty claims, technical support, or further assistance, please visit the official Skullcandy support website or contact their customer service directly.

Online Support: www.skullcandy.com/support

