

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [tectake](#) /

› [tectake Bistro Set - Folding Table and 2 Chairs Instruction Manual](#)

tectake 402936-NL

tectake Bistro Set - Folding Table and 2 Chairs Instruction Manual

Model: 402936-NL

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your tectake Bistro Set, Model 402936-NL. Please read this manual thoroughly before assembly and use, and retain it for future reference. The set includes one folding table and two folding chairs, designed for outdoor use on balconies, patios, and gardens.

2. SAFETY INFORMATION

Important Safety Warnings:

- The table may be heavy and could have sharp edges during handling. Exercise caution during assembly and transport.
- The table is not heat resistant. Do not place hot items directly on the glass surface without protection, and avoid using near heat sources.
- Ensure all components are securely locked in place before use to prevent collapse.
- Do not exceed the maximum weight capacity: 120 kg for chairs (each) and 65 kg for the table.
- Keep children away from moving parts during folding and unfolding to prevent injury.


3. SETUP AND ASSEMBLY

The tectake Bistro Set is designed for quick and easy setup with minimal assembly required. The table and chairs are pre-assembled and only need to be unfolded.

3.1 Unfolding the Chairs

1. Hold the chair frame firmly.
2. Gently pull the seat and backrest apart until the chair fully extends and locks into its open position. Ensure the locking mechanism is engaged for stability.

SUPERSLIM Design



tectake
garden

Deze handige bistroset is een echte alleskunner; door het compacte formaat is het niet alleen ideaal voor kleinere terrassen, tuinen of balkons, maar dankzij de uiterst praktische opvouwfunctie is hij ook een eersteklas metgezel voor jouw volgende kampeertrip.

Image: A person demonstrating the unfolding process of a tectake chair, showing the frame extending.

3.2 Unfolding the Table

1. Place the table on its side.
2. Extend the legs outwards until they are fully open and the table stands securely. Ensure the locking mechanism for the legs is engaged.
3. Carefully stand the table upright on its four legs.



Image: A detailed view of the tectake folding table, illustrating its compact folded form and the process of extending its legs. Once unfolded, ensure all components are stable and properly balanced before use.

4. OPERATING INSTRUCTIONS

The tectake Bistro Set is designed for versatile outdoor use, offering a comfortable and space-saving solution for various activities.

4.1 General Use

- Use the set on a flat, stable surface to ensure maximum stability.
- The chairs and table are suitable for dining, relaxing, or as additional seating in your outdoor space.
- The anti-slip feet on both the table and chairs provide stability and protect floor surfaces.



tectake
garden

Creëer een gezellige plek voor cocktails, ontspanning en een goed gesprek thuis in de buitenlucht of onderweg. De smaakvolle set bestaande uit een tafel en 2 stoelen zorgt overal voor een ontspannen sfeer, waar je de stress van het dagelijks leven kunt vergeten.

Image: The tectake bistro set, consisting of a round table and two chairs, positioned on an outdoor patio, demonstrating typical usage.

4.2 Folding for Storage

To fold the set for storage or transport:

- Chairs:** Locate the folding mechanism under the seat. Release it and gently push the seat and backrest together until the chair is flat.
- Table:** Turn the table upside down. Release the leg locking mechanism and fold the legs inwards until they are flat against the tabletop.

The compact design allows for easy storage in small spaces.

5. MAINTENANCE

Proper maintenance will extend the lifespan and preserve the appearance of your tectake Bistro Set.

5.1 Cleaning

- Glass Tabletop:** Clean with a soft cloth and a mild glass cleaner. Avoid abrasive materials that could scratch

the surface.

- **Textile Fabric (Chairs):** The quick-drying, tear-resistant textile fibers can be cleaned with a damp cloth and mild soap. Rinse thoroughly and allow to air dry.
- **Steel Frame:** Wipe down the powder-coated steel frame with a damp cloth. For stubborn dirt, use a mild detergent. Dry immediately to prevent water spots.

5.2 Weather Resistance

The set features a robust steel frame with stainless steel screws and weather-resistant materials. While designed for outdoor use, prolonged exposure to extreme weather conditions (heavy rain, snow, intense sun) may affect its longevity. Consider storing the set indoors or covering it during harsh weather.



Image: Visual representation of the tectake bistro set's water-repellent properties and weather resistance, depicted in both rainy and sunny environments.

6. TROUBLESHOOTING

If you encounter any issues with your bistro set, refer to the following common problems and solutions:

- **Instability:** Ensure the set is placed on a flat surface. Check that all folding mechanisms are fully engaged and locked. Verify that no parts are bent or damaged.
- **Difficulty Folding/Unfolding:** Check for any obstructions in the folding joints. Apply a small amount of silicone spray to the hinges if they are stiff, ensuring not to get it on the fabric or glass.
- **Scratches on Glass:** Minor scratches can sometimes be minimized with specialized glass repair kits. For deeper scratches, consider replacing the glass top if available.
- **Rust Spots:** Although equipped with stainless steel screws and a powder-coated frame, rust can occur if the coating is damaged or in highly corrosive environments. Clean rust spots immediately with a rust remover and apply a protective coating.

7. SPECIFICATIONS

Feature	Detail
Model Number	402936-NL
Brand	tectake
Color	Black
Material	Powder-coated steel, polyester, polyvinyl chloride, glass
Chair Dimensions (Total)	45.5 x 58 x 81 cm (Width x Depth x Height)
Chair Dimensions (Folded)	45.5 x 12.5 x 98 cm
Seat Height	45 - 49 cm
Table Dimensions (Total)	60 x 70.5 cm (Diameter x Height)
Table Dimensions (Folded)	60 x 9 x 91 cm
Chair Load Capacity	120 kg
Table Load Capacity	65 kg
Item Weight (Chair)	Approx. 3.5 kg
Item Weight (Table)	Approx. 6.5 kg
Assembly Required	No (unfolding only)

AFMETINGEN

Totale afmetingen stoel
45,5 x 58 x 81 cm

Afmetingen stoel ingeklaptd
45,5 x 12,5 x 98 cm

Zithoogte
45 - 49 cm

Totale afmetingen tafel
60 x 70,5 cm

Afmetingen tafel ingeklaptd
60 x 9 x 91 cm

TECHNISCHE DETAILS

Draagkracht stoel 120 kg

Draagkracht tafel 65 kg

Gewicht tafel ca. 6,5 kg

Gewicht per stoel ca. 3,5 kg

Materiaal gepoedercoat staal,
polyester, polyvinylchloride, glas

INHOUD

Tafel
2 stoelen
Montagehandleiding



Image: A comprehensive diagram illustrating the dimensions of both the tectake folding chair and the round folding table, including folded and unfolded measurements.

8. WARRANTY INFORMATION

Specific warranty details for the tectake Bistro Set (Model 402936-NL) are not provided in the product information. Please refer to your purchase receipt or contact the seller directly for information regarding warranty coverage and terms.

9. SUPPORT

For further assistance, technical support, or to inquire about replacement parts for your tectake Bistro Set, please contact the seller or manufacturer directly. Contact information can typically be found on your purchase documentation or the seller's website.

