AREBOS AR-HE-EM22EL

AREBOS Ice Cube Machine Instruction Manual

Model: AR-HE-EM22EL | Brand: AREBOS

1. Introduction

Thank you for choosing the AREBOS Ice Cube Machine. This appliance is designed to provide you with a convenient and efficient way to produce ice cubes for various uses, from refreshing beverages to first aid applications. With its rapid production, multiple ice cube sizes, and user-friendly features, this machine is a valuable addition to any home or small commercial setting.

Please read this instruction manual carefully before operating the appliance to ensure safe and optimal performance. Keep this manual for future reference.

2. Safety Instructions

To reduce the risk of fire, electric shock, or injury when using your appliance, follow these basic safety precautions:

- Read all instructions before use.
- Do not touch the evaporator or ice blades when the machine is in operation.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Ensure the power supply matches the voltage specified on the appliance's rating label.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep the appliance away from heat sources such as radiators, heat registers, stoves, or other heat-producing appliances.
- Do not use the appliance for purposes other than its intended use.
- Unplug the appliance from the outlet when not in use and before cleaning.
- Supervise children closely when the appliance is in use.
- Only use potable water in the water tank.

3. Product Overview

3.1 Components

The AREBOS Ice Cube Machine is designed for ease of use and efficient ice production. Key components include:

- **Main Unit:** Stainless steel casing with integrated control panel and LCD display.
- **Water Tank:** 2.2-liter capacity for water storage.
- **Ice Basket:** Removable basket for collecting produced ice cubes (0.4-liter capacity).
- **Ice Scoop:** Included for hygienic retrieval of ice cubes.
- **Viewing Window:** Transparent lid to monitor ice production.



Figure 3.1: AREBOS Ice Cube Machine with LCD display and ice scoop.



Figure 3.2: The ice machine in a typical usage scenario, providing ice for drinks.

3.2 Control Panel and Display

The intuitive control panel features an LCD display and four operational buttons for easy control of the ice maker.



Figure 3.3: Detailed view of the control panel and its indicators.

- **LCD Display:** Shows current time, timer settings, ice cube size, and status indicators.
- **Operation Indicator:** Illuminates when the machine is actively making ice.
- **Ice Container Full Indicator:** Alerts when the ice basket is full.
- **Water Tank Empty Indicator:** Alerts when the water tank needs refilling.
- **ON/OFF Button:** Powers the machine on or off.
- **SET Button:** Used for setting the timer.
- **Triangle Up/Down Buttons:** Adjust time or timer settings.
- **SELECT Button:** Chooses the desired ice cube size (Small, Medium, Large).

3.3 Key Features



Figure 3.4: Overview of the machine's key features.

- **Energy Saving:** Designed for efficient power consumption.
- **Silent Operation:** Operates at approximately 30 dB(A).
- **BPA Free:** Constructed with safe, food-grade materials.

4. Setup

4.1 Unpacking

1. Carefully remove the ice maker from its packaging.
2. Remove all packaging materials, including any tape or protective films.
3. Check the appliance for any damage. If damaged, do not operate and contact customer support.

4. Place the ice maker on a flat, stable surface, away from direct sunlight and heat sources. Ensure there is adequate ventilation around the unit.

4.2 Initial Cleaning

Before first use, it is recommended to clean the appliance thoroughly.

1. Clean the interior parts, ice basket, and ice scoop with a soft cloth and mild detergent. Rinse thoroughly.
2. Perform a self-cleaning cycle as described in Section 6.2.

4.3 Filling the Water Tank

1. Open the lid of the ice maker.
2. Pour potable water into the water tank. Do not exceed the MAX fill line.
3. Close the lid securely.

5. Operation

5.1 Powering On/Off

- To turn on the machine, press the **ON/OFF** button. The operation indicator will light up.
- To turn off the machine, press the **ON/OFF** button again.

5.2 Selecting Ice Cube Size

- After powering on, press the **SELECT** button repeatedly to cycle through the available ice cube sizes: Small, Medium, and Large.
- The selected size will be indicated on the LCD display.

5.3 Timer Function

The machine features a timer function to schedule operation.

1. In standby mode, press the **SET** button. The timer display will flash.
2. Use the **Triangle Up/Down** buttons to set the desired delay time (e.g., how many hours until the machine turns on or off).
3. Press **SET** again to confirm the setting. The timer icon will appear on the display.

5.4 Indicators

- **Ice Container Full:** When the ice basket is full, the corresponding indicator will light up, and the machine will pause ice production. Remove ice to resume.
- **Water Tank Empty:** When the water level is low, the indicator will light up. Refill the water tank to continue ice production.



Figure 5.1: Various applications for the ice produced by the machine.

6. Maintenance and Cleaning

6.1 Regular Cleaning

Regular cleaning ensures optimal performance and hygiene.

- Always unplug the appliance before cleaning.
- Clean the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Remove the ice basket and clean it with warm, soapy water. Rinse and dry thoroughly.
- Drain any remaining water from the water tank by removing the drain plug (if applicable) or by carefully tilting the machine.
- Wipe the interior of the water tank and ice-making components with a clean, damp cloth.

6.2 Self-Cleaning Function

The machine features an automatic self-cleaning function:



Figure 6.1: Steps for activating the self-cleaning program.

1. Ensure the ice basket is empty.
2. Pour a 1:1 mixture of water and vinegar into the water tank.
3. In standby mode, hold down the**ON**/**OFF** button for 5 seconds to start the self-cleaning mode.
4. Cleaning starts automatically after a beep sound. The cycle will run for a few minutes.
5. Once the self-cleaning cycle is complete, the device will automatically enter standby mode.
6. Drain the water/vinegar mixture and rinse the tank thoroughly with clean water.

6.3 Storage

If the appliance will not be used for an extended period:

- Perform a thorough cleaning, including the self-cleaning cycle.

- Ensure all parts are completely dry.
- Store the appliance in a cool, dry place, away from direct sunlight and extreme temperatures.

7. Troubleshooting

Before contacting customer service, please refer to the following table for common issues and their solutions:

Problem	Possible Cause	Solution
Machine not producing ice.	Water tank empty.	Refill the water tank with potable water.
	Ice basket full.	Remove ice from the basket.
	Ambient temperature too high.	Move the machine to a cooler location.
Ice cubes are too small or clumpy.	Water temperature too high.	Use colder water.
	Machine needs cleaning.	Perform a self-cleaning cycle.
Machine is noisy.	Not on a level surface.	Ensure the machine is on a flat, stable surface.
	Air circulation blocked.	Ensure adequate space around the machine for ventilation.

8. Technical Specifications



Figure 8.1: Product dimensions.

Specification	Value
Brand	AREBOS
Model Number	AR-HE-EM22EL
Product Dimensions (L x W x H)	33 x 25 x 36 cm
Weight	9.5 kg
Water Tank Capacity	2.2 Liters
Ice Basket Capacity	0.4 Liters
Ice Production (24h)	Up to 12 kg

Specification	Value
Voltage	220 Volt
Power Consumption	150 Watts
Country of Origin	China

9. Warranty and Support

This AREBOS Ice Cube Machine comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including the warranty period and coverage details.

For technical support, troubleshooting assistance beyond what is covered in this manual, or warranty claims, please contact the AREBOS customer service department. Contact information can typically be found on the manufacturer's website or on the product packaging.

When contacting support, please have your product model number (AR-HE-EM22EL) and purchase information readily available.

© 2025 AREBOS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question