Wood Trick Wood Trick Treasure Box

Wood Trick Treasure Puzzle Box User Manual

Model: Wood Trick Treasure Box

Introduction Safety Information Package Contents Assembly Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

This manual provides detailed instructions for the assembly and operation of your Wood Trick Treasure Puzzle Box. This 3D wooden model kit is designed for adults and offers an engaging building experience, resulting in a functional jewelry or keepsake box.



Image 1.1: The fully assembled Wood Trick Treasure Puzzle Box.

2. Safety Information

Please read and understand all safety information before beginning assembly.

- **Small Parts:** This kit contains small parts which may pose a choking hazard. Keep out of reach of small children.
- **Sharp Edges:** Some wooden pieces may have sharp edges after removal from the sheets. Handle with care and use sandpaper as needed to smooth edges.
- **Adult Assembly:** This product is intended for adult assembly due to the complexity and nature of the parts.
- **Ventilation:** If staining or painting the model, ensure adequate ventilation.

3. Package Contents

Verify that all components are present before starting assembly. Your Wood Trick Treasure Puzzle Box kit should include:

- Approximately 192 precision-cut wooden pieces.
- Illustrated step-by-step assembly guide.
- Paraffin wax for lubricating moving parts.
- Sandpaper for smoothing edges.
- Small hammer (may be included for assembly assistance).

No glue is required for the assembly of this model.

4. Assembly Instructions

Assembly typically takes 4-6 hours. Patience and attention to detail are key for a successful build.

4.1 General Tips

- **Take Your Time:** Do not rush the assembly process. Each step builds upon the previous one.
- **Follow Instructions Carefully:** Pay close attention to the illustrated guide. Ensure your model matches the images in each step before proceeding.
- **Use Tools Provided:** Utilize the sandpaper to smooth any rough edges on pieces after removal from the sheets. Apply paraffin wax to all moving parts and connections as indicated in the instructions to ensure smooth operation. The small hammer can be useful for gently tapping pieces into place.
- **Check Fit:** Some parts may be tight or loose. Ensure a snug fit without forcing pieces excessively, which could cause breakage.

4.2 Step-by-Step Guidance

Refer to the included illustrated step-by-step assembly guide for detailed visual instructions. The guide will direct you through:

1. Removing pieces from the wooden sheets.
2. Assembling the base structure.
3. Constructing the internal mechanisms and compartments.
4. Attaching decorative elements and the lid.

A detailed video guide of the assembly process may also be available online. Check the Wood Trick official website or YouTube channel for additional resources.

Video 4.1: Official Wood Trick overview of the Jewelry Treasure Box wooden model.

5. Operating Instructions

The Wood Trick Treasure Puzzle Box features a unique mechanical opening system.

5.1 Opening the Box

To open the box and reveal its compartments:

- Locate the button or clasp on the top cover of the box.
- Gently press the button or clasp. The lid will lift, and the internal compartments will extend outwards.



Image 5.1: Demonstrating the opening mechanism of the treasure box.



Image 5.2: The treasure box in its fully open state, showing all compartments.

5.2 Closing the Box

To close the box and secure its contents:

- Simply lower the top cover. The internal compartments will retract, and the lid will lock into place.



Image 5.3: The treasure box with jewelry stored in its various compartments.

6. Maintenance

Proper maintenance ensures the longevity and smooth operation of your wooden model.

- **Lubrication:** Regularly apply paraffin wax to all moving gears, joints, and sliding parts. This reduces friction and prevents wear. Ensure the wax is applied thoroughly, especially to the bottom drawers and where the clasp and lever intersect.
- **Cleaning:** Dust the model periodically with a soft, dry cloth. Avoid using water or chemical cleaners, as these can damage the wood.
- **Inspection:** Periodically inspect the model for any loose or damaged pieces. Address any issues promptly to prevent further damage.
- **Smoothing:** If any parts become rough or sticky, use the provided sandpaper to gently smooth the surfaces. Check for splinters or larger wood chunks that may remain attached to pieces after assembly.

7. Troubleshooting

If you encounter issues with your Wood Trick Treasure Puzzle Box, consider the following solutions:

- **Mechanism Not Opening/Closing Smoothly:**

- Ensure all moving parts are adequately waxed. Reapply paraffin wax to gears, sliders, and hinges.
- Check for any misaligned or improperly fitted pieces. Disassemble and reassemble the problematic section if necessary, ensuring all parts are correctly oriented and fully engaged.
- Verify that no small debris or wood fragments are obstructing the mechanism.

- **Parts Too Loose or Too Tight:**
  - If parts are too tight, gently sand the edges.
  - If parts are too loose, ensure they are fully inserted. In some cases, a small amount of wood glue (not included) might be used for non-moving decorative parts, but avoid it on functional mechanisms.
- **Rubber Bands Lack Tension:**
  - If the rubber bands do not provide enough tension to fully open the lid or retract compartments, ensure they are correctly installed according to the instructions. Check for any stretching or damage to the bands.
- **Broken Pieces:**
  - If a piece breaks during assembly, check the extra wooden sheets for potential replacement parts. Some kits include spares for common fragile components.
  - For critical broken pieces not easily replaced, contact Wood Trick customer support.
- **Difficulty with Specific Steps:**
  - Re-examine the illustrated instructions for the specific step. Ensure every detail matches.
  - Consult online video guides or forums for additional tips from other builders.

8. Specifications

Feature	Detail
Brand	Wood Trick
Model Number	Wood Trick Treasure Box
Material Type	Wood
Number of Pieces	192
Assembled Dimensions (L x W x H)	6.5 x 5.12 x 3.94 inches (16.5 x 13 x 10 cm)
Assembly Time	Approx. 4-6 hours
Recommended Age	Adult
Operation Mode	Manual
Special Features	7 compartments, decorative carving, shimmering crystals



Image 8.1: Dimensions of the assembled Wood Trick Treasure Puzzle Box.

9. Warranty and Support

9.1 Return Policy

This product is subject to a 30-day return or replacement policy from the date of purchase. Please refer to your retailer's specific return guidelines for detailed information.

9.2 Manufacturer Support

For further assistance, missing parts, or inquiries regarding your Wood Trick Treasure Puzzle Box, please contact Wood Trick customer support. You can often find contact information on the packaging or by visiting the official Wood Trick store online: Wood Trick Store.

© 2024 Wood Trick. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question