



Manuals.plus /

› Moxom /

› Moxom 2.4 Amp Micro USB Cable User Manual

## Moxom CC-08

# Moxom 2.4 Amp Micro USB Cable User Manual

Model: CC-08

## 1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your Moxom 2.4 Amp Micro USB Cable. This cable is designed for both fast charging and high-speed data transfer for compatible devices.

Please read this manual thoroughly before using the product and retain it for future reference.

## 2. PRODUCT FEATURES

- Cable Length: 1 meter
- Supports fast charging up to 2.4 Amps
- High-speed data synchronization
- Supports USB 2.0 data transfer speeds up to 480 Mbps
- Durable and tangle-free design
- High purity oxygen-free copper core and nickel-plated connectors for secure charge and data transfer.



Figure 2.1: Moxom Micro USB Cable with both connector types visible.

## Multiple protection Charge transfer is more secure

High purity oxygen free copper core and wire core nickel, can prevent short circuit, corrosion resistance, charging more secure.



Figure 2.2: Illustration of the cable's internal construction for enhanced protection and secure transfer.

## Connected to the handle to play the game, more smooth cool

Connect the USB game handle or the mouse to operate the phone to play games, without touch screen, the operation is more accurate.



Figure 2.3: The cable can be used to connect compatible devices like game controllers to tablets for enhanced gaming experience.

### 3. SETUP

1. **Identify Connectors:** The cable has a Micro USB connector on one end and a standard USB-A connector on the other.
2. **Connect to Device:** Carefully insert the Micro USB connector into the Micro USB port of your smartphone, tablet, or other compatible device. Ensure the connector is oriented correctly to avoid damage.
3. **Connect to Power/Data Source:** Insert the standard USB-A connector into a compatible USB port on a wall charger, power bank, computer, or other USB-enabled device.

### 4. OPERATING INSTRUCTIONS

#### 4.1. Charging

- Connect the Micro USB end to your device and the USB-A end to a USB wall adapter or power bank.

- Ensure the power source is active. Your device should indicate that it is charging.
- The cable supports fast charging for devices that are compatible with 2.4 Amp input.

## 4.2. Data Transfer

- Connect the Micro USB end to your device and the USB-A end to a USB port on a computer (PC or Mac).
- Your computer should recognize the connected device. You may need to select a data transfer mode on your device (e.g., "File Transfer" or "MTP").
- You can now transfer files between your device and the computer at speeds up to 480 Mbps.

## 5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the cable and connectors. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the cable in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling or bending the cable at sharp angles to prevent internal damage.
- **Handling:** Always grasp the connector head when plugging or unplugging the cable. Do not pull on the cable itself, as this can damage the internal wires.

## 6. TROUBLESHOOTING

- **Device not charging:**
  - Ensure both ends of the cable are securely connected.
  - Try a different USB port or power adapter.
  - Check if your device's charging port is clean and free of debris.
- **Slow charging:**
  - Ensure your power adapter supports fast charging and provides sufficient current (e.g., 2.4 Amp).
  - Avoid using your device heavily while charging.
- **Data transfer issues:**
  - Ensure your device is set to "File Transfer" or "MTP" mode when connected to a computer.
  - Try a different USB port on your computer.
  - Restart both your device and computer.

## 7. SPECIFICATIONS

Feature	Specification
Brand Name	Moxom
Model Reference	CC-08
Connector Type	Micro USB
Cable Type	USB
Cable Connector Type	Male to Male
Maximum Current	2.4 Amp
Compatible Devices	Charging Adapter
Special Features	Tangle-free
Recommended Uses	Charging
Color	White
Item Form	Round
Package Dimensions	24 x 10.5 x 3.7 cm
Item Weight	40 grams

## 8. WARRANTY AND SUPPORT

Moxom products are manufactured to high-quality standards. For information regarding warranty coverage and customer support, please refer to the packaging or contact your point of purchase. Keep your purchase receipt as proof of purchase.

For further assistance, please visit the official Moxom website or contact their customer service.