

Antarctic Star 5314

Antarctic Star Tower Fan User Manual

Model: 5314

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using this appliance and retain for future reference. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- Always unplug the fan from the power outlet before cleaning, servicing, or moving.
- Do not operate the fan with a damaged cord or plug. If the cord or plug is damaged, contact qualified service personnel for repair or replacement.
- This appliance is intended for indoor household use only. Do not use outdoors or for commercial purposes.
- Keep the fan away from water or other liquids. Do not immerse the fan in water.
- Ensure the voltage indicated on the fan's rating label matches your local power supply before connecting.
- Do not insert fingers or any objects through the grille when the fan is operating.
- Close supervision is necessary when the fan is used by or near children, pets, or invalids. The bladeless design of this fan enhances safety for children and pets by preventing direct contact with moving blades.
- Place the fan on a stable, flat surface to prevent it from tipping over.
- Do not block air openings or operate near curtains or other materials that could block airflow.

2. PRODUCT OVERVIEW

The Antarctic Star Tower Fan is a sleek, 43-inch tall oscillating fan designed to provide efficient and quiet cooling for various indoor spaces. It features a bladeless design for enhanced safety and comes with a convenient remote control for easy operation.



Image: The Antarctic Star 43-inch White Tower Fan with its remote control, illustrating its modern design and airflow.

Key Features:

- **Bladeless Design:** Safe for homes with children and pets.
- **Quiet Operation:** Engineered for low noise levels, ideal for bedrooms and offices.
- **3 Speed Settings:** Low, Medium, and High for customized airflow.
- **3 Wind Modes:** Normal, Natural, and Sleep modes to suit different preferences.
- **85° Oscillation:** Wide-angle oscillation for broad air circulation.
- **12-Hour Timer:** Programmable timer for automatic shut-off.

- **Remote Control:** Convenient operation from a distance.



Healthy for kids

Secure design for your daily use

Image: A child's hand safely positioned near the fan's narrow grill, highlighting the secure bladeless design.



Quiet And Low Noise

Image: A person sleeping soundly, demonstrating the fan's quiet operation for undisturbed rest.

3. SETUP

The Antarctic Star Tower Fan requires minimal assembly. Follow these steps to set up your fan:

1. **Unpack:** Carefully remove all components from the packaging. Ensure all parts are present: the main fan body, the base (usually two halves), and the remote control.
2. **Assemble the Base:** If the base is in two halves, align them and snap or screw them together according to the markings.
3. **Attach Base to Fan Body:** Align the assembled base with the bottom of the fan body. Twist or secure with screws (if provided) until the base is firmly attached. Ensure the power cord passes through the designated opening in the base.
4. **Placement:** Place the fan on a firm, level surface, ensuring there is adequate space around it for optimal airflow and oscillation.
5. **Power Connection:** Plug the power cord into a standard 115V AC electrical outlet.

4. OPERATING INSTRUCTIONS

Your Antarctic Star Tower Fan can be operated using the control panel on top of the fan or the included remote control.

Control Panel & Remote Control Functions:

Customize Your Cooling Style

Living in a comfort zone, just with a smart remote.



Normal



Natural



Sleep



Image: The tower fan displaying icons for Normal, Natural, and Sleep modes, indicating customizable cooling styles.

- Temperature Indicator
- High Fan Speed
- Timer Indicator
- Normal Fan Mode
- Oscillation Indicator
- Natural Fan Mode
- Low Fan Speed
- Sleep Fan Mode
- Middle Fan Speed
- Show Ambient temperature And Timer Hours

Special Function For Better Sleep

- ON/OFF
- Light
- OSC
- Timer
- Mode
- Speed

Image: A detailed view of the remote control for the Antarctic Star Tower Fan, showing buttons for power, oscillation, timer, mode, light, and speed.

- **Power (ON/OFF):** Press the power button to turn the fan on or off.
- **Speed:** Press the 'Speed' button repeatedly to cycle through the 3 fan speeds: Low, Medium, and High.



Image: The tower fan illustrating its three speed settings: High, Medium, and Low, for varied airflow intensity.

- **Mode:** Press the 'Mode' button to select from 3 wind modes: Normal, Natural, and Sleep.
 - *Normal Mode:* Constant airflow at the selected speed.
 - *Natural Mode:* Simulates natural breeze by varying fan speed.
 - *Sleep Mode:* Gradually decreases fan speed and dims display lights for quiet, comfortable sleep.
- **Oscillation (OSC):** Press the 'OSC' button to activate or deactivate the 85° wide-angle oscillation feature, which distributes air across a larger area.

Large Cooling Space

85° wide-angle oscillation circulates cool air to fill every corner of your room space.



Image: The tower fan shown oscillating, indicating its ability to circulate cool air across a large space.



Image: A visual representation of the fan's 85-degree wide-angle oscillation function.

- **Timer:** Press the 'Timer' button repeatedly to set the automatic shut-off timer in 1-hour increments, up to 12 hours. The display will show the selected time.



Image: A clock face indicating the 12-hour timer function, with a sleeping child in the background, suggesting convenience for nighttime use.

- **Light:** Press the 'Light' button to turn the display lights on or off.

5. MAINTENANCE

Regular cleaning and maintenance will help prolong the life of your fan and ensure optimal performance.

Cleaning:

- **Always unplug the fan** before cleaning.
- **Exterior Cleaning:** Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners, waxes, or solvents as these may damage the finish.
- **Air Inlet/Outlet:** Use a vacuum cleaner with a brush attachment to gently remove dust and debris from the air inlet and outlet grilles. Do not attempt to open the fan casing.
- **Remote Control:** Wipe the remote control with a soft, dry cloth.

Storage:

When not in use for extended periods, store the fan in its original packaging or a clean, dry place. Keep the power cord neatly coiled to prevent damage.

6. TROUBLESHOOTING

If you encounter issues with your fan, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply. Power button not pressed.	Ensure the fan is securely plugged into a working electrical outlet. Press the Power button on the control panel or remote.
Weak or no airflow.	Air inlets/outlets are blocked. Fan speed is too low.	Check for obstructions and clean grilles if necessary. Increase the fan speed setting.
Fan makes unusual noise.	Fan is not on a level surface. Debris inside the fan.	Place the fan on a flat, stable surface. Unplug the fan and gently shake it to dislodge any small debris. If noise persists, contact customer support.

Problem	Possible Cause	Solution
Remote control not working.	Batteries are dead or incorrectly inserted. Obstruction between remote and fan.	Replace batteries (ensure correct polarity). Remove any objects blocking the signal path. Ensure remote is pointed at the fan's receiver.

If the problem persists after trying these solutions, please contact Antarctic Star customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	Antarctic Star
Model Name	5314
Color	White
Product Dimensions	11.81"D x 11.81"W x 43.3"H
Item Weight	9.64 pounds
Power Source	Corded Electric
Voltage	115 Volts (AC)
Wattage	30 watts
Noise Level	36 dB
Control Method	Remote
Special Features	Bladeless, Oscillating, Remote Controlled, Timer
Number of Power Levels	3
Indoor/Outdoor Usage	Indoor

8. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or visit the official Antarctic Star website. For technical support, troubleshooting assistance beyond this manual, or to inquire about replacement parts, please contact Antarctic Star customer service directly. You can often find contact details on the manufacturer's website:[Antarctic Star Official Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question