

TecTake 800451

tectake 4-Piece Dining Chair Set

Model: 800451

1. INTRODUCTION

Thank you for choosing the tectake 4-Piece Dining Chair Set. This manual provides essential information for the safe assembly, proper use, and maintenance of your new chairs. Designed for comfort and durability, these modern ergonomic chairs feature faux leather upholstery and sturdy steel legs, making them a versatile addition to your dining room, kitchen, living room, or office space.

Please read these instructions carefully before assembly and retain this manual for future reference.

2. SAFETY INFORMATION

- Always assemble the chairs on a soft, clean surface to prevent scratches.
- Ensure all screws and bolts are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not stand on the chairs or use them as a step stool.
- The maximum weight capacity for each chair is 120 kg (approximately 264 lbs). Do not exceed this limit.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Avoid exposing the chairs to direct sunlight or extreme temperatures to prevent material degradation.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- 4 x tectake Dining Chairs (unassembled)
- 1 x Set of Assembly Hardware (screws, washers, Allen key)
- 1 x Assembly Instructions Manual (this document)



Image: The complete set of four tectake dining chairs, showcasing their modern design and black faux leather finish.

4. SETUP AND ASSEMBLY

Assembly of your tectake dining chairs is designed to be quick and straightforward. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent damage.
2. **Identify Parts:** Refer to the included hardware diagram (if separate) to identify all screws, washers, and the Allen key.
3. **Attach Seat to Frame:** Align the seat cushion with the pre-drilled holes on the steel frame. Insert the appropriate screws and washers, then partially tighten them with the Allen key.
4. **Attach Backrest to Frame:** Similarly, align the backrest with the frame and secure it with the remaining screws and washers.
5. **Final Tightening:** Once all parts are loosely assembled, place the chair on a level surface. Apply gentle pressure to ensure it sits evenly, then fully tighten all screws. Do not overtighten.

6. **Install Anti-Slip Caps:** Ensure the anti-slip caps are securely fitted to the bottom of the steel frame to protect your floors and provide stability.

tectake
home

Productinformatie

AFMETINGEN

Totale afmetingen

41 x 52 x 99 cm

Zitvlak

41 x 43 cm

Zithoogte

48 cm

Dikte van de vulling

5 cm

Afmetingen zijn bij benadering

TECHNISCHE GEGEVENS

Gewicht ca. 7,5 kg

Draagkracht 120 kg

Materiaal poedergecoat staal,
polyurethaan

INHOUD

4 stoelen

Montagemateriaal

Montagehandleiding



Image: A side view of an assembled chair, illustrating the connection points between the seat, backrest, and the C-shaped steel frame.

STIJLVOLLE Allrounder



tectake
home

Hun grote veelzijdigheid danken deze moderne meubelstukken aan het bewust subtiel gehouden ontwerp. De perfecte combinatie van een hoge rugleuning en het gebogen stalen frame maakt deze set tot een eyecatcher die naadloos in elke woonstijl past.



Image: Detailed view showing the anti-slip caps on the chair's base, designed to protect flooring and enhance stability. Also visible is the quality stitching on the faux leather.

5. USAGE AND OPERATION

Your tectake dining chairs are designed for versatile use and comfort in various settings:

- **Comfortable Seating:** The ergonomic design with padded seat and backrest provides optimal support for extended periods, making them suitable for dining, working, or relaxing.
- **Versatile Placement:** These chairs are lightweight and easy to move, allowing for flexible arrangement in dining rooms, kitchens, living rooms, bedrooms, or even office spaces.
- **Floor Protection:** The integrated anti-slip caps on the steel frame help prevent scratches and damage to your flooring.



EEN ECHT
Dreamteam


Image: The tectake dining chairs seamlessly integrated into a modern dining room setting, demonstrating their aesthetic appeal and functional use.



De **ergonomische rugleuning** en de **zachte vulling** zorgen voor een eerste klas zitervaring.



Het **duurzame kunstleer** is zowel vuil- als waterafstotend en gemakkelijk schoon te maken.



Het extreem stevige, **poedergecoate stalen frame** garandeert een bijzonder hoog draagvermogen.



De **antislipdoppen van kunststof** zorgen voor een stabiele stand en beschermen elke ondergrond.

Image: This collage illustrates the chairs' versatility, showing them in different home environments such as a dining room, living room, kitchen, and bedroom.

6. MAINTENANCE AND CARE

To ensure the longevity and appearance of your tectake dining chairs, follow these maintenance guidelines:

- **Cleaning Faux Leather:** The durable faux leather upholstery is easy to clean. Wipe spills immediately with a soft, damp cloth. For general cleaning, use a mild soap solution and wipe dry with a clean cloth. Avoid harsh chemicals or abrasive cleaners.
- **Frame Care:** The steel frame can be cleaned with a soft, damp cloth. Avoid using abrasive materials that could scratch the finish.
- **Regular Checks:** Periodically inspect all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the faux leather to fade or crack over time. Position chairs away from direct sun exposure when possible.

7. TROUBLESHOOTING

If you encounter any issues with your chairs, refer to the following common solutions:

- **Chair Wobbles:**
 - Ensure the chair is on a flat, even surface.
 - Check all assembly screws and tighten them evenly. Sometimes loosening all screws slightly, sitting on the chair to level it, and then re-tightening can resolve wobbling.
 - Verify that the anti-slip caps are properly installed and not damaged.
- **Squeaking Noises:**
 - Squeaking often indicates loose connections. Re-tighten all screws.
 - A small amount of silicone spray on the joints (avoiding upholstery) can sometimes help, but ensure it does not damage the material.
- **Stains on Upholstery:**
 - For most stains, a damp cloth with mild soap is effective. Blot, do not rub.
 - Test any cleaning solution on an inconspicuous area first.

If problems persist, please contact tectake customer support for further assistance.

8. SPECIFICATIONS

Brand	TecTake
Model Number	800451
Color	Black
Material	Faux Leather (Upholstery), Powder-coated Steel (Frame)
Overall Dimensions (L x W x H)	41 x 52 x 99 cm (16.1 x 20.5 x 39 inches)
Seat Dimensions (L x W)	41 x 43 cm (16.1 x 16.9 inches)
Seat Height	48 cm (18.9 inches)
Cushion Thickness	5 cm (2 inches)
Weight per Chair	Approx. 7.3 kg (16.1 lbs)
Maximum Load Capacity per Chair	120 kg (264 lbs)

tectake home



Moderne sledestoelen
met hoge rugleuning &
opvallend stalen frame



Stevig kunstleer
vereist weinig onderhoud
en is bijzonder duurzaam



Comfortabele bekleding
door een hoogdichte
schuimvulling



Ergonomisch design
past zich aan het lichaam
aan & ontlast de rug



Uitstekende stabiliteit
met een draagvermogen
van maar liefst 120 kg



100% stabiel
door vloerbeschermende
en antislip doppen









Image: Technical drawing illustrating the key dimensions of the tectake dining chair for reference.

9. WARRANTY AND SUPPORT

tectake products are manufactured with quality and durability in mind. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

For technical support, missing parts, or any other inquiries, please contact your retailer or tectake customer service directly. Contact information can typically be found on the packaging or the official tectake website.

© 2023 tectake. All rights reserved.

	<p>TecTake 402756 Home Gym Assembly and Exercise Guide</p> <p>Instruction manual for the TecTake 402756 home gym, covering assembly, safety precautions, and exercise guidance. Includes preparation tips and warm-up/cool-down routines.</p>
	<p>TecTake 400777 Semi-Automatic Washing Machine User Manual and Instructions</p> <p>This user manual provides comprehensive instructions for the TecTake 400777 semi-automatic washing machine, covering installation, operation, safety guidelines, and maintenance. Learn how to effectively wash and spin your clothes with this efficient appliance.</p>
	<p>TecTake Cabinet Assembly Instructions - Models 402483, 402938</p> <p>Comprehensive assembly guide for TecTake cabinets (models 402483, 402938), featuring a detailed parts list and step-by-step instructions with textual descriptions of diagrams.</p>
	<p>Roller Blind Installation Manual</p> <p>Comprehensive instruction manual for the installation of a roller blind, including parts list, assembly steps, and contact information for tectake.</p>
	<p>Assembly Instructions for TecTake Wardrobe (Models 402485, 402940)</p> <p>Comprehensive assembly instructions for TecTake wardrobe models 402485 and 402940, detailing parts list and step-by-step assembly guidance in multiple languages.</p>
	<p>tectake Roskilde 6-Person Camping Tent Assembly Instructions</p> <p>Assembly guide for the tectake Roskilde 6-person camping tent, including parts list and step-by-step instructions. Model FRN230414013-V1.</p>