



[Manuals.plus](#) /

› [Bush Furniture](#) /

› Bush Business Furniture Move 60 Series Electric Height Adjustable Standing Desk Instruction Manual

Bush Furniture Move 60 Series, M6S7230BWBK

Bush Business Furniture Move 60 Series Electric Height Adjustable Standing Desk

INSTRUCTION MANUAL

1. PRODUCT OVERVIEW

The Bush Business Furniture Move 60 Series Electric Height Adjustable Standing Desk is designed to enhance your workspace with ergonomic flexibility. This desk allows for seamless transitions between sitting and standing positions, promoting a healthier and more productive work environment. It features a sturdy construction, easy height adjustments, and safety mechanisms for reliable daily use.



Image 1: Bush Business Furniture Move 60 Series Electric Height Adjustable Standing Desk.

2. SAFETY INFORMATION

Please read all safety instructions before assembly and operation to prevent injury or damage to the product. Keep this manual for future reference.

- Ensure all components are securely fastened before use.
- Do not overload the desk. The maximum weight capacity is 200 pounds.
- Keep hands and objects clear of moving parts during height adjustment.
- Supervise children around the desk to prevent accidents.
- Use only the provided power cord and connect to a standard electrical outlet.
- **WARNING:** This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

3. PRODUCT COMPONENTS

Familiarize yourself with the main components of your electric height adjustable standing desk:



Image 2: Key components and features of the Move 60 Series desk.

- **Durable Thermally Fused Laminate Desktop:** Scratch and stain-resistant surface.
- **Welded 16-Gauge Steel Base:** Provides stability and support.
- **Control Panel:** For height adjustment and preset settings.
- **Anti-Collision Sensor:** Detects obstacles during movement and stops the desk.
- **Wire Management Grommets:** Two holes on the back corners for cable organization.

4. SPECIFICATIONS

| Feature | Detail |
|--------------------|-----------------------------|
| Model Number | M6S7230BWBK |
| Product Dimensions | 29.37"D x 71.02"W x 47.69"H |
| Minimum Height | 27 Inches |
| Maximum Height | 46.7 Inches |
| Weight Capacity | 200 Pounds |

| Feature | Detail |
|------------------------------|--------------------------------------------|
| Top Material | Engineered Wood (Thermally Fused Laminate) |
| Base Material | Steel |
| Lifting Mechanism | Electric |
| Assembly Required | Yes |
| Recommended Assembly Persons | 2 |
| UL Listed | Yes |




Image 3: Desk dimensions and height range.

5. SETUP AND ASSEMBLY

Assembly of the Move 60 Series desk is required. It is recommended that two people assemble the desk to ensure safety and ease of installation. All necessary hardware is typically included, but specific tools may be required (not included).

Assembly Steps:

1. Unpack all components and verify against the parts list in your included manual.
2. Attach the desk legs to the desktop following the detailed instructions in the provided assembly guide.
3. Connect the control panel and motor cables as indicated.
4. Place the desk in its desired location, ensuring it is near a standard electrical outlet.
5. Plug in the 10-foot power cord.

Refer to the detailed assembly instructions included in your product packaging for step-by-step guidance.

6. OPERATING INSTRUCTIONS

The Move 60 Series desk offers intuitive controls for height adjustment and personalized settings.

Height Adjustment:

- To raise the desk, press and hold the 'Up' arrow on the control panel.
- To lower the desk, press and hold the 'Down' arrow on the control panel.
- The desk will move smoothly between 27 inches and 46.7 inches.



Image 4: Desk control panel with digital height display.

Preset Settings:

The control panel allows you to save your preferred seated and standing heights for quick recall.

1. Adjust the desk to your desired height.
2. Press the 'M' button, then press one of the numbered preset buttons (e.g., '1' or '2') to save the current height.
3. To recall a saved height, press and hold the corresponding numbered preset button until the desk

reaches the saved position.

Anti-Collision Sensor:

The desk is equipped with an anti-collision sensor. If an obstruction is detected during height adjustment, the desk will automatically stop and reverse slightly to prevent damage.

Product Video:

Your browser does not support the video tag.

Video 1: Official product video showcasing the features and operation of the Bush Business Furniture Move 60 Collection.

7. MAINTENANCE

To ensure the longevity and appearance of your desk, follow these maintenance guidelines:

- Clean the desk surface with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the laminate finish.
- Regularly check all screws and fasteners to ensure they remain tight.
- Keep the electrical components dry and free from dust.
- Do not apply furniture polish containing wax to the laminate surface, as it cannot be absorbed and may leave residue.

8. TROUBLESHOOTING

If you encounter issues with your electric height adjustable desk, refer to the following common troubleshooting steps:

- **Desk Not Moving:** Check if the power cord is securely plugged into both the desk and the wall outlet. Ensure the outlet is functional.
- **Error Code on Display:** Consult your specific product manual for a list of error codes and their corresponding solutions. Often, unplugging the desk for 10-15 seconds and plugging it back in can reset the system.
- **Uneven Movement:** Ensure the desk is placed on a level surface. Check for any obstructions under the desk or along the legs.
- **Preset Not Working:** Ensure you are pressing and holding the preset button until the desk reaches the desired height. If the issue persists, try re-saving the preset height.
- **Interference with Electronics:** If electronic devices (e.g., graphics tablets) experience interference when the desk is in motion, consider shielding the device or the desk's control unit with aluminum foil to block electromagnetic interference.

If problems persist after attempting these steps, contact customer support.

9. WARRANTY AND SUPPORT

The Bush Business Furniture Move 60 Series Electric Height Adjustable Standing Desk is backed by a **5-Year Manufacturer's Warranty**. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical assistance, or any other inquiries, please contact Bush Furniture customer support. Refer to your product packaging or the Bush Furniture official website for the most current contact

information.

Online Support: Visit the Bush Furniture website.

Phone Support: Check your product documentation for the customer service number.