

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Estink](#) /

› [Estink Telescopic Wardrobe System / Retractable Closet Organizer Instruction Manual](#)

Estink Estinkq5a69tdvgb

Estink Telescopic Wardrobe System / Retractable Closet Organizer Instruction Manual

Model: Estinkq5a69tdvgb

1. PRODUCT OVERVIEW

The Estink Telescopic Wardrobe System is a versatile and space-saving retractable shelf designed to help organize various items in your home. Its adjustable length allows for flexible use in different spaces such as closets, wardrobes, kitchens, bedrooms, bathrooms, utility rooms, and garages.

This organizer features a mobile steel tube design and a PP material plate to prevent small items from falling through. It is designed for easy installation and durability.



Image: The Estink Telescopic Wardrobe System, showing its adjustable design and white finish.

2. SAFETY INFORMATION

- **Weight Capacity:** Do not exceed a maximum load capacity of 5 kg (11 lbs) on the shelf. Overloading can cause damage or injury.
- **Measurement:** Always measure the internal dimensions of your closet or cabinet before purchasing and installing to ensure proper fit.
- **Installation Force:** Avoid using excessive force during installation. This can damage the product or the surrounding furniture.
- **Stability:** Ensure the shelf is securely tightened and stable before placing items on it.

3. PACKAGE CONTENTS

Please check that all components are present before beginning installation.

- Telescopic Shelf Unit (main frame with rods)
- PP Material Plate (optional, for solid surface)
- Fan-shaped Screws / Adjustment Knobs

- End Caps (if separate)



Image: All components of the telescopic shelf system, including the main frame, adjustment screws, and end caps.

4. SETUP AND INSTALLATION

The installation process is designed to be straightforward. Follow these steps for a secure setup:

1. Step 1: Position the Divider

Place the telescopic shelf unit between the two desired boards or walls of your cabinet/wardrobe. Ensure it is level and at the correct height. Gently stretch the rod to approximately the proper length, allowing for slight tension.

2. Step 2: Fix the Fan-shaped Screw

Locate the fan-shaped screw (or adjustment knob) on one end of the shelf. Begin to fix it, but do not tighten it completely at this stage. Apply gentle force only.

3. Step 3: Tighten and Adjust

Adjust the length of the telescopic rods to fit snugly against the walls. Once positioned, tighten the adjustment knobs on both ends of the rack. Turn them clockwise until the shelf is firmly secured and stable. Ensure even pressure on both sides.

4. Step 4: Installation Complete

Verify that the shelf is stable and does not wobble. The installation is now complete. You can optionally place the PP material plate on top of the rods for a solid surface.



Image: Visual guide demonstrating the four steps of installing the telescopic shelf: positioning, fixing screws, tightening, and final placement.

Telescopic rods *can adjust* to the proper length to fit the closet or cupboard well.




Image: Diagram illustrating how the telescopic rods can be adjusted to fit various lengths within a cabinet or cupboard.

5. OPERATING INSTRUCTIONS

Once installed, the telescopic shelf functions as a stable storage surface. You can place various items on it, ensuring the total weight does not exceed 5 kg.

- **Adjusting Length:** The shelf's length can be adjusted between 38 cm and 68 cm. To adjust, loosen the adjustment knobs, extend or retract the rods to the desired length, and then re-tighten the knobs firmly.
- **Placement:** Utilize the shelf in closets, wardrobes, kitchen cabinets, under sinks, in bathrooms, or utility rooms to create additional storage layers.
- **Using the PP Plate:** For smaller items or to create a flat surface, place the provided PP material plate on top of the rods.



Image: The telescopic shelf used in different scenarios, including kitchen cabinets, under a sink, and in a wardrobe, demonstrating its versatility.

6. MAINTENANCE

To ensure the longevity and proper function of your Estink Telescopic Wardrobe System, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the shelf with a soft, damp cloth and mild detergent. Avoid abrasive cleaners or harsh chemicals that could damage the material.
- **Inspection:** Periodically check the adjustment knobs and the overall stability of the shelf. Re-tighten if necessary to maintain a secure fit.
- **Load Management:** Always adhere to the maximum weight capacity of 5 kg to prevent bending or damage to the rods and frame.

7. TROUBLESHOOTING

If you encounter any issues with your telescopic shelf, refer to the following common problems and solutions:

- **Shelf is not stable/wobbles:**
 - Ensure both adjustment knobs are fully and evenly tightened.
 - Check if the shelf is positioned correctly between two firm surfaces.
 - Verify that the length is not over-extended beyond its maximum stable range.
- **Difficulty adjusting length:**
 - Loosen the adjustment knobs completely before attempting to extend or retract the rods.
 - Ensure no debris is obstructing the telescopic mechanism.
- **Items falling through:**

- Use the provided PP material plate on top of the rods to create a solid surface for smaller items.

8. SPECIFICATIONS

Brand	Estink
Model Number	Estinkq5a69tdvgb
Color	White
Adjustable Length Range	38 cm - 68 cm (15 inches - 26.8 inches)
Depth	Approximately 24 cm (9.4 inches)
Maximum Weight Capacity	5 Kilograms (11 lbs)
Material	Polypropylene (PP)
Mounting Type	Built-in / Tension-mounted
Special Features	Durable, Space-saving, Telescopic Design

9. WARRANTY AND SUPPORT

Specific warranty information for the Estink Telescopic Wardrobe System is not provided in this manual. For warranty details, product support, or to report any issues, please contact the retailer or manufacturer directly through their official channels.

Please retain your proof of purchase for any warranty claims.