Maytag M1400BU

Maytag Digital Smart Fill Steam Iron & Vertical Steamer User Manual

Model: M1400BU



The Maytag Digital Smart Fill Steam Iron and Vertical Steamer in White/Blue, Model M1400BU, is designed for efficient and convenient garment care. This image shows the iron from a side angle, highlighting its sleek design and the Maytag branding.

PRODUCT OVERVIEW

The Maytag Smartfill Digital Iron with Removable Water Tank combines advanced technology with user-friendly features for comprehensive ironing. It heats to full temperature in approximately 55 seconds, and its unique removable water tank allows for refilling even while the iron is hot, saving valuable time. The digital interface offers four distinct heat settings, accommodating a wide range of fabrics from heavy cotton to delicate silk. This iron provides versatile steaming options including adjustable continuous steam, steam burst, vertical steam, and water spray functions to effectively smooth out wrinkles. Enhanced safety is provided by a 3-way auto-shutoff feature, and the pearl ceramic soleplate ensures smooth gliding for wrinkle-free results.

SETUP AND INITIAL USE

- Carefully remove the iron and all accessories from the packaging.
- Inspect the iron for any signs of damage. Do not use if damaged.
- Ensure all components listed in the packaging are present.

Filling the Water Tank

The Maytag M1400 iron features a removable water tank for convenient filling. It is recommended to use tap water for this iron, as it is designed to function optimally with the minerals present in tap water. Avoid using distilled water unless specified otherwise in future updates, as it may affect performance.

- 1. Ensure the iron is unplugged before filling.
- 2. Remove the water tank from the iron.
- 3. Fill the tank with tap water up to the MAX fill line.
- 4. Securely reinsert the water tank into the iron.



This image illustrates the removable water tank feature, showing it being filled directly from a faucet. This design allows for easy and quick refilling, even when the iron is hot, enhancing user convenience.

Power Connection

Plug the iron into a standard electrical outlet. The iron is designed to heat up quickly, reaching maximum temperature in less than a minute.

OPERATING INSTRUCTIONS

Temperature Control

The iron features a digital interface for precise temperature selection. Choose from four temperature settings suitable for various fabrics, from heavy cottons to delicate silks. Adjust the thermostat dial to the desired setting based on the fabric type.



A close-up view of the iron's digital interface, showing the temperature settings indicated by illuminated bars. This interface allows users to precisely select the heat level required for different fabric types.

Steam Functions

The Maytag M1400 offers multiple steam options for effective wrinkle removal:

- Adjustable Continuous Steam: Control the level of steam from low to high for consistent wrinkle removal.
- Steam Burst: Press the steam burst button for an extra powerful shot of steam to tackle stubborn wrinkles. Steam regenerates in just 3 seconds.
- Vertical Steam: Use the iron in an upright position to steam hanging garments, curtains, or upholstery.
- Water Spray: Utilize the water spray function to moisten fabrics, aiding in the removal of tough creases.

FULL STEAM AHEAD



VARIABLE STEAM

Control the level of steam from low to high.



VERTICAL STEAM

Steam garments and drapes while hanging.



WATER SPRAY

Remove tough wrinkles from your stubborn fabrics.

This composite image demonstrates the iron's versatile steam capabilities: variable steam control for different fabric needs, vertical steaming for hanging items like drapes, and a water spray function to moisten and smooth out tough wrinkles.



The image shows the iron gliding over fabric with visible steam, emphasizing its even steam distribution feature. This ensures consistent and effective wrinkle removal across the entire garment.

Pearl Ceramic Soleplate

The durable pearl ceramic soleplate is designed for smooth gliding over all fabric types, ensuring effortless ironing and wrinkle-free results.

SMOOTH GLIDE SOLEPLATE Durable ceramic soleplate glides smoothly and leaves your fabric wrinkle-free.

A detailed view of the iron's pearl ceramic soleplate, highlighting its smooth surface and steam holes designed for efficient heat and steam distribution, allowing for effortless gliding over fabrics.

SAFETY FEATURES

For enhanced safety, the Maytag M1400 iron is equipped with a 3-way auto-shutoff feature. This function automatically turns off the iron if it is left unattended for a period of time, whether resting horizontally or vertically, preventing potential hazards.



This image shows the iron in a resting position on an ironing board, illustrating the auto shut-off feature that activates when the iron is not in use, ensuring safety for clothes and surfaces.

MAINTENANCE

Cleaning the Soleplate

To maintain optimal performance of the pearl ceramic soleplate, clean it regularly. Ensure the iron is unplugged and completely cool before cleaning. Use a damp cloth with a mild detergent to wipe the soleplate. For stubborn residue, a non-abrasive cleaner specifically designed for iron soleplates can be used. Do not use abrasive scouring pads or harsh chemicals.

Self-Clean Function

The iron includes a self-clean feature to prevent mineral buildup. It is recommended to use this function approximately once a month, or more frequently if you use the steam function often or live in an area with hard water. Refer to the full

user manual for detailed instructions on performing the self-clean cycle.

Water Tank Care

Always empty the water tank after each use to prevent mineral buildup and prolong the life of your iron. Store the iron with an empty water tank.

TROUBLESHOOTING

If you encounter issues with your Maytag M1400 iron, please refer to the following common troubleshooting tips:

- Iron not heating: Ensure the iron is securely plugged into a working electrical outlet. Check the temperature setting
 on the digital interface.
- No steam or insufficient steam: Verify that the water tank is filled with tap water. Ensure the iron has reached the appropriate temperature setting for steam generation. Check if the steam control is set to the desired level.
- Water leaking from soleplate: This can occur if the temperature setting is too low for steam generation, causing water to drip instead of vaporize. Increase the temperature setting. Ensure the water tank is not overfilled.
- Iron not gliding smoothly: Clean the soleplate as described in the Maintenance section to remove any residue that might be causing friction.
- Auto-shutoff activating too frequently: Ensure the iron is being used actively. The auto-shutoff is a safety feature designed to activate when the iron is stationary for a period.

For more detailed troubleshooting or issues not listed here, please consult the full user manual or contact Maytag customer support.

SPECIFICATIONS

Feature	Detail
Brand	Maytag
Model Name	Digital Smart Fill Steam Iron & Vertical Steamer
Model Number	M1400BU
Color	White/Blue
Base Material	Pearl Ceramic Sole Plate
Wattage	1500-Watt
Water Tank Capacity	8.1 oz (approx. 240 ml)
Cord Length	8ft (360-degree swivel)
Auto Shut-off	3-way auto-shutoff
Product Dimensions	12.7"L x 5.4"W
Item Weight	3.53 pounds
UPC	850011521878

WARRANTY AND SUPPORT

Manufacturer's Warranty

The Maytag Digital Smart Fill Steam Iron & Vertical Steamer is backed by a manufacturer's 2-year warranty. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For product inquiries, technical assistance, or warranty service, please contact Maytag customer support. Refer to the contact information provided in your product packaging or visit the official Maytag website.

Full User Manual

A comprehensive user manual in PDF format is available for detailed instructions and information: Download User Manual (PDF)