

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Evolur](#) /
- › [Evolur Zoodle 3-in-1 High Chair Instruction Manual \(Model 254-LG\)](#)

Evolur Zoodle 3-in-1 High Chair (Model 254-LG)

Evolur Zoodle 3-in-1 High Chair Instruction Manual

Model: 254-LG | Brand: Evolur

1. INTRODUCTION

The Evolur Zoodle 3-in-1 High Chair is designed to provide a safe, comfortable, and adaptable feeding solution for your child. This manual contains important information regarding the assembly, operation, maintenance, and safety of your high chair. Please read it thoroughly before use and retain it for future reference. This high chair is suitable for infants from 6 months of age and converts into a toddler dining chair and a junior chair, ensuring extended usability as your child grows.

2. KEY FEATURES

- **Multi-Functionality:** Converts from a high chair to a toddler dining chair and a junior chair.
- **Safety First:** Equipped with a 5-point safety harness with padded shoulder straps and non-skid feet. Meets ASTM F-833-18 high chair standards.
- **Durable Construction:** Made with sturdy beechwood legs and hygienic food-grade PP material.
- **Easy to Clean:** Features a padded PU leather cushion that is lightweight, waterproof, and removable for quick cleaning. The double feeding trays are dishwasher-safe.
- **Adjustable Comfort:** Includes a 2-position adjustable double feeding tray and two adjustable footrests to accommodate your growing child.

3. SETUP AND ASSEMBLY

Before assembly, ensure all parts are present and undamaged. Refer to the included assembly guide for detailed step-by-step instructions. Assembly typically involves attaching the seat unit to the wooden legs and securing the footrests.



Figure 1: Assembled Evolur Zoodle High Chair in a kitchen setting.

AGE RANGE:

6 M+

PRODUCT WEIGHT:

15 LBS



Figure 2: Dimensions of the high chair and its convertible toddler seat.

3.1 Converting to Toddler Chair

The Zoodle high chair can be converted into a toddler chair by removing the longer leg extensions and attaching the shorter legs (conversion kit included). This allows the chair to be used for a longer period as your child grows.

Convertibility

2-in-1 high chair and toddler seat



Figure 3: High chair converting to a toddler seat.

4. OPERATING INSTRUCTIONS

4.1 Harness System

Always secure your child with the 5-point safety harness. Ensure the shoulder straps are properly adjusted and the buckle is securely fastened. The padded shoulder straps provide additional comfort.

Sturdy and dependable


Putting your needs first.



Dishwasher safe
removable meal tray



5 point safety harness
for extra security



Leatherette fabric
easily wipes clean

Figure 4: Detail of the 5-point safety harness and removable tray.

4.2 Tray Adjustment

The double feeding tray features two adjustable height positions. To adjust, locate the release mechanisms on either side of the tray, press, and slide the tray to the desired position. Ensure both sides are locked into place before use. The tray also includes a built-in cup holder.

4.3 Footrest Adjustment

The high chair is equipped with two footrests that can be adjusted to provide proper posture and comfort for your child as they grow. Consult the assembly guide for specific instructions on adjusting the footrests.

Zoodle

Versatile and stylish solution




Figure 5: Child using the high chair with tray.



Figure 6: Child using the toddler chair configuration.

5. MAINTENANCE AND CLEANING

Regular cleaning will help maintain the hygiene and longevity of your high chair.

- **Seat Cushion:** The padded PU leather seat cushion is removable. Wipe it clean with a damp cloth and mild soap. Allow to air dry completely.
- **Feeding Trays:** The double feeding trays are dishwasher-safe for convenient cleaning. Alternatively, they can be hand-washed with warm soapy water.
- **Frame and Legs:** Wipe the beechwood legs and plastic frame with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Harness:** The 5-point harness straps can be spot cleaned with a damp cloth and mild soap. Ensure they are dry before re-use.



Figure 7: Overview of easy-to-clean features.

6. TROUBLESHOOTING

- **Chair Instability:** Ensure all screws and fasteners are fully tightened. Refer to the assembly instructions to confirm correct leg and frame attachment.
- **Tray Difficulty:** If the tray is difficult to attach or remove, ensure the release mechanisms are fully engaged/disengaged and that no food debris is obstructing the tracks.
- **Harness Adjustment:** If the harness is too tight or too loose, adjust the straps according to your child's size. Ensure a snug but comfortable fit.

For any issues not covered here, please contact Evolur customer support.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	30"D x 25"W x 39"H

Item Model Number	254-LG
Maximum Weight Recommendation	33 Pounds
Material Type	Wood (Beechwood), PU Fabric
Care Instructions	Wipe with Damp Cloth
Number Of Items	1
Item Weight	15 Pounds
Is Portable	Yes

8. WARRANTY AND SUPPORT

Evolur products are designed with quality and safety in mind. For specific warranty information, please refer to the warranty card included with your purchase or visit the official Evolur website. For customer support, replacement parts, or further assistance, please contact Evolur directly through their website or the contact information provided in your product packaging.