

[Manuals.plus](#) /

› [Vianté](#) /

› Vianté Electric Kettle Model 100 Instruction Manual

Vianté 100

Vianté Electric Kettle with Infuser - Model 100 Instruction Manual

Brand: Vianté | Model: 100

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

1. Read all instructions carefully before use.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or the appliance in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
12. Do not use appliance for other than intended use.
13. Extreme caution must be used when moving an appliance containing hot water.
14. This appliance is for household use only.

PRODUCT OVERVIEW

The Vianté Electric Kettle Model 100 is designed for precise brewing of various hot beverages. It features a durable borosilicate glass body, 304 stainless steel components, and BPA-free plastics for safe and efficient operation.

Built for your daily rituals



Durable
borosilicate
glass body



Stainless steel
spout, heating
plate & infuser



Food-safe,
BPA-free lid
interior

*Boiling water only contacts glass
& stainless-steel components.



Image: The Vianté Electric Kettle, showcasing its durable borosilicate glass body, stainless steel spout, heating plate, and infuser. The design emphasizes food-safe and BPA-free materials.

SETUP

1. **Unpacking:** Carefully remove all packaging materials and inspect the kettle for any damage.
2. **Initial Cleaning:** Before first use, fill the kettle with water to the MAX line and boil. Discard the water. Repeat this process 2-3 times to remove any manufacturing residues.
3. **Placement:** Place the power base on a dry, flat, and stable surface away from the edge of the counter.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

OPERATING INSTRUCTIONS

General Operation

1. **Fill the Kettle:** Open the lid and fill the kettle with fresh, cold water. Ensure the water level is between the MIN (0.5L) and MAX (1.5L) marks.
2. **Place on Base:** Place the kettle securely onto its power base.
3. **Select Temperature:** Use the temperature control buttons on the base to select your desired temperature. Preset options are available for various tea types (White, Green, Oolong, Black) and French Press coffee.
4. **Start Heating:** Press the 'Start' button to begin the heating process. The indicator light will illuminate.
5. **Automatic Shut-Off:** The kettle will automatically shut off once the selected temperature is reached.

Using the Tea Infuser

The removable tea infuser allows for direct brewing of loose leaf tea or tea bags within the kettle.

1. **Add Tea:** Place your desired amount of loose leaf tea or tea bags into the stainless steel infuser.
2. **Insert Infuser:** Securely place the infuser into the kettle. Ensure it is properly seated.
3. **Fill Water:** Fill the kettle with water, ensuring it covers the infuser for proper steeping.
4. **Select Temperature & Brew:** Follow the general operating instructions to heat the water to the appropriate temperature for your tea.
5. **Remove Infuser:** Once brewing is complete, carefully remove the infuser using its handle.

Removable tea infuser

Place loose leaf tea or tea bags in the infuser to steep your tea directly in the kettle.



Image: A close-up view of the removable stainless steel tea infuser, demonstrating how loose leaf tea or tea bags can be placed inside for direct brewing.

Temperature Control and Keep Warm Function

The kettle offers precise temperature settings for optimal brewing and a 30-minute Keep Warm function.

- **Preset Temperatures:**

- White Tea: 175°F
- Green Tea: 175°F
- Oolong Tea: 195°F
- French Press/Pour-over Coffee: 200°F
- Black Tea/Boil: 212°F

- **Keep Warm:** After reaching the set temperature, activate the 'Keep Warm' function to maintain the water temperature for up to 30 minutes.



Perfect temperature

Preset temperature settings crafted for green tea, oolong, coffee prep & more.



WHITE TEA

175°F



GREEN TEA

175°F



OOLONG TEA

195°F



COFFEE

200°F



BLACK TEA

212°F

Image: The control panel of the kettle base, showing dedicated buttons for various temperature presets tailored for different types of tea and coffee, including a 'Keep Warm' option.

Keep Warm function

With the 30-minute Keep Warm function, your next cup will be just as warm & comforting as the last.



Image: The Vianté Electric Kettle with brewed tea inside, illustrating the 30-minute Keep Warm function which ensures subsequent cups remain warm and comforting.

Video Demonstrations

Video: This video provides essential information about the Vianté Electric Kettle, covering key features and considerations for new users.

Video: A detailed overview of the Vianté Kettle with Infuser, highlighting its design and functionality for brewing various beverages.

Video: This video demonstrates the Vianté Electric Kettle and Tea Infuser, showcasing its glass body and stainless steel components in action.

CARE AND MAINTENANCE

Proper care ensures the longevity and performance of your kettle.

- **Hand Wash Only:** The kettle and infuser should be hand washed. Do not immerse the power base in water.
- **Use Non-Abrasive Tools:** Use a soft sponge or cloth with mild detergent. Avoid abrasive scrubbers or harsh chemicals that can scratch surfaces.
- **Empty and Dry:** Always empty the kettle and dry it thoroughly after each use to prevent water spots and mineral buildup.

- **Descaling:** Over time, mineral deposits (scale) may build up, especially in hard water areas. To descale, fill the kettle with a solution of equal parts water and white vinegar. Boil the solution and let it sit for 5-10 minutes. Discard the solution and rinse thoroughly. Repeat if necessary.

Effortless cleaning



Wide opening
for easy access



Hand-wash
only



Use non-
abrasive tools



Empty & dry
after each use



Tap water contains minerals that can cause buildup or staining on the heating plate. Descale periodically for best performance.

Image: A person cleaning the Vianté Electric Kettle, demonstrating the wide opening for easy access and emphasizing hand-wash only with non-abrasive tools, and to empty and dry after each use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Kettle does not turn on.	Not plugged in; insufficient water; kettle not properly seated on base.	Ensure power cord is securely plugged in; fill water between MIN and MAX lines; ensure kettle is correctly placed on the power base.
Water not heating.	Temperature not selected; 'Start' button not pressed.	Select desired temperature; press the 'Start' button.

Problem	Possible Cause	Solution
Kettle shuts off too quickly.	Mineral buildup (scale).	Descale the kettle as per the 'Care and Maintenance' section.
Tea tastes bitter.	Water too hot for tea type; tea steeped too long.	Use appropriate temperature preset for your tea; reduce steeping time.

SPECIFICATIONS

- **Brand:** Vianté
- **Model Name:** 100 (Stainless Steel)
- **Capacity:** 1.5 Liters (44 fl.oz)
- **Power:** 1500 W
- **Material:** Borosilicate Glass, 304 Stainless Steel, BPA Free Plastics
- **Special Features:** Automatic Shut-Off, Built-In Infuser, Cordless, Digital Control, Temperature Control, 30-minute Keep Warm function
- **Product Dimensions (with base):** 15.47"L x 12.91"W x 8.07"H
- **Item Weight:** 2.99 pounds
- **Product Care Instructions:** Hand Wash
- **Country/Region of Origin:** Designed in Italy

Perfect fit for any kitchen

Fits beautifully on any counter: compact, modern, and surprisingly capable.

☑ 1.5L (44 fl.oz)

⚡ 1500 W power

↙ H: 8.7" W: 9" D: 7.6" (with base)
H: 7.7" W: 9" D: 5.5" (without base)



Image: The Vianté Electric Kettle displayed with its key specifications including 1.5L capacity, 1500W power, and physical dimensions with and without the base.

WARRANTY AND SUPPORT

Vianté is committed to delivering world-class flavor and service. Your temperature control electric kettle is backed by our commitment to your complete satisfaction.

- **Standard Warranty:** Every product comes with a standard 1-year warranty.
- **Extended Warranty:** Register your purchase to automatically extend your warranty for an additional year.
- **Contact Support:** For any quality issues or support needs, please contact Vianté Products customer service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question