

[Manuals.plus](#) /

› [SoundPEATS](#) /

› SoundPEATS Q30 HD Bluetooth Earphones User Manual

SoundPEATS Q30 HD

SoundPEATS Q30 HD Bluetooth Earphones User Manual

Model: Q30 HD

INTRODUCTION

Welcome to the SoundPEATS Q30 HD Bluetooth Earphones User Manual. This guide provides comprehensive instructions to help you set up, operate, and maintain your new earphones. Designed for high-quality audio and active lifestyles, the Q30 HD features aptX HD support, IPX7 waterproofing, and CVC8.0 noise cancellation for clear calls.

SAFETY INFORMATION

For your safety and to ensure the longevity of your SoundPEATS Q30 HD earphones, please observe the following:

- Do not use a charging current exceeding 5V/1A.
- Avoid using rapid charging devices, as this may damage the battery or earphones.

PACKAGE CONTENTS

Your SoundPEATS Q30 HD package includes the following items:

- SOUNDPEATS Q30 HD Bluetooth Earphones
- Micro USB Charging Cable
- Eartips x 5 pairs (XS/S/M/L/XL) - M size pre-installed
- Ear Hooks x 3 pairs (S/M/L) - M size pre-installed
- Storage Bag
- Cable Buckles x 2
- Cord Clips x 2
- User Guide (this manual)



パッケージ内容

SOUNDPEATS Q30 HD Bluetoothイヤホン
充電用 Micro USBケーブル
イヤピース×5ペア (XS/S/M/L/XL) ※初期装着M
イヤーフック×3ペア (S/M/L) ※初期装着M
収納バッグ

ケーブル留めバックル×2
コードクリップ×2
ユーザーガイド(取扱説明書)

Earphone Components



Image: Exploded view illustrating the 10mm dynamic driver.

The SoundPEATS Q30 HD earphones are equipped with high-performance 10mm dynamic drivers to deliver rich bass and clear audio. The robust construction ensures durability and sound fidelity.

Inline Remote Control



Image: Inline remote control with multi-function, volume up/next track, and volume down/previous track buttons.

The inline remote provides easy access to various functions, including power, volume, track control, and call management.

1. Charging the Earphones

Before first use, fully charge your earphones. A full charge takes approximately 2 hours and provides up to 14 hours of playback.

1. Connect the Micro USB charging cable to the charging port on the inline remote.
2. Connect the other end of the cable to a USB power adapter (5V/1A recommended) or a computer USB port.
3. The LED indicator will show charging status.



Image: Earphones indicating 14 hours of continuous use after charging.

2. Wearing the Earphones

For optimal sound quality and comfort, choose the correct eartips and ear hooks.

1. Select the eartips (XS/S/M/L/XL) that provide a secure seal in your ear canal.
2. Choose the ear hooks (S/M/L) that fit snugly against your ear's concha to prevent the earphones from falling out during activity.
3. Insert the earphones into your ears and adjust the cable for a comfortable fit.

aptX HDコーデックの特徴は？

コーデックの名前	SBC	AAC	aptX	aptX HD	aptX LL (Low Latency)	aptX adaptive	LDAC
特徴	遅延を感じる標準的な音質	SBCより遅延が少ないデータの変化が少なくSBCよりも高音質	SBC,AACより遅延が少ないCD音源相当(48kHz/16bit)の高音質再生が可能	ハイレゾ相当(48kHz/24bit)の高音質再生が可能	aptXよりさらに遅延が少ない40ミリ秒未満という低遅延を実現(SBCの遅延は170 ~ 270ミリ秒)	ハイレゾ相当(96kHz/24bit)の高音質再生が可能状況に応じて音質を切り替えて途切れや遅延を回避	ハイレゾ相当(96kHz/24bit)の高音質再生が可能
簡単な説明	A2DP対応のワイヤレス製品すべてが必ずSBCに対応している	iPhoneで主に対応しているコーデック	Androidで主に対応しているコーデック	SBC,AAC,aptXを上回る高音質コーデック	音楽ゲームができるほどの低遅延コーデック	aptX HDを上回る高音質コーデックaptX LLほどではないが低遅延	Android8.0以降で主に対応しているaptX HDを上回る高音質コーデック

Image: Various sizes of eartips and ear hooks for a customized fit.

3. Bluetooth Pairing

Follow these steps to pair your earphones with a Bluetooth-enabled device:

1. Ensure the earphones are turned off.
2. Press and hold the multi-function button for approximately 3-5 seconds until the LED indicator flashes red and blue alternately, indicating pairing mode.
3. Activate Bluetooth on your device (smartphone, tablet, etc.) and search for 'SOUNDPEATS Q30 HD' in the list of available devices.
4. Select 'SOUNDPEATS Q30 HD' to connect. Once connected, the LED indicator will flash blue slowly.

OPERATING INSTRUCTIONS

Basic Functions

- **Power On:** Press and hold the multi-function button for 3 seconds.
- **Power Off:** Press and hold the multi-function button for 3 seconds.
- **Play/Pause:** Press the multi-function button once.
- **Volume Up:** Press the '+' button once.
- **Volume Down:** Press the '-' button once.
- **Next Track:** Press and hold the '+' button for 2 seconds.
- **Previous Track:** Press and hold the '-' button for 2 seconds.

Call Management

- **Answer/End Call:** Press the multi-function button once.
- **Reject Call:** Press and hold the multi-function button for 1.5 seconds.
- **Switch Call (between earphones and phone):** Press and hold the multi-function button for 1.5 seconds during a call.
- **Mute/Unmute Call:** Double-press the multi-function button during a call.

Voice Assistant

- **Activate Voice Assistant:** Double-press the multi-function button when not on a call.

MAINTENANCE

- **Cleaning:** Gently wipe the earphones with a soft, dry cloth. Do not use harsh chemicals.
- **Storage:** When not in use, the magnetic earbuds can be attached together to prevent tangling and make storage convenient. Store in the provided storage bag.



Image: Magnetic earbuds feature for tangle-free storage.

- **Waterproofing (IPX7):** The earphones are IPX7 waterproof, meaning they can withstand sweat and light rain. Do not submerge them in water or expose them to high-pressure water jets. Ensure the charging port cover is securely closed.



Image: Earphone with water droplets, showcasing IPX7 waterproof rating.

TROUBLESHOOTING

If you encounter any issues with your earphones, please refer to the following common solutions:

- **Cannot Power On:** Ensure the earphones are fully charged.
- **Cannot Pair:**
 - Ensure earphones are in pairing mode (red and blue LED flashing alternately).
 - Turn off Bluetooth on other devices that might be connected.
 - Try turning the earphones off and on again, then re-enter pairing mode.
- **No Sound:**
 - Check volume levels on both earphones and the connected device.
 - Ensure earphones are properly paired and connected to your device.
 - Try playing different audio sources.
- **Poor Call Quality (CVC8.0):** While CVC8.0 reduces ambient noise, extreme noise environments may still affect call clarity. Ensure the microphone is not obstructed.

SPECIFICATIONS

Brand	SoundPEATS
Model	Q30 HD
Bluetooth Version	5.0
Audio Codecs	AAC, aptX, aptX HD
Chipset	Qualcomm QCC3034
Driver Size	10mm Dynamic
Playback Time	Up to 14 hours
Charging Time	Approx. 2 hours
Waterproof Rating	IPX7
Noise Cancellation	CVC8.0 (for calls)
Weight	15 grams
Charging Port	Micro USB
Compatible Devices	iPhone, Android smartphones, PCs, iPads, iPods

絡まることなく収納便利 マグネット式ワイヤレスイヤホン

耳から外しているときにイヤホンのヘッド同士がぶつからなく、カバンなどに入れて携帯する際にも、イヤホンのヘッド同士をくっつけておけばコードが絡みにくくなります。

マグネットなし

コードが絡みやすく、収納にも大変



マグネット付き

首にかけて持ち運ぶのにもカバンに入れて携帯するときにも便利




Image: Comparison table of various audio codecs.

WARRANTY AND SUPPORT

SoundPEATS Q30 HD earphones come with a **1-year manufacturer's warranty**. For support, please contact SoundPEATS customer service through their official website or the retailer where you purchased the product. Please retain your proof of purchase for warranty claims.

© 2024 SoundPEATS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question