

[Manuals.plus](#) /

› [Sunnyglade](#) /

› Sunnyglade 10x10ft Cantilever Patio Umbrella Instruction Manual

Sunnyglade CP

Sunnyglade 10x10ft Cantilever Patio Umbrella Instruction Manual

Model: CP

INTRODUCTION

This manual provides instructions for the assembly, operation, maintenance, and troubleshooting of your Sunnyglade 10x10ft Cantilever Patio Umbrella. Please read this manual thoroughly before use and retain it for future reference. The Sunnyglade 10x10ft Cantilever Patio Umbrella is designed to provide a wide shading area for outdoor spaces. It features a durable 250/gsm polyester fabric with PA coating, offering fade resistance, sun protection (blocking up to 99% of harmful UV rays), and waterproofing. The umbrella includes a 360-degree rotation mechanism and a 4-level adjustable tilt system for optimal shade positioning.



Image: Overview of the Sunnyglade 10x10ft Cantilever Umbrella, highlighting its 10x10ft size, sturdy ribs, 100% polyester fabric with PA coating, 360-degree rotation mechanism, and 4 adjustable heights.

SAFETY INFORMATION

- **Base Requirement:** An umbrella base is NOT included with this product and is required for safe operation. This outdoor umbrella cannot stand alone. Ensure a proper, heavy base (e.g., 4x 3x3 patio pavers or a 200-220lb sand/water-filled base) is used to secure the umbrella. Failure to do so can result in injury or property damage, especially in windy conditions.
- **Wind Conditions:** Always close the umbrella canopy when windy or when not in use to prevent damage to the umbrella and surrounding property. Even slight breezes can cause instability if the umbrella is not adequately secured or closed.
- **Assembly:** While assembly is generally straightforward, some steps may benefit from two people due to the weight and size of components.
- **Clearance:** Ensure adequate clearance around the umbrella when rotating or tilting to avoid obstructions.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- Umbrella Canopy with Ribs
- Main Pole Assembly
- Cross Base
- Crank Handle
- Assembly Hardware (bolts, washers, nuts)
- User Manual (this document)

SETUP AND ASSEMBLY

Assembly typically takes a few minutes with the included tools. Having a second person for certain steps is recommended.

1. **Prepare the Base:** Place the cross base in your desired location. Secure it with a suitable, heavy umbrella base (not included). Ensure the base is stable and level.
2. **Attach Main Pole:** Carefully lift the main pole assembly and insert it into the designated slot on the cross base. This step is easier with two people. Secure the pole to the base using the provided hardware.
3. **Attach Canopy:** Unfold the umbrella canopy and attach it to the main pole's cantilever arm. The four corners of the canopy are designed with innovative long zippers for easy installation and secure attachment.
4. **Verify Stability:** Once assembled, ensure all connections are tight and the umbrella is stable within its weighted base.

10x10ft Patio Offset Hanging Umbrella Deluxe Outdoor Cantilever Umbrella




Image: Detailed view of the umbrella's components, including the handle design and crank system, 100% polyester fabric, sturdy construction, innovative zipper design, and the mechanism to freely adjust sunshade direction and angle.

OPERATING INSTRUCTIONS

Opening and Closing the Umbrella

- To open the umbrella, turn the crank handle clockwise until the canopy is fully extended.
- To close the umbrella, turn the crank handle counter-clockwise until the canopy is fully retracted. Always close the umbrella when not in use or during windy conditions.

360-Degree Rotation

- To rotate the umbrella, step on the pedal located at the base of the main pole.
- While holding the pedal down, gently twist the main pole to rotate the umbrella canopy 360 degrees horizontally to your desired position.
- Release the pedal to lock the umbrella in place.




Image: Diagram illustrating the 360-degree rotation capability of the umbrella, allowing for flexible shade adjustment.

Adjustable Tilt System

- The umbrella features a 4-level adjustable tilt operation system.
- Locate the handle on the main pole that controls the tilt.
- Adjust the handle to change the angle of the canopy, providing maximum shade from the sun throughout the day.



Image: Diagram showing the umbrella's 4 adjustable height settings, allowing the canopy to be positioned at different levels to resist sunlight from various angles.

MAINTENANCE

- **Cleaning:** Wipe the umbrella canopy and frame with a dry cloth to remove dust and debris. For stubborn dirt, use a mild soap solution and a soft brush, then rinse thoroughly and allow to air dry completely before closing.
- **Weather Protection:** Always close the canopy when not in use, especially during strong winds, heavy rain, or snow, to prolong the life of the umbrella. Consider using a protective cover during off-season storage.
- **Fabric Care:** While the polyester fabric is fade-resistant, prolonged exposure to intense sunlight can still cause gradual fading over many years. Applying a fabric protector (e.g., Scotchgard) can enhance water repellency and UV resistance.
- **Hardware:** Periodically check all bolts and connections to ensure they remain tight.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Umbrella is unstable or sways excessively.	Insufficiently weighted base; strong winds.	Ensure a heavy, properly weighted base is used. Close the umbrella in windy conditions.
Crank mechanism is stiff or difficult to operate.	Lack of lubrication; debris in mechanism.	Apply a silicone-based lubricant to moving parts. Clean any visible debris.

Problem	Possible Cause	Solution
Canopy fabric appears faded over time.	Prolonged exposure to direct sunlight.	This is normal wear over extended periods. Consider using a protective cover when not in use or during off-season.
Missing or damaged parts upon arrival.	Shipping damage or packaging error.	Contact customer support immediately with details and photos of the issue.

SPECIFICATIONS

- **Brand:** Sunnyglade
- **Model Number:** CP
- **Canopy Size:** 10 x 10 ft (Square)
- **Canopy Diameter:** 120 Inches
- **Product Dimensions:** 304.8 x 0.03 x 268.22 cm (W x H); 25.63 kg
- **Canopy Material:** 250/gsm Polyester with PA Coating
- **Frame Material:** Aluminum
- **Shaft Material:** Aluminum
- **Handle Material:** Aluminum
- **Opening Mechanism:** Crank Lift
- **Umbrella Tilt Mechanism:** Rotational Tilt (4-level adjustable)
- **Rotation:** 360-degree horizontal rotation
- **Special Features:** Adjustable Height, Multifunctional Vent Design
- **UPC:** 747356582476



Image: Diagram showing the key dimensions of the 10x10ft Sunnyglade Cantilever Umbrella, including canopy width, length, and overall height.

WARRANTY AND SUPPORT

This product is eligible for return or refund within 30 days of receipt, subject to the retailer's return policy. For any questions, missing parts, or support needs, please contact Sunnyglade customer service through your purchase platform or the contact information provided at the time of purchase. When contacting support, please have your model number (CP) and purchase details ready.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question