Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PHI VILLA Swivel-A

PHI VILLA Outdoor Metal Swivel Chairs User Manual

Model: Swivel-A

1. Important Safety Information

Please read and understand all instructions before assembling and using this product. Failure to follow these instructions may result in injury or product damage. Keep this manual for future reference.

- **Weight Capacity:** Do not exceed the maximum load capacity of 300+ lbs per chair. Exceeding this limit may compromise stability and cause damage or injury.
- **Assembly:** Ensure all parts are correctly assembled and all fasteners are securely tightened before use. Do not fully tighten all screws until all components are loosely fitted.
- **Stability:** Always ensure the chair is placed on a flat, stable surface to prevent tipping.
- **Children:** Keep children away from the assembly area. Small parts can be a choking hazard. Supervise children when they are using the chairs.
- **Sharp Edges:** Exercise caution during assembly and handling to avoid contact with any potential sharp edges.
- **Outdoor Use:** While designed for outdoor use, prolonged exposure to extreme weather conditions (heavy rain, snow, strong winds) may reduce product lifespan. Consider covering or storing chairs during harsh weather.

2. Product Overview

The PHI VILLA Outdoor Metal Swivel Chairs are designed for comfort and durability in outdoor settings. This set includes two chairs featuring a paperclip back design, a sturdy metal frame, and comfortable padded cushions. The chairs offer a smooth 360-degree swivel function for enhanced usability.



Image 2.1: Front view of the two PHI VILLA outdoor metal swivel chairs.

Product Dimensions:

Full Height: 35.04 inches

Seat Width: 21.45 inches

Seat Depth: 25 inches

Load Capacity: 300+ lbs



Image 2.2: Detailed dimensions of the swivel chair.

3. Setup and Assembly

Assembly of the PHI VILLA swivel chairs is designed to be straightforward. It is recommended to have two people for easier assembly. All necessary hardware and tools are typically included.

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches. Verify all parts are present against the included parts list.
2. **Attach Seat to Backrest:** Align the seat frame with the backrest. Insert the appropriate bolts through the pre-drilled holes. Hand-tighten the bolts initially.
3. **Attach Armrests:** Connect the armrests to both the seat and backrest using the designated hardware. Again, hand-tighten only.
4. **Install Swivel Base:** Secure the swivel mechanism to the underside of the seat frame. Ensure it is oriented correctly.

5. **Final Tightening:** Once all components are loosely assembled, place the chair upright on a level surface. Systematically tighten all bolts using the provided tool. Ensure all connections are firm and secure, but do not overtighten.
6. **Place Cushions:** Position the padded cushions onto the chair seat.

Important Note: Do not fully tighten any screws until all parts are in place and aligned. This allows for minor adjustments and prevents misalignment during assembly.

4. Operating Instructions

These chairs are designed for comfortable and dynamic outdoor seating.

- **Swivel Function:** The chair features a smooth 360-degree swivel. To rotate, simply shift your weight and turn the chair in the desired direction. Avoid forcing the swivel mechanism if it encounters resistance.
- **Rocker Function:** The base is designed to allow for a gentle rocking motion. Lean back slightly to engage the rocking feature.
- **Seating:** Sit centrally on the seat cushion. Avoid standing on the chair or using it as a step stool.



Image 4.1: The 360-degree swivel base and comfortable cushion.

5. Maintenance

Regular maintenance will help preserve the appearance and extend the lifespan of your PHI VILLA outdoor chairs.

Frame Care:

- **Cleaning:** Wipe clean with a damp cloth and mild soap. Rinse thoroughly with clean water and dry completely to prevent water spots and rust. Avoid harsh chemicals or abrasive cleaners.
- **Rust Prevention:** The metal frame features a rust-resistant powder coating and electrophoretic coating. Inspect the frame periodically for any chips or scratches in the coating. Touch up any damaged areas with appropriate outdoor metal paint to prevent rust.
- **Weather Protection:** While weather-resistant, it is advisable to cover the chairs or store them indoors during prolonged periods of non-use or severe weather conditions (e.g., heavy rain, snow, freezing temperatures, strong UV exposure).



Image 5.1: Explanation of the powder E-coating frame for rust resistance.

Cushion Care:

- **Cleaning:** The cushions are water-resistant. Spot clean with a mild soap solution and a soft brush or cloth. Rinse thoroughly and allow to air dry completely before use or storage.
- **Storage:** To maintain their appearance and prolong their life, store cushions indoors during inclement weather or when not in use for extended periods.

6. Troubleshooting

This section addresses common issues you might encounter with your swivel chairs.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Chair wobbles or feels unstable.	Loose bolts; uneven surface.	Check and tighten all assembly bolts. Ensure the chair is on a flat, level surface.
Swivel mechanism is stiff or noisy.	Lack of lubrication; debris in mechanism.	Clean the swivel mechanism and apply a silicone-based lubricant. Ensure no debris is obstructing movement.
Rust spots appear on the frame.	Damage to protective coating; prolonged moisture exposure.	Clean the affected area, remove loose rust, and apply rust-inhibiting primer and outdoor-grade paint. Ensure chairs are dried after rain.
Cushions appear faded or worn.	Prolonged exposure to direct sunlight or harsh weather.	Store cushions indoors or cover chairs when not in use to minimize exposure. Consider replacing cushions if severely worn.

7. Specifications

Brand: PHI VILLA

Model Name: Swivel

Item Model Number: Swivel-A

Color: Paperclip Back Design (Black frame, Beige cushions)

Product Dimensions: 22"D x 22"W x 35"H

Seat Depth: 25 inches

Material: Metal (frame), Polyester (cushion fill)

Finish Type: Powder Coated

Special Feature: Sturdy, 360-degree Swivel, Rocker

Indoor/Outdoor Usage: Outdoor

Recommended Uses: Dining, Patio, Garden, Bistro

Unit Count: 2.0 Count (per set)

Product Care Instructions: Wipe Clean

8. Warranty and Support

For specific warranty information regarding your PHI VILLA Outdoor Metal Swivel Chairs, please refer to the documentation included with your purchase or contact PHI VILLA customer service directly. Warranty terms and conditions may vary.

If you require assistance with assembly, parts, or have any questions about your product, please contact PHI VILLA customer support. Contact information can typically be found on the manufacturer's website or on your purchase receipt.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08928LWMJ

More documents and user manuals: **https://manuals.plus/**