

- Manuals.plus /
- › MuGo /
- › MuGo N919 Portable Bluetooth Speaker Instruction Manual

MuGo N919

MuGo N919 Portable Bluetooth Speaker User Manual

Model: N919

1. INTRODUCTION

Thank you for choosing the MuGo N919 Portable Bluetooth Speaker. This speaker is designed to deliver high-quality audio with advanced features for various environments. It features dual 20W drivers, a 5200 mAh battery for extended playback, and robust water, dust, and shock resistance. This manual provides essential information for setting up, operating, and maintaining your speaker.



Image: The MuGo N919 Portable Bluetooth Speaker, showcasing its compact and rugged design.

2. PACKAGE CONTENTS

Please check the box for the following items:

- MuGo Bluetooth Speaker (N919)
- Micro USB Charging Cable
- 3.5mm Audio Cable
- Mountaineering Buckle Hook
- User Guide (This document)

3. PRODUCT OVERVIEW

Familiarize yourself with the speaker's ports and controls:



Image: Detailed view of the MuGo N919 speaker's control panel and port section, showing the charging indicator, Micro Input, AUX port, USB Output, NFC area, and control buttons.

Control Buttons:

- **Pre/Volume Down (-):** Short press for previous track, long press to decrease volume.
- **BT Indicator:** LED light indicating Bluetooth status.
- **ON/OFF/Play/Pause/Phone:** Power on/off, play/pause music, answer/end calls.
- **Next/Volume Up (+):** Short press for next track, long press to increase volume.
- **Hook:** Attachment point for the mountaineering buckle hook.

Ports:

- **Charging Indicator Light:** Shows charging status.
- **Micro Input:** For charging the speaker.
- **AUX:** 3.5mm audio input for wired connection.
- **USB Output:** For using the speaker as a power bank.
- **NFC:** Near Field Communication area for quick pairing.

4. SETUP

4.1 Initial Charging

Before first use, fully charge your MuGo N919 speaker. Connect the Micro USB charging cable to the speaker's Micro Input port and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator light will show the charging status. A full charge can provide up to 24 hours of playback.



Image: The MuGo N919 speaker highlighting its 5200mAh battery capacity, providing up to 24 hours of playback.

4.2 Powering On/Off

- **To Power On:** Press and hold the Power button (ON/OFF/Play/Pause/Phone) for a few seconds until you hear an audible prompt and the BT indicator light illuminates.
- **To Power Off:** Press and hold the Power button again for a few seconds until you hear an audible prompt and the BT indicator light turns off.

5. OPERATING INSTRUCTIONS

5.1 Bluetooth Pairing

1. Ensure the speaker is powered on and the BT indicator light is flashing, indicating it's in pairing mode.
2. On your smartphone or Bluetooth-enabled device, go to the Bluetooth settings.
3. Search for available devices and select "MuGo N919" (or similar name) from the list.
4. Once connected, the BT indicator light will become solid, and you will hear a confirmation sound.
5. The speaker can connect to your smartphone within a range of up to 10 meters.

5.2 NFC Pairing (If your device supports NFC)

1. Ensure NFC is enabled on your smartphone.
2. Tap your smartphone gently against the NFC area on the speaker.
3. Confirm the pairing request on your smartphone. The speaker will connect in seconds.

5.3 AUX Mode

To connect a device without Bluetooth, use the included 3.5mm audio cable. Plug one end into the speaker's AUX port and the other end into your audio device's headphone jack. The speaker will automatically switch to AUX mode.

5.4 Hands-Free Calling

When connected to your smartphone via Bluetooth, you can answer incoming calls directly through the speaker:

- **Answer Call:** Short press the Power button.
- **End Call:** Short press the Power button during a call.
- **Reject Call:** Long press the Power button when a call comes in.

5.5 Power Bank Function

The MuGo N919 speaker can serve as an emergency power bank to charge your mobile devices.

1. Connect your phone or tablet's charging cable to the speaker's USB Output port.
2. The speaker will begin charging your device. Note that this function will consume the speaker's battery.

Power bank function with 5200mAh battery

CHARGE

mobile devices from a built-in power bank



Image: The MuGo N919 speaker connected via USB to a smartphone, demonstrating its power bank functionality.

6. MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Water Resistance:** The speaker is waterproof, dustproof, and shockproof. However, avoid prolonged submersion in water or exposing it to extreme conditions to maintain its integrity. Ensure the port cover is securely closed when near water.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in use for extended periods. Store in a cool, dry place.
- **Storage:** When not in use, store the speaker in a dry environment away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

7.1 No Power

- Ensure the speaker is fully charged.
- Check the charging cable and power adapter for damage.

7.2 Cannot Pair via Bluetooth

- Make sure the speaker is in pairing mode (BT indicator flashing).

- Ensure Bluetooth is enabled on your device and it is within 10 meters of the speaker.
- Forget the speaker from your device's Bluetooth list and try pairing again.
- Restart both the speaker and your device.

7.3 No Sound or Low Volume

- Increase the volume on both the speaker and your connected device.
- Ensure the speaker is properly connected via Bluetooth or AUX cable.
- If using AUX, ensure the cable is fully inserted and not damaged.
- If distortion occurs at maximum volume, slightly reduce the volume.

7.4 Speaker Does Not Switch Devices Easily

- Disconnect the speaker from the currently connected device before attempting to pair with a new one.
- Power the speaker off and then on again to reset its connection state.

8. SPECIFICATIONS

Brand:	MuGo
Model Name:	N919
Maximum Speaker Output Power:	20 Watts
Connectivity Technology:	Bluetooth, NFC, USB
Audio Output Mode:	Stereo
Speaker Type:	Outdoor
Other Features:	Enhanced Bass, USB Connectivity, Built-in Microphone, Wireless
Recommended Product Uses:	For smartphone or tablet
Subwoofer Diameter:	6.6 Centimeters
Color:	N919
Waterproof:	Yes
Maximum Range:	10 Meters
Control Method:	Voice (likely refers to voice assistant pass-through)
Speaker Size (Driver):	7 Centimeters
Water Resistance Level:	Waterproof
Bluetooth Range:	10 Meters
Specific Product Uses:	Sports and Exercise, Home, Travel
Battery Playback Time:	Up to 24 hours
Battery Capacity:	5200 Milliamp Hours
Manufacturer:	BT-SP
Item Dimensions (D x W x H):	6.6 x 17 x 6.6 centimeters

Compatible Devices:	Smartphone, Tablet
Power Source:	Battery
Number of Batteries:	1 Lithium Polymer (included)
Audio Driver Type:	Dynamic Driver

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the seller directly. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B08931B1VR>

More documents and user manuals: <https://manuals.plus/>