

[Manuals.plus](#) /

› [KEiID](#) /

› KEiID KD-S01 Alarm Clock Radio Speaker User Manual

KEiID KD-S01

KEiID KD-S01 Alarm Clock Radio Speaker User Manual

Model: KD-S01

INTRODUCTION

The KEiID KD-S01 is a versatile and compact audio system designed for home use, offering multiple functionalities including an alarm clock, FM radio, Bluetooth speaker, USB MP3 player, and night light. It can be used as a desktop unit or wall-mounted, providing a comprehensive audio and time-keeping solution for various living spaces.

This manual provides detailed instructions for setting up, operating, and maintaining your KD-S01 unit to ensure optimal performance and longevity.

PACKAGE CONTENTS

Please check the package carefully to ensure all items are present:

- KEiID KD-S01 Main Unit
- Remote Control (2*AAA Batteries not included)
- FM Antenna
- 12V 5A DC Power Adapter
- User Manual


Packing Details :




Remote control
2*AAA Battery needed



Magnetic antenna



User Manual



12V5A DC power adapter

Image: Contents of the KD-S01 package, showing the main unit, remote control, FM antenna, power adapter, and user manual.

PRODUCT FEATURES

- Minimalist desktop & wall mountable design.
- Multi-functional: Digital clock, calendar, dual alarms, nightlight, anion air purification, USB MP3 player, Headphone connection, remote control.
- RMS 2x 5W HiFi speakers for clear sound.
- Bluetooth 5.0 receiver for wireless audio streaming.
- Full band FM radio with up to 30 presets.
- USB and 3.5mm line-in playback options.
- 12H/24H LED digital clock & calendar with dual alarms.
- Adjustable alarm volume with FM radio or Buzz tone options.
- Snooze function (10 minutes).
- Sleep timer (30-180 minutes auto-off).

- 3 Brightness levels for night light with 3 levels auto-off timer.
- Built-in Anion air purifier.

One for All Media Resources

Retro look Furniture style Solidly built



15.8" (width), 5.1" (height), 7.9" (depth); 10 lb



Slot-in
CD player



Bluetooth
wireless streaming



FM radio



3.5mm
AUX line in



USB flash drive
playback



Remote
control



Dimmer/
night mode



Random/Repeat
play options



Bass/Treble
adjustable

AM radio does not work. Please do not buy if you need AM radio function.

Image: Front view of the KD-S01 unit, highlighting its display and control panel.

SETUP

1. Power Connection

1. Connect the 12V 5A DC power adapter to the DC-12V power input port on the back of the KD-S01 unit.
2. Plug the power adapter into a standard wall outlet.
3. Locate the power switch on the back of the unit and turn it ON.

2. FM Antenna Connection

- Connect the provided FM antenna to the FM/AM antenna connect port on the back of the unit.
- Extend the antenna fully and position it for optimal FM signal reception.

3. Remote Control Setup

- Insert two AAA batteries (not included) into the remote control, observing the correct polarity.



Image: Rear panel of the KD-S01, indicating the power input, power switch, and FM/AM antenna connection.

OPERATING INSTRUCTIONS

Basic Operation

- **Power On/Off:** Press the **Power** button on the remote control or the unit to turn the device on or off.
- **Volume Control:** Use the **Volume knob** on the unit or the **+/-** buttons on the remote to adjust the volume.
- **Mode Selection:** Press the **SRC** button on the unit or the **Mode** button on the remote to cycle through available modes: FM Radio, Bluetooth, USB, AUX.

Setting the Clock and Calendar

The clock and calendar functions are primarily controlled via the remote. Refer to the detailed instructions in the included user manual for specific button sequences.

- Use the **Setup** button on the remote to enter the settings menu.
- Navigate using the arrow keys and confirm selections with the **OK** button.
- Set time format (12H/24H), current time, and date.

Alarm Settings

- The unit supports dual alarms. Access alarm settings via the remote control.
- Set alarm time, alarm source (FM radio or buzzer), and desired volume.
- **Snooze Function:** When the alarm sounds, press the **Snooze** button (usually the large central button on the

remote) to temporarily silence it for 10 minutes.

- **Stopping Alarm:** To turn off the alarm completely, press the **Power** button or the designated alarm off button on the remote.

FM Radio Operation

- Switch to FM mode using the **SRC** or **Mode** button.
- **Auto Scan:** Press and hold the **AST** button to automatically scan and save available FM stations (up to 30 presets).
- **Manual Tuning:** Use the **Tune +/-** buttons to manually adjust the frequency.
- **Preset Recall:** Use the number buttons (1-6) on the unit or remote to select saved preset stations.



Image: Close-up of the KD-S01 display showing FM radio frequency and preset indicators.

Bluetooth Pairing

- Switch to Bluetooth mode using the **SRC** or **Mode** button. The display will show "BT" or a similar indicator.
- On your mobile device, enable Bluetooth and search for "KEiD KD-S01" or a similar device name.
- Select the device to pair. Once paired, you can stream audio wirelessly.
- Note: Bluetooth connectivity is optimized for mobile phones and may not be compatible with all computer systems.

Wireless streaming with your phone via Bluetooth

Built-in mic for handsfree calls.



Image: The KD-S01 unit wirelessly connected to a smartphone via Bluetooth, playing music.

USB MP3 Playback

- Insert a USB flash drive containing MP3 audio files into the USB port on the unit.
- The unit should automatically switch to USB mode and begin playback. If not, select USB mode using the **SRC** or **Mode** button.
- Use the **Previous/Next** buttons to navigate tracks.

AUX Line-in

- Connect an external audio device (e.g., smartphone, tablet) to the AUX-in port using a 3.5mm audio cable.
- Switch to AUX mode using the **SRC** or **Mode** button.
- Audio from the connected device will play through the KD-S01 speakers.

Night Light and Anion Air Purification

- **Night Light:** Press the **Light** button on the remote to cycle through 3 brightness levels or turn off the night light.

- **Night Light Timer:** The night light also features an auto-off timer with 3 levels. Consult the manual for setting this feature.
- **Anion Air Purifier:** This function operates in the background to help purify the surrounding air. There is no direct user control for this feature beyond its automatic operation.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the unit. Do not use liquid cleaners or abrasive materials.
- **Ventilation:** Ensure the unit has adequate ventilation and is not placed in an enclosed space that could obstruct airflow.
- **Storage:** If storing the unit for an extended period, disconnect it from power and remove batteries from the remote control.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not power on.	Power adapter not connected or faulty; power switch off.	Ensure power adapter is securely connected and plugged into a live outlet. Check if the power switch on the back is ON.
No sound.	Volume too low; incorrect mode selected; external device issue.	Increase volume. Verify the correct input mode (FM, BT, USB, AUX) is selected. Check connections for external devices.
Poor FM reception.	Antenna not extended or positioned correctly; interference.	Fully extend and reposition the FM antenna. Move the unit away from other electronic devices that may cause interference.
Bluetooth pairing issues.	Device not in pairing mode; device too far; incompatible device.	Ensure the unit is in Bluetooth mode. Keep devices within 10 meters. Note that Bluetooth is primarily designed for mobile phones and may not connect to all computers.
Remote control not working.	Batteries dead or incorrectly inserted; obstruction.	Replace batteries, ensuring correct polarity. Remove any obstructions between the remote and the unit's sensor.
Clock/Alarm settings difficult to adjust.	Reliance on remote control; unfamiliarity with menu.	Most clock and alarm settings require the remote control. Refer to the specific section in the full user manual for detailed steps.

SPECIFICATIONS

- **Model:** KD-S01
- **Brand:** KEiiD
- **Product Dimensions:** 6.69 x 6.69 x 1.89 inches (L x W x H)
- **Item Weight:** 1.2 pounds
- **Manufacturer:** KEiiD Electronics
- **Connectivity Technology:** Bluetooth 5.0, Auxiliary (3.5mm), USB
- **Color:** Black
- **Speaker Type:** Stereo (2x 5W RMS)

- **FM Radio:** Full band, 30 presets
- **Power Input:** 12V 5A DC
- **Batteries Required (Remote):** 2x AAA (not included)

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the contact details provided in the original product packaging or visit the official KEiiD website. Keep your purchase receipt as proof of purchase for warranty claims. For further assistance, you may contact KEiiD customer service directly.

© 2023 KEiiD Electronics. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question