

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [MINISO](#) /
- > [Miniso Ultrasonic Mini Humidifier Model 4500 Instruction Manual](#)

MINISO 4500

Miniso Ultrasonic Mini Humidifier Model 4500 Instruction Manual

Your guide to setup, operation, and maintenance.

PRODUCT OVERVIEW

The Miniso Ultrasonic Mini Humidifier is designed to provide a comfortable environment by adding moisture to the air. Its compact size makes it ideal for bedrooms, baby rooms, or office desks. Utilizing ultrasonic technology, it operates quietly, ensuring it does not disturb your sleep or work. This humidifier is perfect for individuals experiencing colds, allergies, or dry skin, helping to improve air quality and comfort.



Image: Miniso Ultrasonic Mini Humidifier, showcasing its compact, white design suitable for various settings.

PACKAGE CONTENTS

Please check the box for the following items:

- 1 x Miniso Humidifier
- 1 x USB Cable
- 1 x Replacement Cotton Filter Core

SETUP GUIDE

Follow these steps to set up your humidifier:

1. **Fill with Water:** Carefully open the humidifier and fill the water tank with **pure water only**. Do not exceed the maximum fill line. *Avoid adding essential oils or other aromatic liquids, as this can damage the unit.*
2. **Connect Power:** Insert the USB cable into the humidifier's power port and connect the other end to a suitable USB power source (e.g., a computer, power adapter, or power bank).
3. **Power On:** Press the power button to turn on the humidifier. The indicator light will illuminate, and mist will begin to disperse.

OPERATING YOUR HUMIDIFIER

The Miniso Ultrasonic Mini Humidifier is designed for simple operation:

- **Turning On/Off:** Press the single control button to turn the humidifier on. Press it again to turn it off.
- **Quiet Operation:** The ultrasonic technology ensures a quiet operation, making it suitable for use in bedrooms or other quiet environments without disturbance.
- **Automatic Shut-off:** For safety and to prevent damage, the humidifier may automatically shut off when the water level is too low. Refill the tank to resume operation.

CARE AND MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your humidifier:

- **Filter Core Cleaning:** Wash the cotton filter core at least once a month. Gently remove it, rinse under clean water, and ensure it is fully saturated before reinserting. Replace the filter core every 1-3 months, or when mist output decreases significantly.
- **Water Tank Cleaning:** Empty and rinse the water tank daily to prevent mineral buildup and bacterial growth. Use a soft cloth or brush to clean the inside of the tank.
- **Exterior Cleaning:** Wipe the exterior of the humidifier with a soft, damp cloth as needed. Do not use abrasive cleaners or immerse the unit in water.
- **Storage:** If storing the humidifier for an extended period, ensure it is clean and completely dry. Store in a cool, dry place.

TROUBLESHOOTING

If you encounter issues with your humidifier, refer to the following table:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No mist or low mist output	Low water level Dry or clogged cotton filter core Power connection issue	Refill water tank Soak or replace filter core Check USB cable and power source
Humidifier not turning on	No power Faulty USB cable	Ensure USB cable is securely connected to a working power source Try a different USB cable
Unusual odor from mist	Stagnant water Mineral buildup	Clean water tank thoroughly and refill with fresh water Clean the humidifier as per maintenance instructions

PRODUCT SPECIFICATIONS

Feature	Specification
Brand	MINISO
Model Number	4500
Color	White
Dimensions	8 x 8 x 18 cm
Weight	200 g
Capacity	280 Milliliters
Material	Plastic
Special Feature	Silent Operation
Recommended Floor Area	50 square meters

IMPORTANT SAFETY INFORMATION

Please read and follow these safety precautions to prevent injury or damage:

- Always use pure water. Do not add essential oils, perfumes, or other chemicals to the water tank, as this can damage the humidifier and void the warranty.
- Do not immerse the humidifier in water or any other liquid.
- Keep the humidifier out of reach of children and pets.
- Place the humidifier on a stable, flat surface away from direct sunlight, heat sources, and electronic devices.
- Unplug the humidifier before cleaning, refilling, or when not in use for an extended period.
- Do not block the mist outlet.
- If the humidifier emits smoke, unusual odors, or makes strange noises, unplug it immediately and

discontinue use.

WARRANTY AND CUSTOMER SUPPORT

This Miniso product is covered by a standard manufacturer's warranty against defects in materials and workmanship. For specific warranty details, including duration and terms, please refer to the documentation provided at the time of purchase or contact your retailer.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Miniso customer service through their official website or the contact information provided with your purchase. Please have your model number (4500) and purchase date ready when contacting support.