

LEGAMI MSP0001

Legami Mini Wireless Speaker - Panda (Model MSP0001) Instruction Manual

1. INTRODUCTION

Thank you for choosing the Legami Mini Wireless Speaker. This compact and portable Bluetooth speaker features hands-free calling and a remote selfie function, making it a versatile companion for your audio needs. This manual provides essential information for the safe and efficient use of your speaker. Please read it thoroughly before first use and retain it for future reference.

2. SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the speaker to strong impacts.
- Do not disassemble, repair, or modify the device yourself. Contact qualified service personnel if needed.
- Keep the speaker away from water and other liquids. It is not waterproof.
- Use only the provided charging cable or a certified equivalent.
- Do not operate the speaker at excessively high volumes for prolonged periods to prevent hearing damage.
- Dispose of the product and its battery responsibly according to local regulations.

3. PACKAGE CONTENTS

Ensure all items are present in the package:

- Legami Mini Wireless Speaker (Panda design)
- Micro USB Charging Cable
- Lanyard/Strap

- Instruction Manual (this document)



Image: The Legami Mini Wireless Speaker in its retail packaging, showcasing the Panda design and key features.

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your Legami Mini Wireless Speaker.



Image: Rear view of the Panda speaker showing the Micro USB charging port and the multi-function power button, alongside the included USB charging cable.

- **Speaker Grille:** Located at the top, for audio output.
- **Micro USB Port:** For charging the speaker.
- **Multi-function Button:** Controls power, Bluetooth pairing, play/pause, answer/end calls, and selfie remote.
- **LED Indicator:** Shows power and Bluetooth status.
- **Microphone:** For hands-free calls.




Image: The Legami Mini Wireless Speaker in a hand, demonstrating its small and portable dimensions (approximately 5 cm / 2 inches tall).

5. SETUP

5.1. Charging the Speaker

1. Connect the Micro USB end of the charging cable to the Micro USB port on the speaker.
2. Connect the USB-A end of the charging cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will illuminate during charging. It will turn off or change color (depending on model) once fully charged.
4. A full charge typically takes approximately 1-2 hours.

5.2. Power On/Off

- **To Power On:** Press and hold the multi-function button for approximately 3 seconds. You will hear an audible prompt, and the LED indicator will flash.

- **To Power Off:** Press and hold the multi-function button for approximately 3 seconds. You will hear an audible prompt, and the LED indicator will turn off.

5.3. Bluetooth Pairing

1. Ensure the speaker is fully charged and powered off.
2. Press and hold the multi-function button for approximately 3-5 seconds until the LED indicator flashes rapidly (usually blue), indicating it is in pairing mode.
3. On your smartphone or other Bluetooth-enabled device, go to the Bluetooth settings and enable Bluetooth.
4. Search for available devices. The speaker will appear as "**Legami Speaker**" or a similar name.
5. Select the speaker from the list to connect. Once successfully paired, you will hear an audible confirmation, and the LED indicator will flash slowly or remain solid.
6. The speaker will automatically attempt to reconnect to the last paired device when powered on.

6. OPERATING INSTRUCTIONS

6.1. Music Playback

- After successful Bluetooth pairing, open your music player application on your connected device.
- **Play/Pause:** Press the multi-function button once to play or pause music.
- Volume control is managed directly from your connected device.

6.2. Hands-Free Calls

- When a call comes in, the speaker will ring.
- **Answer Call:** Press the multi-function button once to answer an incoming call.
- **End Call:** Press the multi-function button once during a call to end it.
- **Reject Call:** Press and hold the multi-function button for approximately 2 seconds to reject an incoming call.

6.3. Selfie Remote Function

The speaker can also act as a remote shutter for your smartphone camera.

1. Ensure the speaker is paired with your smartphone via Bluetooth.
2. Open your smartphone's camera application.
3. Position your phone for the desired shot.
4. Press the multi-function button on the speaker once to trigger the camera shutter and take a photo.

7. MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.
- **Battery Care:** To prolong battery life, charge the speaker at least once every three months if not used regularly.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; Bluetooth off on device; device too far.	Ensure speaker is in pairing mode (rapidly flashing LED). Turn on Bluetooth on your device. Move device closer to speaker (within 10 meters).
No sound or distorted sound.	Volume too low; speaker not connected; interference.	Increase volume on your device. Re-pair the speaker. Move away from other wireless devices.
Selfie remote not working.	Speaker not paired; camera app not open.	Ensure speaker is paired. Open your phone's camera app before pressing the button.

9. SPECIFICATIONS

Model: MSP0001

Brand: LEGAMI

Connectivity: Bluetooth, USB (for charging)

Speaker Output: 10 Watt

Control Method: Touch (Multi-function button)

Compatible Devices: Smartphones

Material: Rubber, Plastic

Dimensions: 40D x 40B x 45H millimeters

Item Weight: 42.5 Grams

Power Source: Corded Electric Component (via USB)

Special Feature: Wireless, Hands-free, Selfie Remote

UPC: [8051739306279](#)

10. WARRANTY AND SUPPORT

This product is covered by a standard manufacturer's warranty. For detailed warranty information, please refer to the documentation provided at the point of purchase or contact Legami customer support. If you encounter any issues or have questions regarding your Legami Mini Wireless Speaker, please visit the official Legami website or contact their customer service for assistance.