

AutoFull C3

AutoFull C3 Gaming Chair Instruction Manual

Model: C3 (AF070)

1. INTRODUCTION

Thank you for choosing the AutoFull C3 Gaming Chair. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new chair. Please read this manual thoroughly before assembly and retain it for future reference.

The AutoFull C3 Gaming Chair is designed for comfort and ergonomic support during extended periods of sitting, ideal for gaming and office use. It features high-density foam, PU leather upholstery, adjustable armrests, and a reclining backrest with a retractable footrest.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Do not stand on the chair.
- Do not use the chair as a step stool.
- Ensure all bolts and screws are securely tightened before use. Re-tighten periodically.
- Do not sit on the armrests.
- Keep children away from moving parts.
- Maximum weight recommendation: 350 pounds (158 kg).
- Avoid exposing the chair to direct sunlight or extreme temperatures to prevent material degradation.
- Use on a hard floor surface is recommended for optimal caster performance.

3. PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, contact customer support.

- Backrest (x1)
- Seat Cushion (x1)
- Armrests (x2)
- Star Base (x1)
- Casters (x5)
- Gas Lift Cylinder (x1)
- Gas Lift Cover (x1)
- Mechanism Plate (x1)
- Headrest Pillow (x1)
- Lumbar Support Pillow (x1)
- Footrest Assembly (x1)
- Side Covers (x2)
- Hardware Pack (screws, washers, Allen wrench)
- User Manual (this document)

4. ASSEMBLY INSTRUCTIONS

Estimated assembly time: 10-15 minutes. It is recommended to assemble the chair on a soft, clean surface to prevent damage.

Step 1: Assemble the Base

1. Insert the five casters into the holes at the end of each leg of the star base. Push firmly until they click into place.
2. Place the gas lift cylinder into the center hole of the star base. Cover it with the gas lift cover.



Image: Attaching casters to the star base and inserting the gas lift cylinder.

Step 2: Attach the Mechanism Plate to the Seat Cushion

1. Align the mechanism plate with the screw holes on the underside of the seat cushion. Ensure the front of the mechanism plate faces the front of the seat cushion.
2. Secure the mechanism plate using the provided screws and Allen wrench. Tighten all screws evenly.

Step 3: Attach the Backrest to the Seat Cushion

1. Align the backrest with the metal brackets on the sides of the seat cushion.
2. Insert and tighten the screws to secure the backrest to the seat cushion.
3. Attach the plastic side covers over the metal brackets and screws.

Ergonomic Design

To provide long lasting support



Image: Attaching the backrest to the seat cushion and covering side brackets.

Step 4: Attach Armrests

1. Attach the armrests to the designated holes on the sides of the seat cushion using the provided screws. Ensure they are securely fastened.

Step 5: Attach Footrest (if applicable)

1. Slide the footrest assembly into the designated slots under the seat cushion. Ensure it slides smoothly.

Step 6: Connect Seat to Base

1. Carefully place the assembled seat onto the gas lift cylinder on the star base. Press down firmly to secure.

Step 7: Attach Pillows

1. Attach the headrest pillow to the top of the backrest using its straps, positioning it for neck support.
2. Attach the lumbar support pillow to the lower backrest using its straps, positioning it for lower back support.

Racing Seat Leather & Carbon Fiber

To withstand long time tear and wear



Image: Attaching the headrest and lumbar support pillows.

5. OPERATING INSTRUCTIONS

Height Adjustment

To adjust the chair height, pull the lever located under the right side of the seat upwards. While pulling the lever, lift your weight off the seat to raise the chair, or remain seated to lower it. Release the lever to lock the height.

Backrest Recline

To recline the backrest, pull the lever on the right side of the chair (near the seat) upwards. Lean back to the desired angle (up to 155°). Release the lever to lock the backrest position.

155° Tilting + 25° Rocking

To suit all sitting positions



Image: Adjusting the recline angle of the chair.

Rocking Function and Tilt Lock

The chair features a 25° rocking function. To enable rocking, pull the lever on the left side of the seat outwards. To disable rocking and lock the chair in an upright position, push the lever inwards. A tension knob under the seat allows you to adjust the resistance of the rocking function. Turn clockwise to increase tension (harder to rock) and counter-clockwise to decrease tension (easier to rock).

Armrest Adjustment

The 2D armrests can be adjusted in height and rotated. To adjust height, press the button on the side of the armrest and move it up or down. Release the button to lock. To rotate, simply twist the armrest pad to the desired angle.

Footrest Operation

To extend the footrest, pull it out from under the seat. To retract, push it back in until it is fully stored under the seat.

High Density Aviation Grade Seat Cushion

For all-day comfort



Image: Extending the retractable footrest.

6. MAINTENANCE

- **Cleaning:** Wipe the PU leather with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners. For spills, blot immediately with a clean, dry cloth.
- **Tightening:** Periodically check and re-tighten all screws and bolts to ensure stability and safety.
- **Casters:** Clean casters regularly to remove dust and debris that may hinder smooth movement.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the PU leather to fade or crack.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair wobbles or is unstable.	Loose screws or uneven assembly.	Check and tighten all screws and bolts. Ensure the chair is assembled on a flat surface.
Chair does not adjust height.	Gas lift cylinder malfunction or lever not engaged.	Ensure the height adjustment lever is fully pulled. If the issue persists, the gas lift cylinder may need replacement. Contact customer support.
Backrest does not recline or lock.	Recline lever not engaged or mechanism jammed.	Ensure the recline lever is fully pulled. Check for any obstructions in the recline mechanism.
Casters do not roll smoothly.	Debris in casters or damaged casters.	Clean any hair or debris from the casters. If damaged, casters may need replacement.

8. SPECIFICATIONS

- **Model Name:** C3 (AF070)
- **Brand:** AutoFull
- **Color:** Black
- **Material:** Faux Leather (PU Leather), High-Density Foam
- **Product Dimensions:** 20.9"D x 27.6"W x 50.8"H
- **Item Weight:** 47 pounds (21.3 kg)
- **Maximum Weight Recommendation:** 350 Pounds (158 kg)
- **Back Style:** Solid Back
- **Special Features:** Adjustable Height, 2D Armrests, 155° Recline, 25° Rocking Function, Retractable Footrest, Headrest Pillow, Lumbar Support Pillow
- **Recommended Uses:** Gaming, Office
- **Manufacturer:** AutoFull



Image: Detailed dimensions of the AutoFull C3 Gaming Chair, including backrest width, armrest height adjustability, seat thickness, seat depth, height adjustment, base diameter, floor to seat height, and seat width.

9. WARRANTY AND SUPPORT

AutoFull provides a 3-year warranty for free parts replacement. If you encounter any issues or require assistance, please contact AutoFull customer support. Solutions are generally provided within 24 hours. For further assistance, visit the [AutoFull Store on Amazon](#).

10. PRODUCT VIDEOS

AutoFull C3 Gaming Chair Product Display

Your browser does not support the video tag.

Video: An official product display showcasing the features and design of the AutoFull C3 Gaming Chair.

