

[Manuals.plus](#) /

› [NPET](#) /

› NPET Cat Water Fountain WF050TP User Manual

NPET WF050TP-01

NPET Cat Water Fountain WF050TP User Manual

Model: WF050TP-01

INTRODUCTION

Thank you for choosing the NPET WF050TP Automatic Pet Drinking Fountain. This fountain is designed to encourage your pets to drink more water, promoting better hydration and health. It features a 1.5L capacity, multiple drinking modes, and a multi-layer filtration system to provide clean and fresh water. Please read this manual carefully before use to ensure proper setup, operation, and maintenance.



Image: The NPET WF050TP Cat Water Fountain, a clear plastic unit with a water spout, showing the internal filter and water levels.

PACKAGE CONTENTS

Before proceeding, please verify that all components are present:

- Water Fountain Unit (Main body, top cover, water tray)
- Water Pump
- Faucet Kit (multiple parts for adjustable height)
- Filter Cartridges (typically 2 included)
- Cleaning Brush

- User Manual (this document)

Note: An AC power adapter is **NOT** included with this model. You will need a standard USB power adapter (5V/1A) to power the fountain.



Image: Disassembled components of the NPET WF050TP Cat Water Fountain, including the main clear reservoir, top tray, pump, faucet parts, filter, and cleaning brush. A red circle with a cross indicates that a power adapter is not included.

SETUP INSTRUCTIONS

1. **Initial Cleaning:** Before first use, disassemble all parts of the fountain (except the pump's electrical components) and wash them thoroughly with water and mild soap. Rinse all parts completely to remove any soap residue.
2. **Assemble the Pump:** Ensure the pump is clean. Attach the silicone hose to the pump outlet. Do not remove the silicone hose from the pump.
3. **Place the Pump:** Place the assembled pump into the designated slot at the bottom of the main water reservoir. Ensure the power cord is routed through the cable channel to prevent pinching.
4. **Install the Filter:** Rinse the new filter cartridge under running water for a few minutes to remove any loose carbon dust. Place the rinsed filter into the filter tray, ensuring it sits securely.
5. **Assemble the Faucet Kit:** If using the faucet mode, assemble the faucet parts. You can adjust the height by adding or removing the middle section of the faucet. Insert the assembled faucet into the hole on the top cover.
6. **Fill with Water:** Fill the main reservoir with clean water up to the "MAX" line. Do not overfill. The 1.5L capacity is suitable for various pets.
7. **Place Top Cover:** Carefully place the top cover onto the main reservoir, ensuring it is properly aligned and seated.
8. **Connect Power:** Connect the USB cable from the pump to a standard 5V/1A USB power adapter (not included) and plug it into a wall outlet. The fountain should begin operating.

OPERATING INSTRUCTIONS

The NPET WF050TP fountain offers two primary drinking modes to suit your pet's preferences:

- **Faucet Mode:** This mode mimics a running tap, which can be highly appealing to cats and some dogs, encouraging them to drink more. The height of the faucet can be adjusted during assembly.
- **Spring Surge Mode:** Without the faucet attachment, the water bubbles up from the center, creating a gentle spring-like flow.

The fountain operates continuously when plugged in. Monitor the water level regularly through the transparent tank. Refill water when it reaches the "MIN" line to ensure continuous operation and prevent pump damage.

Better Drinking Water

Match to small & medium cat dog drinking habits



Image: Two views of the NPET WF050TP Cat Water Fountain, demonstrating the faucet mode on the top and the bubbling spring mode on the bottom, illustrating different drinking options for pets.

Emergency Water Storage

The fountain is designed with a small emergency water storage area (approximately 200ml / 6.8oz) in the top tray. This ensures your pet has access to some water even in the event of a power outage, providing peace of mind.

Emergency Water Storage

Not afraid your pets will run out of water when there is sudden power outages



Image: A cat looking at the NPET WF050TP Cat Water Fountain, highlighting the emergency water storage capacity in the top tray, ensuring water availability during power outages.

Quiet Operation

The NPET WF050TP fountain is designed for ultra-quiet operation, typically producing noise levels around 40dB, which is

quieter than a whisper. This low noise level ensures a peaceful environment for both you and your pets.

Ultra Quiet Working

Provide a low noise environment for you and your pets



Image: A small cat sleeping peacefully next to the NPET WF050TP Cat Water Fountain, with an overlay graphic indicating the low noise level of 40dB compared to other common sounds.

MAINTENANCE

Regular cleaning and maintenance are crucial for the longevity of your fountain and the health of your pet. Neglecting cleaning can lead to pump clogging and reduced water quality.

Daily Maintenance

- Check the water level and refill as needed.
- Remove any visible debris, pet hair, or food particles from the water tray.

Weekly Cleaning (Recommended)

1. Unplug the fountain from the power outlet.
2. Disassemble all parts: top cover, filter tray, filter, pump, and main reservoir.
3. Wash all parts (except the pump's electrical components) with water and mild soap. Use the provided cleaning brush to clean hard-to-reach areas and the inside of the faucet.
4. Rinse all components thoroughly to ensure no soap residue remains.
5. Clean the pump (see detailed instructions below).
6. Reassemble the fountain and refill with fresh water.

Filter Replacement

The 3-layer filter system (sponge, ion exchange resin, activated carbon) helps remove impurities, soften water, and eliminate odors. Replace the filter cartridge every 2-4 weeks, or more frequently if you have multiple pets or notice reduced water quality.

- Always rinse a new filter under running water before placing it in the fountain.

Pump Cleaning (Every 2 Weeks Recommended)

Regular cleaning of the pump is essential to extend its lifespan and maintain optimal water flow. Pet hair and debris can easily clog the pump.

1. **Step 1: Remove the pump cover.** Gently pry off the front cover of the pump.
2. **Step 2: Remove the impeller cover.** Locate the small cover protecting the impeller and remove it.
3. **Step 3: Remove the impeller.** Carefully pull out the impeller (a small rotor with blades) from its housing.
4. **Step 4: Clean all parts with clean water.** Use the provided cleaning brush to thoroughly clean the impeller, its housing, and all internal parts of the pump. Remove any hair, slime, or debris.
5. Reassemble the pump by reversing the steps. Ensure the impeller is properly seated and the covers click securely into place.

Cleaning Pump to Extend Spanlife

Step 1



1. Remove the pump cover

Step 2



2. Remove the impeller cover

Step 3



3. Remove the impeller

Step 4



4. Clean all parts with clean water

Image: A four-panel diagram illustrating the steps to clean the water pump of the NPET WF050TP fountain: 1. Removing the pump cover, 2. Removing the impeller cover, 3. Removing the impeller, and 4. Cleaning all parts with a brush.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Fountain not working / No water flow	- No power supply. - Water level too low. - Pump clogged with hair/debris. - Impeller stuck or dirty.	- Check power connection and USB adapter. - Refill water to the MAX line. - Clean the pump thoroughly as per maintenance instructions. - Ensure the impeller spins freely.
Excessive noise from pump	- Water level too low. - Pump not properly seated. - Pump clogged or dirty.	- Refill water. - Ensure pump is securely placed in its slot. - Clean the pump thoroughly.
Water has bad taste or odor	- Filter needs replacement. - Fountain needs thorough cleaning.	- Replace the filter cartridge. - Disassemble and clean all fountain parts.
Water flow is weak	- Filter clogged. - Pump partially clogged. - Water level too low.	- Replace the filter. - Clean the pump. - Refill water.

SPECIFICATIONS

Feature	Detail
Model Name	WF050TP-01
Brand	NPET
Capacity	1.5 Liters (approx. 50 oz)
Material	Food-grade Plastic
Product Dimensions (L x W x H)	6.8" x 6.77" x 6.5" (17.3cm x 17.2cm x 16.5cm)
Item Weight	0.5 Kilograms (1.1 pounds)
Power Source	Corded Electric (USB 5V/1A, adapter not included)
Special Feature	Lightweight, Transparent Tank, Quiet Operation, Emergency Water Storage
Filter Type	3-layer activated carbon and ion exchange resin filter

WARRANTY AND SUPPORT

The NPET WF050TP Cat Water Fountain comes with a **1-year warranty** from the date of purchase. This warranty covers

manufacturing defects and malfunctions under normal use.

For warranty claims, technical support, or any questions regarding your product, please contact NPET customer service. You can typically find contact information on the NPET official website or through the retailer where you purchased the product.

Legal Disclaimer: The adapter is not included. Please do not take off the silicone hose attached to the pump.

© 2024 NPET. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0895P6XBV>

More documents and user manuals: <https://manuals.plus/>