

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Gigastone](#) /

› [Gigastone V10 64GB USB2.0 Flash Drive Instruction Manual](#)

Gigastone V10

Gigastone V10 64GB USB2.0 Flash Drive Instruction Manual

Model: V10 (GS-Z64GCNBL-B)

1. INTRODUCTION

The Gigastone V10 64GB USB2.0 Flash Drive is a portable storage device designed for convenient data transfer and backup. Its capless retractable design protects the USB connector while offering ease of use. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your flash drive.



Image 1.1: The Gigastone V10 64GB USB2.0 Flash Drive, featuring its retractable design and Gigastone 64GB branding.

2. SETUP

The Gigastone V10 Flash Drive is designed for plug-and-play functionality, requiring no additional software installation for basic operation.

2.1 Connecting the Flash Drive

1. Locate an available USB port on your computer or compatible device.
2. Gently slide the capless mechanism to expose the USB connector.
3. Insert the USB connector firmly into the USB port. The device should be automatically recognized by your operating system.

Plug and play

Transfer data easily without extra installation.



Image 2.1: The Gigastone V10 Flash Drive connected to a laptop, demonstrating its plug-and-play capability for easy data transfer.

3. OPERATING INSTRUCTIONS

3.1 Transferring Files

Once connected, the flash drive will appear as a removable storage device (e.g., 'USB Drive' or 'Removable Disk') in your computer's file explorer.

- **To copy files to the flash drive:** Drag and drop files or folders from your computer to the flash drive's folder, or copy and paste them.
- **To copy files from the flash drive:** Drag and drop files or folders from the flash drive's folder to your computer, or copy and paste them.

3.2 Safe Removal

To prevent data corruption, always safely remove the flash drive before disconnecting it from your computer.

- **Windows:** Click the 'Safely Remove Hardware and Eject Media' icon in the system tray, then select the Gigastone V10.
- **macOS:** Drag the flash drive icon from your desktop to the Trash, or right-click (Control-click) the icon

and select 'Eject'.



Image 3.1: A user operating a laptop, illustrating the use of the flash drive for efficient data transfer.

4. COMPATIBILITY

The Gigastone V10 Flash Drive offers broad compatibility with various devices and operating systems.

- **USB Interface:** Compatible with both USB 2.0 and USB 3.0 ports.
- **Operating Systems:** Supports Windows 7 / 8 / 10 / Vista / XP / Unix / 2000 / ME / NT, Linux, and Mac OS.
- **Devices:** Suitable for use with desktops, laptops, tablets, smart TVs, gaming consoles, and car audio systems.



Great compatibility


Compatible with multiple devices

Image 4.1: The Gigastone V10 Flash Drive shown alongside a laptop and tablet, highlighting its compatibility with multiple devices.

5. MAINTENANCE

Proper care ensures the longevity and reliable performance of your Gigastone V10 Flash Drive.

- **Physical Protection:** Avoid dropping the drive or subjecting it to strong impacts. The retractable design helps protect the connector.
- **Environmental Conditions:** Keep the drive away from extreme temperatures, direct sunlight, and high humidity.
- **Cleaning:** If necessary, gently wipe the exterior with a soft, dry cloth. Do not use liquid cleaners or solvents.
- **Data Backup:** Regularly back up important data stored on the flash drive to another storage medium.



Rope Hole Design

Bring important data with one keychain

Image 5.1: The Gigastone V10 Flash Drive with its rope hole design, allowing it to be attached to a keychain for secure and convenient portability.

6. TROUBLESHOOTING

If you encounter issues with your Gigastone V10 Flash Drive, refer to the following common solutions:

- **Drive Not Recognized:**

- Ensure the drive is fully inserted into the USB port.
- Try a different USB port on your computer.
- Test the drive on another computer to rule out a computer-specific issue.
- Check your computer's Device Manager (Windows) or System Information (macOS) to see if the drive is listed.

- **Slow Transfer Speeds:**

- Ensure you are using a USB 2.0 or 3.0 port. While compatible with USB 3.0, the drive operates at USB 2.0 speeds.
- Transferring many small files can be slower than transferring a single large file of the same total size.

- Close other applications that might be using system resources.
- **Cannot Write Files:**
 - Check if the drive is full. Delete unnecessary files or transfer them to another location.
 - Ensure you have appropriate permissions to write to the drive on your operating system.
 - The drive might be formatted with a file system that has limitations (e.g., FAT32 has a 4GB file size limit). Consider reformatting if necessary (this will erase all data).

7. SPECIFICATIONS

Feature	Detail
Brand	Gigastone
Model Name	V10
Item Model Number	GS-Z64GCNBL-B
Memory Storage Capacity	64 GB
Hardware Interface	USB 2.0, USB 3.0 (compatible)
Reading Speed	Up to 25 Megabytes Per Second
Flash Memory Type	NAND
Special Features	Pocket Size, Easy To Use, Retractable Design
UPC	804272755640
Package Dimensions	19 x 12 x 0.8 cm
Item Weight	40 g

8. WARRANTY AND SUPPORT

Gigastone stands behind the quality of its products.

- **Warranty:** The Gigastone V10 Flash Drive comes with a 5-year limited warranty. Please retain your proof of purchase for warranty claims.
- **Support:** For further assistance, technical support, or warranty inquiries, please visit the official Gigastone website or contact their customer service.



Image 8.1: Gigastone's commitment to quality, highlighted by the 5-year global manufacturer warranty.

Related Documents - V10

	<p>Gigastone R101 Quick Installation Guide</p> <p>A quick installation guide for the Gigastone R101 wireless router, covering hardware introduction, operating modes (AP, Router, Repeater, Client), and PC IP address setup.</p>
	<p>Gigastone GA-9700 Wireless Fast Charger User Guide</p> <p>User guide for the Gigastone GA-9700 Qi Compatible 15Watt Fast Charge wireless charger, including specifications, usage instructions, and safety precautions.</p>

	<p><u>Gigastone D1 Bluetooth Headset User Manual</u> Official user manual for the Gigastone D1 Bluetooth Headset, providing specifications, features, operating instructions, pairing guide, troubleshooting, and safety precautions.</p>
	<p><u>H1 Bluetooth Headphone User Manual</u> User manual for the H1 Bluetooth Headphone, detailing specifications, pairing, operation, and troubleshooting.</p>
	<p><u>Gigastone KMH-9550 Bluetooth Wireless Microphone User Manual and FCC Statement</u> User manual and FCC compliance information for the Gigastone KMH-9550 Bluetooth Wireless Microphone. This document provides essential details regarding product usage, safety, and regulatory compliance.</p>
	<p><u>Gigastone QP-10100 Wireless Power Bank User Manual and Specifications</u> Comprehensive user manual for the Gigastone QP-10100 wireless power bank, detailing specifications, charging instructions, troubleshooting tips, and FCC compliance information.</p>