

[Manuals.plus](#) /

> [OVENTE](#) /

> OVENTE Electric Steam Mop Cleaner ST405W User Manual

OVENTE

OVENTE Electric Steam Mop Cleaner ST405W User Manual

Model: ST405W | Brand: OVENTE

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using your OVENTE Electric Steam Mop. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- Always ensure the steam mop is unplugged before filling the water tank or performing maintenance.
- Do not leave the steam mop unattended while it is powered on or steaming.
- Keep out of reach of children and pets.
- Use only distilled or demineralized water in the tank to prevent mineral buildup and prolong product life.
- Do not add cleaning solutions, perfumes, or other chemicals to the water tank. This can damage the appliance and void the warranty.
- Avoid directing steam at people, animals, or electrical outlets.
- Do not immerse the steam mop in water or any other liquid.
- Ensure the microfiber pad is properly attached before use.
- Unplug the appliance when not in use and before cleaning.
- Do not operate the steam mop if the cord or plug is damaged.
- This appliance operates on 120 Volts. Ensure your power outlet matches this voltage.

PRODUCT OVERVIEW

The OVENTE Electric Steam Mop ST405W is designed for efficient and chemical-free floor cleaning. It utilizes 1300W of power to generate steam for sanitizing various floor surfaces.

Components

- Main Steam Mop Unit (Handle, Body, Swivel Head)
- Refillable Water Tank (350ml capacity)
- Microfiber Cleaning Pad
- Refill Measuring Cup
- Carpet Glider
- Power Cord (13-foot)

- Power Light Indicator





Figure 1: OVENTE Electric Steam Mop ST405W, showing the full assembled unit.



CORD WRAP

For safely moving your steam mop from room to room and storing it neatly

REFILLABLE WATER TANK

Easily fill 350ml water tank with the included refill measuring cup

Figure 2: Close-up of the steam mop highlighting the convenient cord wrap and the refillable water tank.

1. **Attach Microfiber Pad:** Place the microfiber cleaning pad onto the bottom of the steam mop's triangular swivel head. Ensure it is securely attached via the Velcro strips.

2. **Fill Water Tank:**

- Lay the mop flat.
- Open the water tank cap.
- Use the provided measuring cup to fill the 350ml water tank with distilled or demineralized water. Do not overfill.
- Securely close the water tank cap.

Your browser does not support the video tag.

Video: Demonstrates how to fill the water tank and attach the microfiber pad.

3. **Connect Power:** Plug the 13-foot power cord into a standard 120V electrical outlet. The power light indicator will illuminate.

OPERATING INSTRUCTIONS

The OVENTE Steam Mop is ready for use once the water tank is filled and it is plugged in. It heats up quickly to produce steam.

1. **Pre-heating:** Allow the steam mop to pre-heat for a few seconds after plugging it in. The power light indicator will show it's ready.
2. **Steam Activation:** Press the light-touch power button to activate steam release. The mop will release continuous steam for up to 15 minutes per tank fill.
3. **Cleaning Hard Floors:**
 - Move the steam mop slowly and steadily across your hardwood, marble, tile, or stone floors.
 - The triangular swivel head allows for easy maneuvering around furniture and into corners.
 - For stubborn spots, hold the mop over the area for a few seconds to allow the steam to penetrate.



Figure 3: The triangular swivel head allows for easy access to hard-to-reach areas.

4. Cleaning Carpets:

- Attach the included carpet glider over the microfiber pad.
- Move the steam mop over your carpets to refresh and sanitize them.



Figure 4: The carpet glider attached to the steam mop for use on carpets.

5. **Refilling During Use:** If the water tank runs empty during cleaning, simply unplug the unit, refill the tank as per step 2 in Setup, and plug it back in to continue.
6. **Finishing Cleaning:** When finished, unplug the steam mop from the electrical outlet.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your OVENTE Steam Mop.

- **Empty Water Tank:** After each use, unplug the mop and allow it to cool. Empty any remaining water from the tank.
- **Clean Microfiber Pad:**
 - Detach the microfiber cleaning pad from the mop head.
 - The pad can be washed by hand or in a washing machine. Do not use bleach or fabric softeners.
 - Allow the pad to air dry completely before storing or re-using.



MICROFIBER PADS

Includes high-density removable microfiber cleaning pads. Simply detach and throw in the washer

Figure 5: Detaching the microfiber pad for cleaning.

- **Store Properly:** Use the built-in cord storage wrap to neatly store the power cord. Store the steam mop in a cool, dry place.
- **Descaling (Periodic):** If you notice reduced steam output, mineral buildup may be occurring. Consult the OVENTE customer support for specific descaling instructions.

TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
No steam output.	Water tank is empty. Unit not plugged in. Unit not heated up. Mineral buildup.	Refill water tank. Ensure power cord is securely plugged into a 120V outlet. Allow a few seconds for pre-heating. Perform descaling (contact support if unsure).
Steam output is weak.	Low water level. Mineral buildup.	Refill water tank. Perform descaling.

Problem	Possible Cause	Solution
Mop leaves streaks on floor.	Microfiber pad is dirty. Too much water/steam.	Wash or replace microfiber pad. Move the mop at a slightly faster pace.
Power light not on.	Unit not plugged in. Power outlet issue.	Check power connection. Try a different electrical outlet.

SPECIFICATIONS

Model Name: ST405W

Brand: OVENTE

Power: 1300 Watts

Voltage: 120 Volts

Water Tank Capacity: 350 Milliliters

Product Dimensions: 11" (D) x 11" (W) x 46" (H)

Item Weight: 4.39 pounds

Power Source: Electric

Special Features: Power Light Indicator, Swivel Head

Included Components: User Manual, Mop Pad, Measuring Cup, Carpet Glider

Surface Recommendation: Floor (Hardwood, Laminate, Tile, Grout, Carpet with glider)

Country of Origin: China

UPC: 814667024794

WARRANTY AND SUPPORT

OVENTE provides a **1-Year Warranty** on Domestic (USA) Repairs and Replacements for workmanship and materials from the original purchase date from an authorized reseller.

For customer service, technical support, or warranty claims, please visit the official OVENTE website or contact their customer support line.

Keep your proof of purchase for warranty validation.

For more information, visit: [OVENTE Official Store](#)

