

MoKo P840034653632

MoKo Magnetic Case Instruction Manual

For Samsung Galaxy Tab S6 Lite 10.4 Inch (2022/2020 Models SM-P613/P619/P610/P615)

1. PRODUCT OVERVIEW

This manual provides instructions for the MoKo Magnetic Case, designed to protect and enhance the functionality of your Samsung Galaxy Tab S6 Lite 10.4 Inch. The case features a magnetic attachment system, a built-in S Pen slot, and supports auto wake/sleep functionality.

1.1 Compatibility

This case is exclusively designed for the Samsung Galaxy Tab S6 Lite 10.4 Inch 2022/2020 models (SM-P613/P619/P610/P615). It is not compatible with Samsung Galaxy Tab S6 2019 or any other tablet models.



Image 1.1: This image illustrates the compatibility of the MoKo Magnetic Case, showing it is designed for Samsung Galaxy

2. INSTALLATION GUIDE

2.1 Attaching the Case

The MoKo Magnetic Case utilizes strong magnets for secure attachment. Align your Samsung Galaxy Tab S6 Lite with the back panel of the case. The tablet will magnetically snap into place, ensuring a firm and precise fit without protruding edges.



Image 2.1: This diagram illustrates the magnetic absorption mechanism, showing how the tablet is securely held in place by powerful magnets within the case.

2.2 Built-in S Pen Slot

The case features a built-in S Pen slot on the interior spine. This slot magnetically absorbs your S Pen, keeping it securely in place and easily accessible. To store, simply place the S Pen into the designated slot. To retrieve, gently pull the S Pen from the slot.



Image 2.2: This image shows the built-in S Pen slot, demonstrating how the S Pen is magnetically secured within the case's spine.

2.3 Visual Installation Guide

Your browser does not support the video tag.

Video 2.3: This video demonstrates the installation process of the MoKo Magnetic Case for the Samsung Galaxy Tab S6 Lite 2020, including how to attach the tablet, secure the S Pen, and utilize the magnetic stand feature.

3. OPERATING INSTRUCTIONS

3.1 Auto Wake/Sleep Function

The case supports the auto wake/sleep feature. Opening the lid will automatically wake your tablet, and closing the lid will put it to sleep, conserving battery life. This function operates seamlessly and quickly.

SMART WAKE/SLEEP

Wake on open. Sleep on close.




Image 3.1: This image visually explains the auto wake/sleep function, showing arrows indicating the tablet waking upon opening the cover and sleeping upon closing it.

3.2 Magnetic Trifold Stand

The front cover of the case can be folded into a trifold stand, providing multiple viewing angles. This allows for comfortable hands-free viewing or typing. Simply fold the cover into the desired triangular shape to prop up your tablet.

TRIFOLD STAND

Multiple angles as desired anytime and anywhere.



Image 3.2: This image shows the MoKo case configured as a trifold stand, supporting the tablet at an angle suitable for viewing or typing.

4. CARE AND MAINTENANCE

To ensure the longevity and appearance of your MoKo Magnetic Case, follow these maintenance guidelines:

- **Cleaning the Exterior:** The premium PU leather exterior can be wiped clean with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the material.
- **Cleaning the Interior:** The soft microfiber interior can be gently wiped with a dry, lint-free cloth to remove dust or smudges.
- **Avoid Extreme Conditions:** Do not expose the case to extreme temperatures, direct sunlight for prolonged periods, or excessive moisture.
- **Magnetic Integrity:** Keep the magnetic areas free from metallic debris that could interfere with the magnetic connection.

5. TROUBLESHOOTING

5.1 Tablet Not Staying Securely Attached

- **Check Alignment:** Ensure the tablet is perfectly aligned with the magnetic back panel of the case.
- **Remove Debris:** Verify that there is no dust, dirt, or other foreign objects between the tablet and the case

that could weaken the magnetic connection.

- **Case Condition:** Inspect the case for any damage or wear that might affect the magnetic strength.

5.2 S Pen Not Staying in Slot

- **Proper Insertion:** Ensure the S Pen is fully inserted into the designated magnetic slot on the case's spine.
- **Magnetic Interference:** Check for any metallic objects near the S Pen slot that might interfere with its magnetic hold.

5.3 Auto Wake/Sleep Not Functioning

- **Lid Closure:** Confirm that the case lid is fully closed and making proper contact with the tablet screen.
- **Tablet Settings:** Check your tablet's display settings to ensure the 'Smart Cover' or 'Auto Wake/Sleep' feature is enabled.

6. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	MoKo
Model Number	P840034653632
Compatible Devices	Samsung Galaxy Tab S6 Lite 2022/2020 (Models: SM-P613/P619/P610/P615)
Compatible Device Size Maximum	10.4 Inches
Color	Black
Form Factor	Case
Shell Type	Soft
Enclosure Material	Faux Leather, Polycarbonate, Microfiber
Additional Features	Auto Sleep/Wake, Lightweight, Built-in S Pen Slot, Magnetic Absorption, Trifold Stand
Item Dimensions	9.69 x 6.54 x 0.43 inches
Item Weight	9.52 Ounces

7. WARRANTY AND SUPPORT

7.1 Warranty Information

MoKo products are typically covered by a manufacturer's warranty against defects in materials and workmanship. For specific warranty terms and conditions, please refer to the product packaging or contact MoKo customer support directly. Keep your proof of purchase for warranty claims.

7.2 Customer Support

If you encounter any issues or have questions regarding your MoKo Magnetic Case, please contact MoKo

customer support. You can typically find contact information on the official MoKo website or through the retailer where the product was purchased.

For further assistance, visit the MoKo Store on Amazon: [MoKo Store](#)