



Manuals.plus /

› LINSY HOME /

› LINSY HOME 47-Inch Computer Desk Instruction Manual

LINSY HOME B0899LXDFV

LINSY HOME 47-Inch Computer Desk Instruction Manual

Model: B0899LXDFV

1. PRODUCT OVERVIEW

The LINSY HOME 47-inch Computer Desk is designed for home office, gaming, study, and general working environments. It features a sturdy metal frame, an engineered wood desktop, and integrated 2-tier storage shelves. The desk is designed for easy assembly and offers a spacious work surface.



Figure 1: Overall view of the LINSY HOME 47-inch Computer Desk.

Dimensions

- **Desk Panel Dimension:** 47.2 inches (W) x 23.6 inches (D)
- **Desk Height:** 29.5 inches
- **Overall Product Dimensions:** 23.6"D x 47.2"W x 29.5"H




Figure 2: Desk dimensions and scale.

2. PACKAGE CONTENTS

Before beginning assembly, please ensure all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Desktop Panel
- Side Frame with Shelf Supports (2)
- Back Crossbars (2)
- Storage Shelf Panels (2)
- Adjustable Feet (4)
- Assembly Hardware (screws, Allen wrench)
- Instruction Manual

3. ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to assemble the desk on a soft, clean surface to prevent scratches. Do not fully tighten screws until all components are loosely assembled.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a protected surface. Verify all parts are present against the package contents list.
2. **Attach Adjustable Feet:** Screw the four adjustable feet into the bottom of the main desk legs. Do not overtighten.
3. **Assemble Side Frames:** Attach the two side frames to the desktop panel. Ensure the holes for the storage shelves are oriented correctly based on your desired left or right side configuration. *Note: The 2-tier storage shelves can be installed on either the left or right side of the desk.*
4. **Install Storage Shelves:** Slide the two storage shelf panels into the designated slots on the side frame. Secure them with the provided hardware, but do not fully tighten yet.
5. **Attach Back Crossbars:** Connect the two back crossbars between the main desk legs. These provide additional stability. Secure with hardware.
6. **Final Tightening:** Once all components are loosely assembled and aligned, gradually tighten all screws using the provided Allen wrench. Ensure the desk is stable and level.



Figure 3: Reversible design for left or right shelf placement.



Figure 4: Stability features including adjustable feet and crossbar.

4. OPERATING INSTRUCTIONS

Using the Storage Shelves

The desk includes two integrated storage shelves, ideal for organizing books, documents, small office supplies, or decorative items. Distribute weight evenly on the shelves to maintain stability.

Adjusting Non-Skid Feet

The four adjustable feet allow you to level the desk on uneven floors and protect your flooring from scratches. To adjust, gently lift the corner of the desk and rotate the foot clockwise to shorten or counter-clockwise to lengthen until the desk is stable and level.

Desk Surface Use

The engineered wood desktop provides a durable and spacious surface for your computer, laptop, and other work essentials. It is designed to be waterproof and scratch-resistant for daily use.



Figure 5: Close-up of the desk surface.

5. MAINTENANCE

- **Cleaning:** Wipe the desk surface and metal frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Promptly wipe up any spills to prevent water damage, especially on the engineered wood surfaces.
- **Screw Tightness:** Periodically check and retighten all assembly screws to ensure the desk remains stable and secure.
- **Weight Distribution:** Avoid placing excessively heavy items on one side of the desk or shelves to prevent imbalance or damage.

6. TROUBLESHOOTING

Desk Wobbles

- **Uneven Floor:** Adjust the non-skid feet on the bottom of the desk legs until the desk is level and stable.
- **Loose Screws:** Check all assembly screws and tighten them securely. Ensure the back crossbars are properly installed and tightened.

Parts Missing or Damaged

- If you find any parts missing or damaged upon opening the package, please contact LINSY HOME customer support immediately for assistance.

7. SPECIFICATIONS

Feature	Detail
Brand	LINSY HOME
Model	B0899LXDFV
Shape	Rectangular
Desk Design	Computer Desk
Product Dimensions (D x W x H)	23.6"D x 47.2"W x 29.5"H
Color	Rustic Brown
Style	Industrial
Base Material	Engineered Wood
Top Material Type	Engineered Wood
Number Of Shelves	2
Required Assembly	Yes
Included Components	Assembly tools and instructions

8. WARRANTY INFORMATION

This LINSY HOME Computer Desk comes with a **Limited Warranty**. For specific details regarding warranty coverage, terms, and conditions, please refer to the documentation included with your purchase or contact LINSY HOME customer support directly.

9. CUSTOMER SUPPORT

For any questions, concerns, or assistance with your LINSY HOME Computer Desk, please contact our customer support team. Please have your model number (B0899LXDFV) and purchase information ready when contacting support.

You can typically find contact information on the LINSY HOME official website or through your original retailer.

