MageGee G10

MageGee G10 Gaming Mouse User Manual

Comprehensive guide for your MageGee G10 Wired Gaming Mouse, featuring 7-color breathing LED backlight, 6 adjustable speeds, and ergonomic design.

PRODUCT OVERVIEW

The MageGee G10 Gaming Mouse is a high-performance wired optical mouse designed for PC gamers. It features a high-precision optical sensor for accurate tracking, a durable 1.5m braided cable with an anti-corrosion USB connector, and an ergonomic design for comfortable extended use. The mouse is equipped with 7 buttons and offers 6 adjustable DPI speed levels, along with a vibrant 7-color breathing LED backlight.

Figure 1: Top view of the MageGee G10 Gaming Mouse, showcasing its black finish and illuminated geometric patterns.

Key features include:

- **High-Precision Optical Sensor:** Delivers precise positioning and high sensitivity for stable control.
- **Ergonomic Design:** Shaped for comfort, reducing fatigue during long gaming sessions.
- **7-Color Breathing LED Backlight:** Provides excellent visual effects and can be customized or turned off.
- **6 Adjustable Speed Options:** DPI levels from 600 to 3200 for versatile performance.
- **7 Programmable Buttons:** Includes Left, Right, Forward, Back, speed +/- buttons, and a Scroll wheel.
- **Durable Construction:** 3 million keystroke test ensures a longer lifespan.

SETUP GUIDE

The MageGee G10 Gaming Mouse is designed for simple plug-and-play functionality, requiring no additional drivers or software installation for basic operation.

Connecting Your Mouse

1. Locate an available USB port on your computer (PC, laptop, notebook, etc.).

2. Plug the USB connector of the MageGee G10 Gaming Mouse into the USB port.

3. The mouse will be automatically recognized by your operating system (Windows 10, 8, 7, XP, WinME, Vista, Linux).

4. The LED backlight will illuminate, indicating the mouse is powered on and ready for use.

No additional setup is required to begin using the mouse for navigation and basic functions.

OPERATING INSTRUCTIONS

The MageGee G10 Gaming Mouse offers adjustable settings to enhance your gaming and computing experience.

Adjusting DPI Speed

The mouse features 6 adjustable DPI (Dots Per Inch) levels, allowing you to change cursor sensitivity on the fly. This is useful for different tasks, such as precise aiming in games or fast navigation across multiple monitors.

- The available DPI levels are: 600, 800, 1200, 1600, 2400, and 3200.
- Use the "Speed +" button (located behind the scroll wheel) to increase the DPI.
- Use the "Speed -" button (located behind the scroll wheel) to decrease the DPI.

Figure 2: Location of the Speed+ and Speed- buttons for DPI adjustment.

Understanding Mouse Buttons

The G10 mouse is equipped with 7 buttons for various functions:

- **Left Button:** Standard click function.
- **Right Button:** Standard right-click function.
- **Scroll Wheel:** Scrolls content up/down. Can also be clicked for middle-click functionality.
- **Forward Button:** Navigates forward in web browsers or file explorers (located on the left side).
- **Back Button:** Navigates backward in web browsers or file explorers (located on the left side).
- **Speed + Button:** Increases DPI sensitivity.
- **Speed - Button:** Decreases DPI sensitivity.

LED Backlight Control

The MageGee G10 features a dynamic 7-color breathing LED backlight that cycles through blue, red, green, purple, cyan,

yellow, and white. This creates an immersive gaming atmosphere.

Figure 3: The MageGee G10 mouse displaying its seven breathing LED colors.

To turn off the LED backlight, press and hold the bottom speed button (Speed -) for 3 seconds. To turn it back on, press and hold the same button for 3 seconds again.

> Your browser does not support the video tag.

Video 1: Demonstration of the MageGee G10 Gaming Mouse's 7-color breathing LED backlight effect.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your MageGee G10 Gaming Mouse.

Cleaning Your Mouse

- Disconnect the mouse from your computer before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the surface of the mouse.

- Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the mouse.
- For crevices and around buttons, use a cotton swab or compressed air to remove dust and debris.
- Ensure the optical sensor on the bottom of the mouse is clean and free of obstructions for accurate tracking.
- Allow the mouse to dry completely before reconnecting it to your computer.

TROUBLESHOOTING

If you encounter issues with your MageGee G10 Gaming Mouse, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Mouse is not responding.	Loose USB connection or faulty USB port.	Ensure the USB cable is securely plugged into a working USB port. Try a different USB port on your computer.
LED backlight is off.	Backlight feature might be turned off.	Press and hold the bottom speed button (Speed -) for 3 seconds to toggle the LED backlight on/off.
Cursor movement is erratic or inaccurate.	Dirty optical sensor or unsuitable mouse pad surface.	Clean the optical sensor on the bottom of the mouse. Use the mouse on a clean, uniform surface or a dedicated mouse pad.
Buttons are not responding correctly.	Dust/debris under buttons or internal issue.	Try cleaning around the buttons with compressed air. If the issue persists, contact customer support.

SPECIFICATIONS

Detailed technical specifications for the MageGee G10 Gaming Mouse:

| Feature	Detail
Brand	MageGee
Model Number	G10
Connectivity Technology	Wired, USB
Movement Detection Technology	Optical
Adjustable DPI Levels	600/800/1200/1600/2400/3200
Number of Buttons	7
LED Backlight	7 Colors Breathing LED (Blue, Red, Green, Purple, Cyan, Yellow, White)
Ergonomic Design	Yes
Cable Length	1.5m (braided)
Item Weight	5.6 ounces
Package Dimensions	5.31 x 3.66 x 1.89 inches
Compatibility	Windows 10/8/7/XP/WinME/Vista, Linux (PC, laptop, computer, notebook)

Figure 4: Dimensions of the MageGee G10 Gaming Mouse.

WARRANTY AND SUPPORT

MageGee is committed to providing high-quality computer peripherals and excellent customer service. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

Customer Support

For technical assistance, troubleshooting beyond this guide, or warranty inquiries, please contact MageGee customer support through the retailer where you purchased the product or visit the official MageGee website for contact information. *Note: Product specifications and features are subject to change without prior notice.*

Related Documents - G10

	MAGEGEE V100 Wireless Mouse User Guide User guide for the MAGEGEE V100 wireless mouse, detailing its features, technical specifications, and button layout for optimal use. Learn about DPI settings, connectivity, and support.
	MageGee SKY87 Mechanical Keyboard User Guide and Warranty Comprehensive user guide for the MageGee SKY87 Mechanical Keyboard, detailing its features, multi-function keys, lighting effects, and warranty information. Includes product specifications and troubleshooting tips.
	MAGEGEE V920 Wireless Keyboard and Mouse Combo User Guide Official user guide for the MAGEGEE V920 wireless 2.4G keyboard and mouse combo, detailing features, specifications, and multimedia key functions. Includes FCC compliance information and support contact.
	MageGee K1 Keyboard and Mouse User Manual Comprehensive user manual for the MageGee K1 keyboard and mouse, detailing features, specifications, multimedia key functions, combination key instructions, and warranty information.
	G10 Backlit Voice Remote with Air Mouse & QWERTY Keyboard - Product Overview Explore the G10 backlit voice remote, a versatile 2.4GHz device featuring an air mouse, full QWERTY keyboard, and voice control for PC, Android TV Box, and smart TVs. Includes specifications and important usage notices.
	Magegee V920 Keyboard & Mouse Combo User Guide User guide for the Magegee V920 Keyboard & Mouse Combo, detailing features, specifications, and multimedia key functions for both the keyboard and mouse.