

Manuals.plus /

- › vidaXL /
- › vidaXL Garden Marquee 118.1"x118.1" (Model 48033) Instruction Manual

vidaXL 48033

vidaXL Garden Marquee 118.1"x118.1" (Model 48033) Instruction Manual

Model: 48033 | Brand: vidaXL

1. INTRODUCTION

This manual provides essential instructions for the safe assembly, operation, and maintenance of your vidaXL Garden Marquee, Model 48033. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image 1.1: Overview of the vidaXL Garden Marquee. This image displays the fully assembled white marquee with its black

powder-coated steel frame, providing a general view of the product.

2. SAFETY INFORMATION

WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

- Always follow the manufacturer's instructions for safe setup, use, and dismantling.
- Ensure the product is properly anchored during windy conditions to prevent damage or injury.
- Keep the marquee away from heat sources, open flames, and sparks to prevent fire hazards.
- Do not use the marquee in extreme weather conditions, including heavy rain, strong winds, or snow.
- Regularly inspect all components for wear and tear. Replace damaged parts immediately.
- Keep children and pets away from the assembly area.

3. PACKAGE CONTENTS

Before assembly, verify that all parts listed in the packaging list are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Powder-coated steel frame components
- Fabric roof canopy with polyamide coating
- Assembly hardware (bolts, nuts, washers, etc.)
- Ground stakes or anchoring ropes (if included)

4. ASSEMBLY INSTRUCTIONS

Assembly requires at least two adults. Ensure you have sufficient space and all tools required (e.g., wrench, ladder) before starting.

1. **Unpack and Identify Components:** Carefully unpack all parts and lay them out on a clean, flat surface. Refer to the parts diagram (if provided in your physical manual) to identify each component.
2. **Assemble Base Frame:** Connect the horizontal and vertical steel frame components to form the base structure of the marquee. Secure all connections with the provided hardware, but do not fully tighten bolts until the entire frame is assembled.



Image 4.1: Side view of the marquee frame. This image illustrates the structural design of the powder-coated steel frame, highlighting the connection points for the legs and roof support.

3. **Attach Roof Frame Components:** Connect the upper frame components that will support the roof canopy. Ensure all connections are secure.




Image 4.2: Detail of a frame corner. This close-up shows the intricate design and connection of the steel frame at a corner, indicating robust construction.

4. **Install Canopy:** Carefully drape the fabric roof canopy over the assembled roof frame. Ensure the canopy is centered and evenly distributed. Secure the canopy to the frame using any integrated fasteners (e.g., Velcro straps, ties).



Image 4.3: Canopy and frame connection detail. This image provides a closer look at how the white fabric canopy attaches to the black steel frame, showing the fit and finish.

5. **Final Tightening and Anchoring:** Once all components are in place and the canopy is secured, fully tighten all bolts. Anchor the marquee to the ground using the provided stakes or ropes to ensure stability, especially in outdoor conditions.

5. OPERATING INSTRUCTIONS

The vidaXL Garden Marquee is designed for temporary outdoor use as a sunshade or shelter for events. It is not intended for permanent installation.

- **Placement:** Choose a level, clear area for setup, away from overhead power lines, trees, or other obstructions.
- **Anchoring:** Always ensure the marquee is securely anchored to the ground to prevent it from being lifted by wind. Use all provided stakes and ropes.
- **Weather Conditions:** Do not use the marquee during strong winds, heavy rain, hail, or snow. Dismantle the marquee and store it in severe weather to prevent damage.
- **Ventilation:** The marquee features a double-vented design for improved airflow. Ensure these vents are not obstructed.

6. MAINTENANCE

- **Cleaning:** Clean the canopy fabric with mild soap and water. Do not use harsh chemicals or abrasive cleaners, as these can damage the polyamide coating. Rinse thoroughly and allow to air dry completely before storage.
- **Frame Care:** Wipe the steel frame with a damp cloth to remove dirt. Inspect the powder coating for any chips or scratches and touch up with appropriate paint to prevent rust.
- **Storage:** When not in use, or during adverse weather, dismantle the marquee and store all components in a dry, protected area. Ensure the canopy is completely dry before folding to prevent mildew.
- **Inspection:** Periodically check all bolts, nuts, and frame connections for tightness. Re-tighten as necessary. Inspect the canopy for tears or damage.

7. TROUBLESHOOTING

- **Marquee is unstable:** Ensure all frame connections are fully tightened. Verify that the marquee is properly anchored to the ground with stakes and ropes. Check for uneven ground.
- **Canopy does not fit correctly:** Ensure the frame is assembled squarely and all parts are oriented correctly. The canopy should be stretched evenly over the frame.
- **Water pooling on canopy:** This may indicate improper tensioning of the canopy or an issue with the frame's pitch. Ensure the canopy is taut and the frame is assembled according to instructions to allow water runoff.
- **Rust on frame:** The frame is powder-coated steel. If scratches or chips occur, touch up with rust-inhibiting paint to prevent further corrosion.

8. SPECIFICATIONS

Feature	Specification
Brand	vidaXL
Model Number	48033
Color	White
Roof Material	Fabric with polyamide coating (Polyester)
Frame Material	Powder-coated steel (Alloy Steel)
Overall Dimensions (L x W x H)	118.1" x 118.1" x 106.2" (300 cm x 300 cm x 270 cm)
Roof Size	118.1" x 118.1" (300 cm x 300 cm)
Roof Clearance	78.7" (200 cm)
Item Weight	62.4 pounds
UV Protection	True
Water Resistance Level	Waterproof
Assembly Required	Yes




Image 8.1: Marquee dimensions diagram. This image provides a visual representation of the marquee's length, width, and height, including roof clearance, with measurements in both inches and centimeters.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or visit the official vidaXL website. Keep your proof of purchase for any warranty claims.

For further assistance, you may contact vidaXL customer service through their official channels.