

[Manuals.plus](#) /

› [ALLIMITY](#) /

› ALLIMITY CT-RC1US-16 Replacement Remote Control User Manual for Toshiba LED TVs

ALLIMITY CT-RC1US-16

ALLIMITY CT-RC1US-16 Replacement Remote Control User Manual

Model: CT-RC1US-16 | Brand: ALLIMITY

1. INTRODUCTION

This manual provides instructions for the ALLIMITY CT-RC1US-16 Replacement Remote Control, designed for use with various Toshiba LED TV models. This remote control operates using infrared (IR) technology and requires no programming; simply insert batteries to begin use.



Image 1: Front view of the ALLIMITY CT-RC1US-16 replacement remote control, showing all buttons and layout.

2. SETUP

To prepare your remote control for use, follow these steps:

1. **Open the Battery Compartment:** Locate the battery cover on the back of the remote control. Slide the cover downwards or press the latch (if present) to open it.
2. **Insert Batteries:** Insert two (2) AAA batteries into the compartment. Ensure the positive (+) and negative (-) terminals of the batteries match the markings inside the compartment.
3. **Close the Battery Compartment:** Slide the battery cover back into place until it clicks securely.

The remote control is now ready for use. No additional programming is required.





Image 2: Back view of the remote control with the battery compartment open, showing where to insert two AAA batteries.

3. OPERATING INSTRUCTIONS

This remote control operates via infrared (IR) signals. For optimal performance, follow these guidelines:

- **Aim at the Sensor:** Point the remote control directly towards the infrared sensor on your Toshiba LED TV.
- **Avoid Obstacles:** Ensure there are no objects blocking the line of sight between the remote control and the TV's IR sensor.
- **Button Functions:** The remote features standard TV control buttons including power, input, volume up/down, channel up/down, number pad, menu, navigation, and playback controls. Refer to your TV's user manual for specific functions of each button if needed.

4. MAINTENANCE

To ensure the longevity and proper functioning of your remote control, consider the following maintenance tips:

- **Cleaning:** Wipe the remote control periodically with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones.
- **Storage:** Store the remote control in a dry place, away from direct sunlight and extreme temperatures. If not used for an extended period, remove the batteries to prevent leakage.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

5. TROUBLESHOOTING

If you experience issues with your remote control, try the following troubleshooting steps:

- **Remote Not Responding:**
 - Check if the batteries are inserted correctly with the correct polarity (+/-).
 - Replace old batteries with new AAA batteries.
 - Ensure there are no obstructions between the remote and the TV's IR sensor.
 - Confirm you are pointing the remote directly at the TV's IR sensor.
- **Limited Functionality:**
 - While this remote is designed for specific Toshiba models, some advanced or smart TV functions might require the original TV remote or a universal remote with programming capabilities.

6. SPECIFICATIONS

Feature	Detail
Model Number	CT-RC1US-16 (AMT-CT-RC1US-16)
Brand	ALLIMITY

Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Product Material	Plastic
Color	Black
Product Dimensions	7 x 2 x 0.7 inches (approximately)
Item Weight	2 ounces (approximately)
Special Feature	Ergonomic design
Max Number of Supported Devices	1 (Television)

7. COMPATIBLE TOSHIBA LED TV MODELS

This ALLIMITY CT-RC1US-16 remote control is compatible with the following Toshiba LED TV models:

- 32L220U
- 43L420U
- 49L420U
- 50L420U
- 65L350U
- 28L110U
- 32L110U

If your specific Toshiba TV model is not listed, please contact the manufacturer or seller for compatibility confirmation.

8. SUPPORT

For further assistance or inquiries regarding your ALLIMITY CT-RC1US-16 remote control, please contact the seller or manufacturer directly. Refer to your purchase documentation for contact details.

For product support related to Toshiba TVs, you may visit the official Toshiba TV support website or contact their customer service. A common support link for Toshiba TVs is www.tv.toshiba.com. For US & Canada Market support, you may call 855-527-2411.