

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [TOPINCN](#) /

› TOPINCN Replacement Brush for Shark IF100, HV390, HV391, HV392, IC205 Series Vacuum Cleaners

## TOPINCN Replacement Brush for Shark IF100, HV390, HV391, HV392, IC205 Series

# TOPINCN Replacement Brush for Shark IF100, HV390, HV391, HV392, IC205 Series Vacuum Cleaners

Instruction Manual

## 1. INTRODUCTION

---

This manual provides essential information for the proper installation, operation, and maintenance of your TOPINCN replacement soft main brush. This brush is designed to be compatible with specific Shark vacuum cleaner models, including the IF100, HV390, HV391, HV392, and IC205 series. Regular replacement of your vacuum's brush roll is crucial for maintaining optimal cleaning performance and extending the life of your appliance.

The replacement brush features an anti-winding design, ensuring efficient dust collection into the dust box and preventing hair from tangling around the brush.



Image 1.1: Overview of the TOPINCN replacement soft main brush.

## 2. SAFETY INFORMATION

---

- Always unplug your vacuum cleaner from the power outlet before performing any maintenance, installation, or removal of parts.

- Ensure your hands are dry before handling electrical components or plugging/unplugging the vacuum.
- Keep fingers, hair, and loose clothing away from moving parts.
- Do not operate the vacuum cleaner without the brush roll properly installed.

### 3. INSTALLATION GUIDE

---

Follow these steps to replace the brush roll in your compatible Shark vacuum cleaner. For detailed instructions specific to your vacuum model, refer to your original Shark vacuum cleaner manual.

1. **Power Off and Unplug:** Ensure the vacuum cleaner is turned off and unplugged from the wall outlet to prevent accidental operation.
2. **Access the Brush Roll Compartment:** Lay the vacuum cleaner flat on its back. Locate the brush roll access cover, typically on the bottom of the cleaner head.
3. **Remove the Old Brush Roll:** Depending on your model, you may need to unlatch clips or unscrew fasteners to open the brush roll compartment. Carefully lift out the old brush roll. Note the orientation of the brush roll for correct installation of the new one.
4. **Inspect and Clean:** While the compartment is open, inspect for any debris, hair, or obstructions that may have accumulated. Clean the area thoroughly before installing the new brush.
5. **Install the New Brush Roll:** Align the new TOPINCN replacement brush roll with the slots or gears in the vacuum cleaner head. Ensure the ends of the brush roll are properly seated. One end typically has a 'PULL' mechanism for easy removal and installation.



Image 3.1: Detail of the brush roll end, showing the 'PULL' mechanism for secure fitting.

6. **Secure the Compartment:** Close the brush roll access cover and secure any latches or screws that were removed. Ensure it is firmly closed before use.
7. **Test Operation:** Plug in the vacuum cleaner and turn it on to ensure the new brush roll spins freely and operates correctly.




Image 3.2: The replacement brush shown in context with a compatible vacuum cleaner head.

## 4. OPERATING THE BRUSH ROLL

---

Once installed, the TOPINCN replacement soft main brush functions automatically with your Shark vacuum cleaner. Its design is optimized for effective cleaning across various floor types.

- **Efficient Cleaning:** The soft wool and plastic construction, combined with its rotating action, efficiently sweeps dust and debris into the vacuum's dust box.
- **Anti-Winding Feature:** The brush is designed to minimize hair and string entanglement, contributing to consistent performance and reducing the frequency of manual cleaning.
- **Optimal Performance:** A properly installed and maintained brush roll is essential for your vacuum cleaner to pick up dirt and debris effectively.

## 5. MAINTENANCE

---

Regular maintenance of your replacement brush roll will ensure its longevity and the continued efficiency of your vacuum cleaner.

1. **Regular Inspection:** Periodically inspect the brush roll for any signs of wear, damage, or excessive debris accumulation.
2. **Remove Tangled Debris:** Using scissors or a brush cleaning tool, carefully cut and remove any hair,

string, or fibers that have become tangled around the brush bristles.

- Clean the Brush:** If necessary, gently wipe the brush roll with a damp cloth. Ensure it is completely dry before reinstalling it into the vacuum cleaner. Do not submerge the brush roll in water.
- Check End Caps:** Ensure the end caps of the brush roll are free from debris and can rotate smoothly.
- Replacement Frequency:** The lifespan of a brush roll varies depending on usage. Replace the brush roll when bristles show significant wear, or if cleaning performance noticeably declines, typically every 6-12 months for average household use.

## 6. TROUBLESHOOTING

---

If you encounter issues with your replacement brush roll, refer to the following common troubleshooting steps:

- **Brush Roll Not Spinning:**
  - Ensure the vacuum is unplugged.
  - Check for any obstructions (e.g., large debris, tangled hair) preventing the brush from rotating.
  - Verify that the brush roll is correctly seated in its compartment and the cover is securely closed.
- **Reduced Cleaning Performance:**
  - Inspect the brush for excessive wear or damage to the bristles.
  - Clean any tangled hair or debris from the brush roll.
  - Ensure the vacuum's filters are clean and the dust bin is empty.
- **Unusual Noise from Brush Area:**
  - Unplug the vacuum.
  - Remove the brush roll and inspect for any foreign objects lodged in the brush or its compartment.
  - Check the brush roll for any damage or bent components.
- **Brush Roll Does Not Fit:**
  - Double-check the compatibility list to ensure your Shark vacuum model is supported (IF100, HV390, HV391, HV392, IC205).
  - Ensure the brush is oriented correctly during installation.

## 7. SPECIFICATIONS

---

<b>Item Type</b>	Vacuum Cleaner Brush
<b>Material</b>	Plastic + Metal + Soft Wool
<b>Length</b>	Approx. 22.5 cm / 8.9 in
<b>Weight</b>	Approx. 196 g / 6.9 oz
<b>Compatible Models</b>	Shark IF100, HV390, HV391, HV392, IC205 Series



Image 7.1: The replacement brush showing its approximate length.

## 8. WARRANTY AND SUPPORT

---

Specific warranty information for this TOPINCN replacement brush is not provided within this manual. For any product support or warranty inquiries, please refer to the retailer or manufacturer's official website where the product was purchased.

