

[manuals.plus](#) /

› [ALLIMITY](#) /

› [ALLIMITY AH59-02306A Replacement Remote Control User Manual for Samsung AV Receiver Systems](#)

ALLIMITY AH59-02306A

ALLIMITY AH59-02306A Replacement Remote Control User Manual

For Samsung AV Receiver Systems

INTRODUCTION

This manual provides instructions for the ALLIMITY AH59-02306A replacement remote control, designed for use with various Samsung AV Receiver Systems. This remote operates using infrared (IR) technology and requires no programming; simply insert batteries for immediate use.





Figure 1: Front view of the ALLIMITY AH59-02306A Replacement Remote Control.

SETUP

Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.







Figure 2: Back view of the remote control showing the open battery compartment for AAA batteries.

OPERATING INSTRUCTIONS

This remote control operates via infrared (IR) signals. For optimal performance, observe the following:

- **Aiming:** Point the remote control directly towards the infrared sensor on your Samsung AV Receiver System.
- **Obstacles:** Ensure there are no physical obstructions (e.g., furniture, objects) between the remote control and the receiver's sensor.
- **Range:** Operate the remote within a reasonable distance from the receiver.
- **No Programming:** This replacement remote control does not require any programming. Once batteries are installed, it is ready for use with compatible Samsung AV Receiver Systems.

MAINTENANCE

- **Cleaning:** To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote control's response becomes inconsistent or stops working. Always replace both batteries simultaneously with new ones of the same type (AAA).
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

TROUBLESHOOTING

Remote Control Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace old or depleted batteries with new AAA batteries.
- **Line of Sight:** Verify that there are no obstructions between the remote control and the AV receiver's infrared sensor.
- **Distance:** Move closer to the AV receiver to ensure you are within the effective operating range.
- **Receiver Sensor:** Confirm that the infrared sensor on your Samsung AV Receiver System is not blocked or dirty.

SPECIFICATIONS

Model Number	AH59-02306A / AH5902306A
Brand	ALLIMITY
Product Material	Plastic

Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Dimensions	Approximately 7 x 2 x 0.7 inches
Item Weight	Approximately 2 ounces

COMPATIBLE SAMSUNG AV RECEIVER MODELS

This ALLIMITY AH59-02306A replacement remote control is compatible with the following Samsung AV Receiver Systems:

- HW-C700
- HW-C700B
- HW-C770S
- HW-C770BS
- HW-C560S
- HW-C500
- HW-C500/XAA
- HW-C700/XAA
- HWC700
- HWC700B
- HWC770S
- HWC770BS
- HWC560S
- HWC500
- HWC500/XAA
- HWC700/XAA

SUPPORT

If your specific model is not listed or if you encounter any issues not covered in this manual, please contact the seller for assistance. Provide your product model number for efficient support.