Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY BA59-03528A

User Manual: BA59-03528A Replacement Remote Control

For Samsung All-in-One PC Models

1. Introduction

This manual provides instructions for the ALLIMITY BA59-03528A Replacement Remote Control. This remote is designed to function as a direct replacement for the original remote control of various Samsung All-in-One PC models.

Compatible Samsung All-in-One PC Models:

- DP300A2A
- DP500A2D
- DP300A2A-A01US
- DP500A2D-EXP
- DP500A2D-A02UK
- DP300A2AA01US
- DP500A2DEXP
- DP500A2DA02UK

This remote control operates using Infrared (IR) technology and requires no programming. Simply insert batteries to begin use.





Image 1.1: Front view of the BA59-03528A Replacement Remote Control, showing all buttons and the model number at the bottom.

2. Safety Information

- Do not expose the remote control to direct sunlight or heat sources.
- Avoid dropping the remote control or subjecting it to strong impacts.
- Do not immerse the remote control in water or any other liquid.
- Keep batteries out of reach of children. If swallowed, seek immediate medical attention.
- Dispose of used batteries according to local regulations.

3. Package Contents

The package includes:

- 1 x BA59-03528A Replacement Remote Control

Note: Batteries are not included and must be purchased separately.

4. Setup

4.1 Battery Installation

The remote control requires two (2) AAA batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, ensuring it clicks securely into place.





Image 4.1: Back view of the remote control with the battery compartment open, illustrating the correct orientation for AAA battery insertion.

Once batteries are installed, the remote control is ready for use. No additional programming is required.

5. Operating Instructions

To operate your Samsung All-in-One PC with this replacement remote control:

1. **Aiming:** Point the remote control directly towards the infrared (IR) sensor on your Samsung All-in-One PC.
2. **Obstacles:** Ensure there are no physical obstructions between the remote control and the PC's IR sensor.
3. **Distance:** Operate the remote within a reasonable range of the PC's IR sensor.
4. **Functionality:** Press the desired buttons to control your PC's functions, such as power, volume, channel, navigation, and media playback.





Image 5.1: Angled view of the remote control, demonstrating its form factor for comfortable handling.

6. Maintenance

6.1 Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. Do not use abrasive cleaners, solvents, or wet cloths, as these can damage the remote's finish or internal components.

6.2 Battery Replacement

If the remote control's performance degrades (e.g., reduced range, unresponsive buttons), it may be time to replace the batteries. Follow the battery installation steps in Section 4.1 to replace the old batteries with new AAA batteries.
Always replace both batteries at the same time with new ones. Do not mix old and new batteries, or different types of batteries.

7. Troubleshooting

Problem	Possible Cause	Solution
Remote control is not working.	• Batteries are dead or inserted incorrectly. • Obstruction between remote and PC sensor. • Remote is too far from the PC.	• Replace batteries with new AAA batteries, ensuring correct polarity. • Remove any objects blocking the line of sight to the PC's IR sensor. • Move closer to the PC.
Buttons are unresponsive or delayed.	• Low battery power. • Interference from other electronic devices.	• Replace batteries. • Ensure no other IR devices are causing interference.

If you encounter issues not listed here or if the problem persists, please refer to the "Support" section for assistance.

8. Specifications

Model Number	BA59-03528A / AMT-BA59-03528A
Brand	ALLIMITY
Product Material	Plastic
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Product Dimensions	7 x 2 x 0.7 inches (17.8 x 5.1 x 1.8 cm)
Item Weight	2 ounces (56.7 grams)
Compatible Devices	Samsung All-in-One PC (Models: DP300A2A, DP500A2D, DP300A2A-A01US, DP500A2D-EXP, DP500A2D-A02UK, DP300A2AA01US, DP500A2DEXP, DP500A2DA02UK)

9. Support

For further assistance, questions regarding compatibility, or if you cannot find your specific model listed, please contact the seller directly via email.
Note: We only list the model numbers we have known. If you cannot find yours, please contact us via email, we will help to find the correct remote control you need.

© 2023 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B089B5W375

More documents and user manuals: **https://manuals.plus/**