

## Conair 2735ABR

# Conair Diamond Rotating Hair Dryer Brush 110V

Model: 2735ABR

## IMPORTANT SAFETY INSTRUCTIONS

---

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- **DANGER:** Keep away from water. As with most electrical appliances, electrical parts are electrically live even when the switch is off. To reduce the risk of death by electric shock:
- Always unplug this appliance immediately after using.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- If an appliance falls into water, unplug it immediately. Do not reach into the water.
- **WARNING:** To reduce the risk of burns, electrocution, fire, or injury to persons:
- This appliance should never be left unattended when plugged in.
- Do not pull, twist, or wrap line cord around appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped, damaged, or dropped into water. Do not attempt to repair the appliance. Incorrect reassembly or repair could cause a risk of fire, electric shock, or injury to persons when the appliance is used. Return the appliance to an authorized service center for examination and repair.
- Keep the cord away from heated surfaces.
- Never use while sleeping.
- Never drop or insert any object into any opening.

- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.
- Do not direct hot air toward eyes or other heat-sensitive areas.
- Attachments may be hot during use. Allow them to cool before handling.
- Do not place appliance on any surface while it is operating.
- While using the appliance, keep your hair away from the air inlets.
- Do not operate with a voltage converter.
- Do not overload the power outlet.
- Unplug the dryer whenever it is not in use.

## PRODUCT OVERVIEW

---

The Conair Diamond Rotating Hair Dryer Brush is designed to dry, straighten, and style your hair with ease. It features an exclusive Diamond Technology combined with ceramic plates and ionic conditioning to seal hair cuticles, eliminate frizz, and create long-lasting styles with enhanced shine. This versatile tool is suitable for all hair types, whether dry, damp, or wet, and comes with two interchangeable rotating brushes of different sizes to cater to various styling needs, from short to long hair, including bangs and ends.



The Conair Diamond Rotating Hair Dryer Brush, including its main body, two interchangeable brush heads, and power cord.

# MUITO MAIS COMPLETA

Diferentes escovas, infinitas possibilidades

The product includes two rotating brush heads of different sizes for versatile styling.

## Key Features:

- **Diamond Technology:** Infused with diamond particles for enhanced shine and smooth results.
- **Ceramic Plates:** Provides even heat distribution to protect hair from damage.
- **Ionic Conditioning:** Reduces frizz and static, leaving hair soft and manageable.
- **Dual Rotating Brushes:** Two brush sizes (large and small) for styling various hair lengths and types.
- **Multiple Heat Settings:** Offers different temperature levels for customized styling.
- **Cool Shot Function:** Helps to set the style for long-lasting hold.
- **Swivel Cord:** 360-degree rotating cord for tangle-free use.

## Product Demonstration Video

Your browser does not support the video tag.

This video demonstrates the features and usage of the Conair Diamond Rotating Hair Dryer Brush, showcasing its ability to dry, straighten, and style various hair types.

## SETUP

---

1. **Unpack:** Carefully remove the hair dryer brush and all accessories from the packaging.
2. **Attach Brush Head:** Select the desired brush head (larger for volume, smaller for tighter curls or bangs). Align the brush head with the main unit and push it firmly until it clicks into place. Ensure it is securely attached before use.
3. **Power Connection:** Ensure your hands are dry. Plug the appliance into a 110V electrical outlet. Do not use an adapter or extension cord.

## OPERATING INSTRUCTIONS

---

For best results, ensure hair is towel-dried and detangled before use. You can use the brush on dry, damp, or even wet hair.



The control panel showing power, heat settings, and rotation buttons.

1. **Power On:** Slide the power switch to the desired heat setting. The available settings are typically:
  - **'0' (Off):** Turns the appliance off.
  - **'I' (Low Heat):** For fine or delicate hair.
  - **'II' (High Heat):** For thick or coarse hair.
  - **'\*\*' (Cool Shot):** For setting styles with cool air.
2. **Section Hair:** Divide your hair into manageable sections.
3. **Styling:** Place the brush under a section of hair, close to the roots. Press the rotation button (left or right arrow) to make the brush rotate. Guide the brush slowly down the hair section, allowing the bristles to grip and smooth the hair.
  - For straightening: Keep the brush moving downwards.
  - For volume: Lift the brush upwards at the roots.
  - For curls/waves: Wrap the hair around the brush and hold for a few seconds before releasing.
4. **Cool Shot:** Once a section is styled, use the cool shot setting to lock in the style.
5. **Repeat:** Continue with all sections of hair until desired style is achieved.
6. **Power Off:** After use, slide the power switch to '0' (Off) and unplug the appliance from the outlet.



A user demonstrating the styling process with the rotating brush.

## CARE AND MAINTENANCE

---

Proper care ensures the longevity and performance of your Conair Diamond Rotating Hair Dryer Brush.

- Cleaning:** Ensure the appliance is unplugged and completely cool before cleaning.
  - Remove any hair tangled in the bristles of the brush head.
  - Wipe the surface of the appliance with a damp cloth. Do not use abrasive cleaners or immerse the appliance in water.
  - The brush heads can be gently cleaned with a soft, damp cloth. Ensure they are completely dry before reattaching or storing.
- Storage:** Store the appliance in a cool, dry place. Do not wrap the cord around the appliance, as this can cause damage. Hang it by the loop provided or store it loosely coiled.
- Filter Cleaning:** Regularly check and clean the rear filter to prevent lint and dust buildup, which can affect performance and lead to overheating. Twist and remove the filter cover, clean with a small brush or vacuum, then replace.

## TROUBLESHOOTING

---

If you encounter issues with your Conair Diamond Rotating Hair Dryer Brush, refer to the following common solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in correctly; power outlet issue; internal fault.	Ensure the plug is fully inserted into a working 110V outlet. Test the outlet with another appliance. If the problem persists, contact customer support.
Brush is not rotating.	Rotation button not pressed; hair tangled in bristles; internal mechanism issue.	Ensure you are pressing the correct rotation button (left or right). Check for and remove any hair or debris obstructing the brush rotation. If the issue continues, discontinue use and contact support.
Appliance overheats or shuts off automatically.	Blocked air intake/outlet; prolonged use; internal safety mechanism activated.	Unplug the appliance and allow it to cool down completely. Clean the air filter at the rear of the appliance. Ensure air vents are clear during use. If it continues to shut off, contact customer support.
Hair is not styling effectively.	Incorrect heat setting; hair sections too large; improper technique.	Use a higher heat setting for thicker hair. Work with smaller sections of hair. Ensure the brush is moving slowly and evenly through the hair.

## TECHNICAL SPECIFICATIONS



Product certified by INMETRO and SGS for safety standards.

Feature	Detail
Brand	Conair
Model Number	2735ABR
Voltage	110 Volts
Wattage	900 watts
Hair Type	All hair types
Product Dimensions	10 x 8 x 40 cm
Product Weight	700 g
Included Components	Two rotating brushes
Power Source	Corded Electric

## WARRANTY AND CUSTOMER SUPPORT

---

This Conair product is manufactured to the highest standards and is warranted against defects in materials and workmanship for a period of 1 year from the date of purchase. This warranty does not cover damage caused by misuse, abuse, or unauthorized modifications.

For warranty claims, technical assistance, or general inquiries, please refer to the contact information provided on your product packaging or visit the official Conair website. Please retain your proof of purchase for any warranty service.