

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [mDesign](#) /

› [mDesign Plastic Stacking Food Storage Bin User Manual - Model 13787MDKEU](#)

mDesign 13787MDKEU

mDesign Plastic Stacking Food Storage Bin User Manual

Model: 13787MDKEU

Brand: mDesign

INTRODUCTION

Thank you for choosing the mDesign Plastic Stacking Food Storage Bins. These versatile clear bins are designed to help organize various items in your home, including food, household supplies, and personal belongings. Their stackable design maximizes vertical storage space, making them ideal for pantries, cabinets, shelves, refrigerators, and freezers. This manual provides essential information for the proper use and care of your storage bins.

PRODUCT FEATURES


- **Stackable Design:** Allows for efficient vertical storage, maximizing space in tight areas.
- **Clear Construction:** Transparent plastic enables easy visibility of contents, simplifying item retrieval.
- **Durable Material:** Constructed from sturdy plastic for long-lasting use.
- **Open Front:** Provides convenient access to stored items without needing to unstack or remove the entire bin.
- **Versatile Use:** Suitable for various environments including kitchens, pantries, refrigerators, freezers, bathrooms, and closets.



Image: Two mDesign clear plastic stacking bins, demonstrating their stackable nature. One bin is empty, and the other is filled with various snack bags, showcasing the open front for easy access.

SETUP AND ASSEMBLY

- 1. Unboxing:** Carefully remove the storage bins from their packaging. Inspect each bin for any signs of damage.
- 2. Initial Cleaning:** Before first use, wash the bins with mild soap and water. Rinse thoroughly and dry completely.
- 3. Stacking:** To stack the bins, align the bottom edges of the upper bin with the recessed grooves on the top edges of the lower bin. Gently press down to ensure a secure fit. The design includes small protrusions on the bottom of each bin that fit into corresponding indentations on the top of another, ensuring stability when stacked.



Stackable storage

Image: A visual representation of how the mDesign clear plastic bins are designed to stack securely, with an arrow indicating the stacking direction.

OPERATING INSTRUCTIONS (USAGE)

These storage bins are designed for organizing a wide range of items in various household environments. Their open front allows for quick and easy access to contents.

Recommended Uses:

- **Kitchen & Pantry:** Store fruits, vegetables (potatoes, onions), snacks, pasta, drinks, baking supplies, and packaged goods. The open front makes it easy to grab items quickly.
- **Refrigerator & Freezer:** Organize produce, packaged foods, and frozen items. The clear design helps identify contents at a glance.
- **Bathroom:** Keep toiletries, towels, and cleaning supplies neatly arranged.
- **Closet & Craft Room:** Store accessories, craft supplies, or small clothing items.



Image: A pantry shelf organized with multiple mDesign clear plastic bins, holding items like coconut flour, sprinkles, cupcake liners, snacks, and beverages.

BATH



BABY



CRAFT



CLOSET



Image: A collage illustrating the versatility of the mDesign bins, showing them organizing towels in a bathroom, diapers in a baby room, crayons in a craft area, and wallets in a closet.

Official Product Videos:

Video: This video from mDesign demonstrates the stackable bins in various home settings, highlighting their utility for organizing different items and maximizing space.

Video: An official mDesign video showcasing the clear plastic stackable food storage organizer bins, illustrating their design and how they can be used to organize pantry items.

MAINTENANCE

To maintain the clarity and integrity of your mDesign storage bins, follow these cleaning instructions:

- **Cleaning:** Wash by hand with mild soap and water. Avoid abrasive cleaners or scrubbers that could scratch the plastic surface.
- **Drying:** Air dry or wipe with a soft cloth to prevent water spots.
- **Dishwasher Use:** These bins are not recommended for dishwasher use, as high temperatures can cause warping or damage to the plastic.

TROUBLESHOOTING

Warping or Instability When Stacking:

If you experience issues with bins not stacking properly or appearing warped, consider the following:

- **Temperature Exposure:** Extreme temperatures, such as those in a dishwasher or prolonged direct sunlight, can affect the plastic's shape. Always hand wash and avoid placing in very hot environments.
- **Even Weight Distribution:** Ensure that the weight of items within the bins is distributed evenly, especially in the top bins of a stack, to prevent imbalance.
- **Proper Alignment:** Double-check that the bins are correctly aligned with the stacking grooves. A slight misalignment can cause instability.

SPECIFICATIONS

Attribute	Detail
Model Number	13787MDKEU
Dimensions (D x W x H)	5"D x 8"W x 11"H (12.7cm D x 20.3cm W x 27.9cm H)
Material	Plastic
Color	Clear
Special Feature	Stackable
Number of Items	4
Item Weight	3.91 pounds
UPC	192173137871




Image: A diagram illustrating the precise dimensions of a single mDesign storage bin, including depth, width, and height in both inches and centimeters.

WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your mDesign Plastic Stacking Food Storage Bins, please contact mDesign customer service. Refer to your product packaging or the official mDesign website for the most current contact information and warranty details.