

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Queenmew](#) /

› [Queenmew Dog Bark Collar User Manual](#)

### Queenmew Citronella Spray Anti Barking Device

## Queenmew Dog Bark Collar USER MANUAL

### Introduction

Thank you for choosing the Queenmew Dog Bark Collar. This device is designed to help train your dog to reduce excessive barking using safe and humane methods. It utilizes citronella spray and warning beeps, providing a gentle yet effective deterrent without electric shock. Please read this manual thoroughly before use to ensure proper operation and the well-being of your pet.



Image: The Queenmew Dog Bark Collar receiver and remote control. The collar is black with an orange panel, and the remote is black with orange buttons. A German Shepherd wearing the collar is visible in the background.

## Package Contents

Please verify that all items listed below are included in your package:

- 1x Receiver Collar
- 1x Remote Control (Transmitter)
- 2x AAA Batteries (for Remote Control)
- 1x Collar Strap (Adjustable Nylon)
- 1x Lanyard
- 1x USB Charging Cable
- 1x User Manual (this document)



Image: All components included in the Queenmew Dog Bark Collar package, laid out on a white surface. This includes the collar, remote, USB cable, batteries, lanyard, and user manual.

## Product Components Overview

Familiarize yourself with the key parts of your Queenmew Dog Bark Collar system:

### 1 Microphone

Sensor of dog barking.

### 2 Spray Nozzle



### 3 Blue Led

Indicates sensitivity level.

### 4 LED light

Status Indicate:

- Turn on/off, green flash.
- Standby, green flash, 1 time per 5sec.
- Low battery, red flash, 1 time per sec.
- Low spray, red flash, 1 time per 5sec.
- Charging, red is in, green is full.

### 5 Mini USB

### 6 Refill Port

### 7 On/Off button

- Turn on: press and hold on 3secs, with 2 short beeps sound and green LED flash.
- Turn off: press and hold on 3secs, with long beep sound.
- Adjust spray nozzle sensitive, 1 time press change a level.



1 Hold the refill spray can upright and **vigorously** press the nozzle down into the refill port.

2 Hold down firmly for 15 seconds and then release.

**Note: Citronella Spray NOT Included**

Image: A detailed diagram labeling the components of the collar and remote. Key parts include the Microphone, Spray Nozzle, Blue LED (sensitivity indicator), LED light (status indicator), Mini USB port, Refill Port, and On/Off button.

**1. Microphone:** Sensor for detecting dog barking.

**2. Spray Nozzle:** Emits citronella spray.

**3. Blue LED:** Indicates sensitivity level (L, M, H).

**4. LED Light:** Status indicator for power, standby, low battery, low spray, and charging.

**5. Mini USB:** Charging port for the receiver collar.

**6. Refill Port:** For refilling citronella spray.

**7. On/Off Button:** Powers the collar on/off and adjusts sensitivity.

## Setup

### 1. Charging the Receiver Collar

The receiver collar has a built-in rechargeable Li-ion battery. Charge it fully before first use.

- Connect the USB charging cable to the Mini USB port (5) on the receiver collar.
- Plug the other end into a USB power source (e.g., computer, power bank, USB wall adapter).
- The LED light (4) will be red during charging and turn green when fully charged.
- A full charge takes approximately 2 hours and provides up to 30 days of standby time.

## 2. Installing Batteries in the Remote Control

The remote control requires 2x AAA batteries (included).

- Open the battery compartment on the back of the remote control.
- Insert the 2x AAA batteries, ensuring correct polarity (+/-).
- Close the battery compartment securely.

# Rapid Charging & Long Standby Receiver

The collar and the remote have been paired together when producing

**Remote**  
2 x AAA Batter  
(Included)



**Receiver**

Built-in **250mA** Li-ion battery  
USB rapid charging in appr.**2** hours  
Up to **30** days standby



Easy charging by your PC/Laptop/Phone chanrger/Power bank



Image: A diagram illustrating the USB charging port on the receiver collar and the battery compartment for the remote control, showing where to insert the 2x AAA batteries.

## 3. Refilling Citronella Spray

**Important: The collar does not include spray gas. Please purchase citronella spray separately.**

- Hold the refill spray can upright.
- Vigorously and firmly press the nozzle of the spray can down into the refill port (6) on the collar.
- Hold down firmly for approximately 15 seconds to ensure a full refill.
- It is recommended to fully refill the spray before each use.

### 1 Microphone

Sensor of dog barking.

### 2 Spray Nozzle

### 3 Blue Led

Indicates sensitivity level.

### 4 LED light

Status Indicate:

- Turn on/off, green flash.
- Standby, green flash, 1 time per 5sec.
- Low battery, red flash, 1 time per sec.
- Low spray, red flash, 1 time per 5sec.
- Charging, red is in, green is full.



### 5 Mini USB

### 6 Refill Port

### 7 On/Off button

- Turn on: press and hold on 3secs, with 2 short beeps sound and green LED flash.
- Turn off: press and hold on 3secs, with long beep sound.
- Adjust spray nozzle sensitive, 1 time press change a level.



**1** Hold the refill spray can upright and **vigorously** press the nozzle down into the refill port.

**2** Hold down firmly for 15 seconds and then release.

**Note: Citronella Spray NOT Included**

Image: A hand demonstrating how to refill the citronella spray into the collar's refill port using a spray can. The collar's components are also labeled.

## 4. Fitting the Collar

Proper fit is crucial for the collar's effectiveness and your dog's comfort.

- Place the collar strap on the middle of your dog's neck.
- Ensure the Spray Nozzle (2) is positioned towards your dog's nose.
- The collar should fit snugly, but loose enough to allow one finger to fit comfortably under the strap.
- For long-haired dogs, trim the neck hairs along the path of the spray to ensure proper contact and effectiveness.

# Fits for Dogs of All Sizes And Breeds

Adjustable Nylon Collar  
(8-27 inches long)



Image: Several dogs of different breeds and sizes, from small to large, wearing the adjustable nylon collar. This illustrates the collar's versatility for various dog sizes.

## Operating Instructions

### 1. Turning On/Off the Collar

- To Turn On:** Press and hold the On/Off button (7) for 3 seconds. You will hear 2 short beeps, and the green LED light (4) will flash.
- To Turn Off:** Press and hold the On/Off button (7) for 3 seconds. You will hear a long beep sound.

### 2. Adjusting Sensitivity Level

After turning on the collar, press the On/Off button (7) to cycle through sensitivity levels. The blue LED light (3) will indicate the current level:

- **L (Low):** Less sensitive to barking.
- **M (Medium):** Moderate sensitivity.
- **H (High):** Most sensitive to barking.

### 3. Operating Modes

The Queenmew Dog Bark Collar offers two operating modes: Remote Control Mode and Auto Anti-Bark Mode. You cannot use both modes simultaneously.

#### Remote Control Mode

This mode allows you to manually activate the spray or beep functions using the remote control within a range of up to 500 feet.

- Ensure the collar is turned on.
- Press the desired button on the remote control to emit a beep or spray.
- This mode is ideal for direct training and correcting specific misbehaviors.

#### Auto Anti-Bark Mode

The collar automatically enters this mode if no button on the remote control is pressed within the first 1 minute after turning on the collar.


- In this mode, the collar will automatically detect your dog's bark.
- Upon detecting a bark, the collar will first emit a warning beep.
- If the barking continues, the collar will then release a short burst of citronella spray.

# 2 in 1 Auto & Manual Modes

Train dogs in different ways according to your needs



**Auto Modes**



**Manual Modes**

**Note:** The receiver collar will enter "Auto Mode" automatically if you don't use the remote control in the first 1 minute after turning on the collar. So please press any button on the remote in the first 1 minute if you want the "Remote mode"

Image: A visual representation of the two operating modes: Auto Mode, where the collar automatically responds to barking, and Manual Mode, where the user controls the spray via remote. A note emphasizes that the collar enters Auto Mode if the remote is not used within the first minute.

## 4. Training Multiple Dogs

This system allows you to train up to 2 dogs with a single remote transmitter. Additional receiver collars can be purchased separately if needed.

# Up to 500 Feet Remote Control



**Training up to 2 dogs**

**Waterproof design allows dogs to play in rainy weather**

Image: Two dogs running outdoors, one wearing the bark collar, with a hand holding the remote control. This image highlights the remote's range of up to 500 feet and the waterproof design.

## Maintenance

### Cleaning

Regularly clean the collar and receiver unit with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials.

### Waterproof Information

The receiver collar is designed to be waterproof, allowing your dog to play in splash water or rain. However, it is **not** suitable for prolonged submersion. Please remove the collar when your dog goes swimming or bathing to prevent damage.

## Indicators

- **Low Spray Indicator:** The red LED light (4) on the collar will flash 1 time every 5 seconds when the citronella spray level is low. Refill the spray as soon as possible.
- **Low Battery Indicator:** The red LED light (4) on the collar will flash 1 time per second when the battery is low. Recharge the collar promptly.

## Troubleshooting

### Why does the collar not spray or beep when my dog barks?

- **Check Mode:** Ensure the collar is in "Auto Anti-Bark Mode." If you used the remote within the first minute of turning it on, it might be in Remote Control Mode.
- **Citronella Level:** The collar may be out of citronella spray. Refill it as per the instructions in the Setup section. Remember, the collar does not come pre-filled.
- **Bark Sequence:** The collar first emits a beep sound to warn the dog. If the dog continues to bark, then it will spray. You will hear the beep first, then the spray.
- **Sensitivity:** The sensitivity level might be too low to detect your dog's bark. Adjust the sensitivity to a higher level (M or H) by pressing the On/Off button after turning on the collar. The blue LED light indicates the current level.

### How do I know when to refill the spray?

The red LED light (4) on the collar will flash 1 time every 5 seconds when the citronella spray is low. It is recommended to fully refill the spray before each use to ensure consistent operation.

## Specifications

<b>Brand</b>	Queenmew
<b>Model</b>	Citronella Spray Anti Barking Device
<b>Package Dimensions</b>	5.63 x 4.45 x 1.73 inches
<b>Item Weight</b>	9.1 ounces
<b>Collar Closure Type</b>	Button
<b>Recommended Age Range</b>	Over 6 months
<b>Remote Control Range</b>	Up to 500 feet
<b>Receiver Battery</b>	Built-in 250mA Li-ion battery
<b>Receiver Charging Time</b>	Approx. 2 hours
<b>Receiver Standby Time</b>	Up to 30 days
<b>Remote Control Battery</b>	2x 1.5V AAA Battery

## Support

If you encounter any issues or have questions regarding your Queenmew Dog Bark Collar, please contact our customer support for assistance. Refer to the product packaging or the retailer's website for specific contact information.

© 2024 Queenmew. All rights reserved.