

Znewtech ZNT-ZT-X2P

Znewtech Hexagon Productivity Timer User Manual

Model: ZNT-ZT-X2P | Brand: Znewtech

INTRODUCTION

Welcome to the Znewtech Hexagon Productivity Timer user manual. This innovative digital timer and alarm clock is designed to enhance your time management, whether for work, study, cooking, or exercise. Its intuitive design allows for quick and easy setup of preset countdowns, helping you stay focused and productive.



Image: Znewtech Hexagon Productivity Timer promotional banner.

KEY FEATURES

- **Intuitive Operation:** Start and stop countdowns by simply rotating the timer to the desired preset time.
- **Digital Display:** Clear LCD screen displays countdown time remaining and current clock time.
- **Adjustable Volume:** Four volume levels (High, Mid, Low, Silent) to suit any environment.
- **Visual Alert:** Flashing LCD backlit visual alert for silent mode or additional notification.
- **Preset Times:** Includes common preset durations for quick use (5, 10, 15, 20, 30 minutes for this model).

SETUP GUIDE

1. Battery Installation

The Znewtech Hexagon Productivity Timer requires 2 AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the underside of the timer.

2. Gently slide or unclip the cover to open the compartment.
3. Insert two AAA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover until it clicks securely into place.



Image: Rear view of the timer, highlighting the battery compartment and control buttons.

2. Initial Power-On and Clock Setting

Upon successful battery installation, the timer will power on and display the current time (default 12:00 AM). To set the correct time:

1. Ensure the timer is in 'Clock' mode (the side with the 'Clock' icon facing up).
2. On the back of the timer, locate the 'SET' button. Press and hold it until the hour digits begin to flash.
3. Use the 'UP' and 'DOWN' buttons to adjust the hour. Press 'SET' again to confirm and move to minutes.
4. Adjust the minutes using 'UP' and 'DOWN'. Press 'SET' one more time to save the time.

OPERATING INSTRUCTIONS

Using the Countdown Timer

The Znewtech Hexagon Productivity Timer features pre-set countdown times on each of its six sides. To activate a timer:

1. Identify the desired preset time (5, 10, 15, 20, or 30 minutes) on one of the timer's sides.
2. Rotate the timer so that the desired time is facing directly upwards. The timer will automatically begin counting down from that preset.
3. When the countdown reaches zero, the alarm will sound (if not in silent mode) and the LCD will flash.
4. To stop the alarm, simply rotate the timer to any other side, or press the 'SNOOZE/LIGHT' button on top.



Image: Front view of the timer, showing the digital display and preset time labels on each side.

Pause/Resume Function

During an active countdown, you can pause and resume the timer:

- To pause: Press the 'P/S' (Pause/Start) button located on the back of the timer. The countdown will freeze.
- To resume: Press the 'P/S' button again. The countdown will continue from where it left off.

Volume Adjustment

Adjust the alarm volume to High, Mid, Low, or Silent:

- Locate the 'Volume' button on the back of the timer.
- Press the 'Volume' button repeatedly to cycle through the four volume levels. The current volume level will be indicated on the display.

Snooze/Light Function

The button on the top of the timer serves two purposes:

- **Snooze:** When the alarm sounds, press this button to activate snooze (if applicable, typically 5-10 minutes).
- **Backlight:** Press this button at any time to briefly illuminate the LCD display for better visibility in low light conditions.

MAINTENANCE

Cleaning

Wipe the timer with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.

Battery Replacement

When the display dims or the timer functions become erratic, it's time to replace the batteries. Follow the 'Battery Installation' steps in the Setup Guide.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Timer not turning on/display is blank.	Batteries are dead or incorrectly installed.	Replace batteries, ensuring correct polarity.

Problem	Possible Cause	Solution
Timer not starting countdown when rotated.	Timer is not placed on a flat, stable surface; internal mechanism issue.	Ensure the timer is on a flat surface. If issue persists, contact customer support.
Alarm is too loud/quiet or not sounding.	Volume setting is incorrect.	Press the 'Volume' button on the back to adjust the sound level. Check if it's set to 'Silent'.
Display is dim or hard to read.	Low battery power or viewing angle.	Replace batteries. Adjust viewing angle or use the 'SNOOZE/LIGHT' button for temporary illumination.

SPECIFICATIONS

Brand: Znewtech

Model: ZNT-ZT-X2P

Color: Yellow

Material: Plastic

Product Dimensions: 1.5"D x 4.75"W x 4.25"H

Item Weight: 11.4 ounces (322 Grams)

Number of Settings: 5 (5, 10, 15, 20, 30 Minute Presets)

Screen Size: 2.25 Inches

Batteries: 2 AAA batteries required (not included)

Country of Origin: China

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your product packaging or visit the official Znewtech website. Contact details for customer service are typically provided on the manufacturer's website or within the product's retail packaging.