

[Manuals.plus](#) /

> [Jura](#) /

> Jura E8 Automatic Espresso Machine User Manual

Jura E8

Jura E8 Automatic Espresso Machine User Manual

Model: E8

PRODUCT OVERVIEW

The Jura E8 Automatic Espresso Machine in Piano White is designed for home brewing and coffee connoisseurs, offering a fully automatic operation with a 2.8-inch color display and six intuitive buttons. It features a Professional Aroma Grinder for flawless grinding results, ensuring maximum flavor development. The machine is capable of preparing 17 different specialties, including espresso, coffee, ristretto, hot water, cappuccino, flat white, and latte macchiato, with an integrated one-touch milk system cleaning process.



Figure 1: Front view of the Jura E8 Automatic Espresso Machine, highlighting its sleek design and dual coffee spouts.

SETUP

Before first use, ensure the machine is placed on a stable, level surface. Fill the water tank and the bean container. The machine will perform an initial rinse and heating cycle upon power-on.

1. **Unpacking:** Carefully remove all packaging materials and place the machine in its desired location.
2. **Water Tank:** Remove the water tank, rinse it thoroughly, and fill it with fresh, cold water. Reinsert the tank securely.
3. **Bean Container:** Open the aroma preservation cover and fill the bean container with fresh coffee beans. Close the cover.

4. **Power Connection:** Plug the machine into a grounded power outlet.
5. **Initial Start-up:** Press the power button. The machine will display "Machine is heating" followed by "Rinse the coffee system". Place a container under the coffee spout and milk spout to collect the rinsing water.



Figure 2: The transparent water tank, easily accessible for refilling.

OPERATING INSTRUCTIONS

The Jura E8 offers a variety of coffee specialties accessible via its intuitive display and buttons. The machine grinds fresh beans for each preparation, ensuring optimal aroma.

Brewing Coffee/Espresso:

1. **Select Beverage:** On the 2.8-inch color display, use the buttons to navigate and select your desired beverage (e.g., Espresso, Coffee, Ristretto).
2. **Adjust Spout:** Adjust the height of the coffee spout to fit your cup. The spout can be moved up or down to accommodate various cup sizes, including travel mugs.

3. **Start Brewing:** Press the button corresponding to your selection. The machine will automatically grind the beans and dispense the coffee.



Figure 3: Coffee being dispensed from the adjustable spout into a glass.

Preparing Milk-Based Specialties:

For beverages like Cappuccino, Flat White, or Latte Macchiato, the E8 features a sophisticated milk system.

1. **Connect Milk Container:** Attach the milk hose from the machine's milk frother to a Jura milk container (sold separately) or a suitable milk jug.
2. **Select Beverage:** Navigate the display to select a milk-based specialty.
3. **Adjust Froth:** Use the dial on the milk frother to adjust the desired amount of milk froth.
4. **Start Preparation:** Press the button for your selected drink. The machine will first dispense milk/froth, then coffee.



Figure 4: The Jura E8 preparing a layered milk-based coffee specialty.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Jura E8.

Daily Cleaning:

- **Rinse Coffee System:** The machine prompts for rinsing upon startup and shutdown. Ensure a container is placed under the spout.
- **Empty Drip Tray and Coffee Grounds Container:** Empty and rinse the drip tray and coffee grounds container daily. The design of the drip tray prevents water from spilling and allows for convenient one-handed removal.
- **Clean Milk System:** The E8 features a one-touch milk system cleaning process. Follow the prompts on the display to initiate this automatic cleaning cycle after preparing milk-based drinks.

Weekly/Monthly Cleaning:

- **Coffee System Cleaning:** Perform a full coffee system cleaning cycle as prompted by the machine or at least once a month, using Jura cleaning tablets.
- **Descaling:** The machine will indicate when descaling is required. Use Jura descaling tablets and follow the on-screen instructions.
- **Filter Change:** Replace the CLARIS Smart filter cartridge as prompted by the machine to ensure optimal water quality and protect against limescale.

TROUBLESHOOTING

This section addresses common issues you might encounter with your Jura E8.

Problem	Possible Cause	Solution
Machine not heating up.	Power supply issue or internal fault.	Check power connection. If issue persists, contact customer support.
Coffee not dispensing.	Water tank empty, coffee beans empty, or brewing unit clogged.	Refill water tank/beans. Perform a cleaning cycle.
Milk not frothing correctly.	Milk system dirty, milk type unsuitable, or frother dial setting.	Perform milk system cleaning. Use cold, fresh milk. Adjust frother dial.
Error message on display.	Specific issue indicated by the message.	Refer to the machine's display for specific instructions or consult the full manual.

SPECIFICATIONS

- **Brand:** Jura
- **Model:** E8
- **Coffee Maker Type:** Espresso Machine
- **Operation Mode:** Fully Automatic
- **Human Interface Input:** Buttons
- **Product Dimensions:** 20 x 17.2 x 12.4 inches
- **Item Weight:** 1 pounds
- **Filter Type:** Reusable
- **Exterior Finish:** Painted or Powder-coated

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Jura website or contact their customer service directly. Ensure you have your product model number (E8) and purchase details available when seeking support.

Jura Official Website: www.jura.com