

[Manuals.plus](#) /

› [Hatteker](#) /

› Hatteker Professional Grooming Kit User Manual

Hatteker RFC-69031

Hatteker Professional Grooming Kit User Manual

Model: RFC-69031

Brand: Hatteker

SAFETY INFORMATION

Please read all instructions carefully before using the Hatteker Professional Grooming Kit. Keep this manual for future reference.

- Use with caution near sensitive areas like the face and eyes.
- Keep small parts and accessories away from children to prevent choking hazards.
- Clean the device according to the maintenance instructions to ensure proper hygiene and performance.
- Do not immerse the charging dock in water. The grooming unit itself is waterproof.
- Avoid disassembling the unit beyond what is described in this manual.

PRODUCT OVERVIEW

The Hatteker Professional Grooming Kit is a versatile, cordless, and waterproof personal care device designed for comprehensive grooming needs. It features high-carbon self-sharpening ceramic titanium blades for precise and irritation-free cutting. The kit includes multiple interchangeable heads and adjustable settings, making it suitable for various hair and beard styles.



The Hatteker Professional Grooming Kit, showcasing the main unit, charging dock, various guide combs, and additional trimming heads.

PACKAGE CONTENTS

Your Hatteker Professional Grooming Kit includes the following items:

- Hatteker Grooming Unit (Main Body)
- Hair Clipper Head
- Beard Trimmer Head
- Detail Trimmer Head
- Precision Dial (integrated with main unit, 3mm to 8mm)
- 6 Guide Combs (3mm, 4-6mm, 7-9mm, 10-12mm, 16-18mm, 22-24mm)
- Charging Dock
- Power Adapter/USB Charging Cable
- Cleaning Brush
- Hair Comb

- Lubricating Oil

SETUP

Initial Charge

Before using your grooming unit for the first time, ensure it is fully charged. Connect the charging cable directly to the unit or place the unit in the charging dock and connect the cable to the dock. Plug the adapter into a standard power outlet. The LCD display will show the battery percentage, indicating charging progress. A full charge typically takes approximately 90 minutes and provides up to 2.5 hours of cordless operation.

Attaching Blades and Guide Combs

To attach a specific trimming head (Hair Clipper, Beard Trimmer, or Detail Trimmer), align the head with the top of the main unit and gently press down until it clicks securely into place. To remove a head, push it off from the front. For desired hair length, select the appropriate guide comb and slide it onto the trimming head until it locks. The unit also features a 5-degree tunable blade, adjustable from 0.5mm to 2.5mm by rotating the dial located just below the blade.



The Hattaker grooming unit displayed with its three interchangeable heads: hair clipper, beard trimmer, and detail trimmer, demonstrating their modular design.



Titanium Ceramic Blade



Whole Body Washable



5 Precise Length
Setting Adjustment



Switch button



LED indicator light




Precision Dial

Close-up of the Hatteker trimmer's adjustable dial, allowing precise length settings from 0.5mm to 2.5mm for fine-tuning cuts.

5-Degree Tunable Blade



From 0.5mm To 2.5mm



6 Guide Combs



3 mm



4-6 mm



7-9 mm



10-12 mm



16-18 mm



22-24 mm



Illustration of the 5-degree tunable blade settings and the various guide combs included for different hair lengths.

OPERATING INSTRUCTIONS

Power On/Off

To turn the grooming unit on or off, simply press the power button located on the front of the device. The LCD display will illuminate, showing the current battery capacity as a percentage.

Hair Clipping

For general hair clipping, attach the hair clipper head and select the appropriate guide comb for your desired length. Move the clipper slowly and steadily against the direction of hair growth for an even and consistent cut. Ensure the blades are clean and lubricated for optimal performance.

Beard Trimming

For beard trimming, you can use either the beard trimmer head or the detail trimmer head, depending on the precision required. Adjust the precision dial or attach a suitable guide comb to achieve your preferred beard length. Trim your beard using smooth, even strokes, following the contours of your face.

Detail Trimming

The detail trimmer head is specifically designed for creating sharp lines, defining edges, and intricate designs. Use this head without a guide comb for the closest possible trim. Exercise caution and precision when using the detail trimmer for delicate areas.

This video demonstrates the practical application of the Hatteker grooming kit for both hair cutting and beard trimming, showcasing its versatility and ease of use.

MAINTENANCE

Cleaning

The Hatteker grooming unit is designed to be fully washable, allowing for quick and hygienic cleaning. After each use, simply rinse the trimming head and the main unit under running water to remove hair and debris. For a more thorough clean, detach the trimming head and use the provided cleaning brush to clear any trapped hairs from both the head and the internal mechanism of the unit. Ensure the unit is completely dry before storage or next use.

Blade Lubrication

To maintain the sharpness and smooth operation of the blades, it is recommended to apply a small drop of the included lubricating oil to the blades after every few uses, especially after cleaning. Turn the unit on for a few seconds to allow the oil to distribute evenly across the blades.



The image shows the Hattaker grooming unit being cleaned under running water, highlighting its waterproof design for easy maintenance.

TROUBLESHOOTING

Device Not Turning On

- Ensure the battery is sufficiently charged. Check the LCD display for the battery percentage.
- Verify that the power button is pressed firmly and held for a moment if necessary.

Poor Cutting Performance

- Clean the blades and remove any trapped hair or debris using the provided brush.
- Apply a small drop of lubricating oil to the blades.
- Ensure the correct trimming head and guide comb are securely attached and properly aligned.
- If the issue persists, the blades may be dull and require replacement.

Skin Irritation

- Ensure blades are clean and well-lubricated. Dull or dirty blades can cause pulling and irritation.
- Trim against the direction of hair growth for a smoother cut, but adjust technique if irritation occurs.
- Avoid applying excessive pressure to the skin during use.

SPECIFICATIONS

Feature	Detail
Model Number	RFC-69031
Brand	Hatteker
Power Source	Battery Powered
Battery Type	1 A batteries (included)
Run Time	Up to 2.5 hours
Charge Time	Approx. 90 minutes
Blade Material	Ceramic Titanium
Waterproof	Yes (Whole Body Washable)
Adjustable Blade Length	0.5mm to 2.5mm (5-degree tunable)
Guide Combs Included	3mm, 4-6mm, 7-9mm, 10-12mm, 16-18mm, 22-24mm
Dimensions	8.39 x 6.3 x 2.91 inches
Weight	1.41 Pounds
Country of Origin	China

WARRANTY & SUPPORT

For warranty information, product support, or to purchase replacement parts, please contact Hatteker customer service through their official website or the retailer where the product was purchased. Please refer to your purchase receipt for specific warranty terms and conditions.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B089F5D6KQ>

More documents and user manuals: <https://manuals.plus/>